
# **PVM-2054QM**

# **SERVICE MANUAL**

AEP Model Chassis No. SCC-G62A-A



#### SPECIFICATIONS

# Video signal

Color system

PAL, SECAM, NTSC, NTSC4.43

Resolution Aperture correction

600 TV lines 0dB - +6.0dB

LINE 9.0MHz (-3 dB) Frequency response

RGB 10.0 MHz (-3 dB)

Synchronization

AFC time constant 1.0 msec.

#### Picture performance

Normal scan

7% over scan of CRT effective screen

Underscan

5% underscan of CRT effective screen

H. linearity

Less than 8.0% (typical)

V. linearity

Less than 7.0% (typical)

Convergence

Central area: 0.7 mm (typical) Peripheral area:

1.3 mm (typical)

Raster size stability

H: 1.0%, V: 1.5%

High voltage regulation

4.0%

Color temperature

SMPTE-C phosphor 6,500K/9,300K (+8MPCD), selectable USER (3200K-10000K, factory setting

is 6500K)

Remote input

Speaker output

1Vp-p ±6dB, sync negative AUDIO IN: phono jack, -5 dBs, more

than 47k ohms

R/R-Y, G/Y, B/B-Y IN: BNC

connector

R, G, B channels: 0.7 Vp-p, ±6dB Sync on green: 0.3 Vp-p, negative, 75

ohms terminated R-Y, B-Y channels: 0.7 Vp-p, ±6 dB

Y channel: 0.7 Vp-p, ±6dB (Standard color bar signal of 75%

chrominance)

EXT SYNC IN: BNC connector Composite sync 4 Vp-p, ±6 dB,

negative

Loop-through outputs

Y/C OUT: 4-pin mini DIN connector

VIDEO OUT: BNC connector, 75

ohms terminated

AUDIO OUT: phono jack R/R-Y, G/Y, B/B-Y OUT: BNC connector, 75 ohms terminated EXT SYNC OUT: BNC connector, 75

ohms terminated

REMOTE: 20-pin connector (See the

pin assignment on the next page.)

Output level 0.8 W

# **Inputs and Outputs**

Inputs

Y/C IN: 4-pin mini DIN connector (See the pin assignment on the next

VIDEO IN:BNC connector

TRINITRON® COLOR VIDEO MONITOR SONY



# General

Power consumption

Approx. 130 Wh (incl. SDI) Approx. 120 Wh (without. SDI)

100 - 240 V AC, 50/60 Hz

Power requirements

Operating temperature range 0 –35 °C Storage temperature range

−10 − +40 °C

Humidity Dimensions 0 - 90%

Approx.  $450 \times 457.5 \times 503$  mm (w/h/d)  $(17^{3}/_{4} \times 18^{1}/_{8} \times 19^{7}/_{8}$  inches)

not incl. projecting parts and controls Approx. 30 kg (66 lb 2 oz)

Mass Accessory supplied

AC power cord (1) AC plug holder (1) Tally label (1)

Cable with a 20-pin connector (1)


# Pin assignment

# Y/C IN connector (4-pin mini DIN)



Pin No.	Signal	Description
1	Y-input	1 Vp-p, sync negative, 75
	:	ohms
2	CHROMA sub-	300 mVp-p, burst
	carrier-input	Delay time between Y and C:
		within 0±100 nsec., 75 ohms
3	GND for Y-input	GND
4	GND for	GND
	CHROMA-input	

# **REMOTE connector (20-pin)**



Pin No.	Signal	Wire color
1	Blue only	Brown
2	H/V DELAY	Red
3	MAIN/SUB*	Orange
4	EXT SYNC	Yellow
5	DEGAUSS	Green
6	R ch ON/OFF*	Blue
7	TALLY	Purple
8	LINEB	Grey
9	GND	White
10	GND	Black
11	GND	Pink
12	GND	Light Blue
13	LINE A	Spiral Orange
1.4	LINE/RGB	Spiral Yellow
15	GND	Spiral Green
16	L ch ON/OFF*	Spiral Blue
17	REMOTE	Spiral Purple
18	LINEC	Spiral Grey
19	UNDER SCAN	Spiral Pink
20	16:9	Spiral Light Blue

(\* For digital audio control)

#### **TABLE OF CONTENTS**

Se	ction <u>Title</u>	<u>Page</u>	Sec	ction	<u>Title</u>	<u>Page</u>
1.	GENERAL		5.	CIRC	UIT ADJUSTMENTS	
	Features	4		5-1. /	A Board Adjustments	23
	Location and Function of Parts and Controls	5	A	5-2. (	G Board Adjustment · · · · · · · · · · · · · · · · · · ·	
	Using On-screen Menus	9			en e	*. *
	Power Sources ·····	11	6.		RAMS	
				6-1. E	Block Diagrams (1) ·····	35
2.	DISASSEMBLY			F	Block Diagrams (2) ······	40
	2-1. Top Cover and Rear Cover Removal	12			Frame Schematic Diagram	
	2-2. Terminal Board Removal ·····				Circuit Boards Location	
	2-3. J and H Board Removal ·····			6-4. F	Printed Wiring Boards and Schematic I	)iagrams····· 48
	2-4. Picture Tube Removal ·····	13		•	A Board (1/3)	55
					A Board (2/3)	
3.	SET-UP ADJUSTMENTS				A Board (3/3)	
	3-1. Preparations(1)	14			O Board······	
	Preparations(2)······			•	G Board·····	72
	3-2. Writing Model Data·····				J Board	74
-	3-3. Picture Output·····	16		•	XBoard ·····	
	3-4. Landing Adjustment ·····				H Board·····	74
	3-5. Convergence Adjustment ······			•	C Board·····	75
	3-6. Deflection Yoke Neck Rotation Adjustment ···			6-5. S	Semiconductons	81
	3-7. G2 Adjustment ·····	19				•
	3-8. White Balance Adjustment ·····		7.	EXPL	ODED VIEWS	
	3-9. Blue-Only White Balance Adjustment	20		7-1. (	Chassis·····	83
	3-10.Sub Brt Adjustment	20		7-2. F	Picture Tube ·····	84
	3-11.Focus Adjustment ·····	20				
	•		8.	ELEC	TRICAL PARTS LIST	85
					The second secon	
4.	SAFETY RELATED ADJUSTMENT	21			And the second second	

#### (CAUTION)

SHORT CIRCUIT THE ANODE OF THE PICTURE TUBE AND THE ANODE CAP TO THE METAL CHASSIS, CRT SHIELD, OR CARBON PAINTED ON THE CRT, AFTER REMOVING THE ANODE.

#### WARNING!!

AN ISOLATION TRANSFORMER SHOULD BE USED DURING ANY SERVICE TO AVOID POSSIBLE SHOCK HAZARD, BECAUSE OF LIVE CHASSIS.

THE CHASSIS OF THIS RECEIVER IS DIRECTLY CONNECTED TO THE AC POWER LINE.

# SAFETY-RELATED COMPONENT WARNING!!

COMPONENTS IDENTIFIED BY SHADING AND MARK  $\Delta$  ON THE SCHEMATIC DIAGRAMS, EXPLODED VIEWS AND IN THE PARTS LIST ARE CRITICAL TO SAFE OPERATION. REPLACE THESE COMPONENTS WITH SONY PARTS WHOSE PART NUMBERS APPEAR AS SHOWN IN THIS MANUAL OR IN SUPPLEMENTS PUBLISHED BY SONY. CIRCUIT ADJUSTMENTS THAT ARE CRITICAL TO SAFE OPERATION ARE IDENTIFIED INTHIS MANUAL. FOLLOW THESE PROCEDURES WHENEVER CRITICAL COMPONENTS ARE REPLACED OR IMPROPER OPERATION IS SUSPECTED.

# SECTION 1 GENERAL

The operating instructions mentioned here are partial abstracts from the Operating Instruction Manual. The page numbers of the Operating Instruction Manual remein as in the manual.

# **Features**

# HR (High Resolution) Trinitron picture tube

HR Trinitron tube provides a high resolution picture. Horizontal resolution is more than 600 (PVM-1354Q/1954Q) or 450 (PVM-1351Q) TV lines at the center of the picture.

# Four color systems available

The monitor can display PAL, SECAM, NTSC and NTSC<sub>4.4</sub>\* signals. The appropriate color system is selected automatically.

\* A signal of NTSC<sub>4.43</sub> is used for playing back NTSC recorded video cassettes with a video tape recorder/ player especially designed for use with this system.

### Blue only mode

In the blue only mode, an apparent monochrome display is obtained with all three cathodes driven with a blue signal. This facilitates color saturation and phase adjustments and observation of VCR noise.

# **Analog RGB/component input connectors**

Analog RGB or component (Y, R-Y and B-Y) signals from video equipment can be input through these connectors.

# Y/C input connectors

The video signal, split into the chrominance signal (C) and the luminance signal (Y), can be input through this connector, eliminating the interference between the two signals, which tends to occur in a composite video signal, assuring video quality.

# Beam current feedback circuit

The built-in beam current feedback circuit assures stable white balance.

#### **Comb filter**

When NTSC video signals are received, a comb filter activates to increase the resolution, resulting in fine picture detail without color spill or color noise.

# Automatic termination (connector with \( \infty\) mark only)

The input connector is terminated at 75 ohms inside when no cable is connected to the loop-through output connectors. When a cable is connected to an output connector, the 75-ohms termination is automatically released.

#### **Underscan mode**

The signal normally scanned outside of the screen can be monitored in the underscan mode.

#### Note

When the monitor is in the underscan mode, the dark RGB scanning lines may appear on the top edge of the screen. These are caused by an internal test signal, rather than the input signal.

# Horizontal/vertical delay mode

The horizontal and vertical sync signals can be checked simultaneously in the H/V delay mode.

# **External sync input**

When the EXT SYNC selector is in the on position, the monitor can be operated on the sync signal supplied from an external sync generator.

#### Auto/manual degaussing

Degaussing of the screen can be performed automatically when the power is turned on, or manually by pressing the DEGAUSS button.

#### **On-screen menus**

You can set color temperature, CHROMA SET UP, and other settings by using the on-screen menus.

#### Five menu languages

You can select the menu language from among the five languages on the menu.


# **EIA standard 19-inch rack mounting**

By using an MB-502B (for PVM-1354Q/1351Q) or SLR-103 (for PVM-1954Q) mounting bracket (not supplied), the monitor can be mounted in an EIA standard 19-inch rack. For details on mounting, see the instruction manual of the mounting bracket kit.

### SDI (Serial Digital Interface) kit

By using SDI kit, the monitor can display SMPTE 259M 4:2:2 serial digital signal from a digital VTR. (ex. Sony 4:2:2 VTR) SDI kit: 4:2:2 digital video board Digital audio board

# Location and function of parts and controls



#### 1 Tally lamp

Lights up when the video camera connected to this monitor is selected, indicating that the picture is being recorded.

# 2 POWER switch and indicator

Depress to turn the monitor on. The indicator will light up in green.

# **3 REMOTE indicator**

Lights up when you set USER PRESET to ON in the menu, or when you connect a supplied cable to REMOTE connector (No. 17 pin is ground). The controls on the front panel do not work when this indicator lights up.

# 4 VOLUME control

Turn this control clockwise or counterclockwise to obtain the desired volume.

# 5 CONTRAST control

Turn clockwise to make the contrast higher and counterclockwise to make it lower.

# **6** PHASE control

This control is effective only for the NTSC<sub>3.58</sub> and NTSC<sub>4.43</sub> color systems. Turn clockwise to make the skin tones greenish and counterclockwise to make them purplish.

# 7 CHROMA control

Turn clockwise to make the color intensity higher and counterclockwise to make it lower.

# 8 BRIGHT (brightness) control

Turn clockwise for more brightness and counterclockwise for less.

# 9 APERTURE control

Turn clockwise for more sharpness and counterclockwise for less.

#### Note

The APERTURE, CHROMA, PHASE control settings have no effect on the pictures of RGB signals.

# MENU (EXIT) button

Press to make the menu appear. Press to return to the previous screen in the menu.

# 11 ENTER (SELECT) button

Press to decide a selected item in the menu.

#### 12 **↑** (+)/ **↓** (~) buttons

Press to move the cursor (▶) or adjust selected value in the menu.

2

# 13 16:9 selector

Press (light on) for the signal of 16:9 picture.

# 14 H/V DELAY selector

Press (light on) to observe the horizontal and vertical sync signals at the same time.

The horizontal sync signal is displayed in the left quarter of the screen; the vertical sync signal is displayed near the center of the screen.

# 15 UNDER SCAN selector

Press (light on) for underscanning. The display size is reduced by approximately 5% so that four corners of the raster are visible.

# 16 BLUE ONLY selector **RESET button**

Press (light on) to turn off the red and green signals. A blue signal is displayed as an apparent monochrome picture on the screen. This facilitates "chroma" and "phase\*" control adjustments and observation of VCR noise.

"Phase" control adjustment is effective only for the NTSC signals.

Press to reset the setting in the menu.

# 17 DEGAUSS button

Press this button momentarily. The screen will be demagnetized. Wait for 10 minutes or more before activating this button again.

# 18 EXT SYNC (external sync) selector

Keep this button in the off position (light off) to operate the monitor on the sync signal from the displayed video signal.

Keep this button in the on position (light on) to operate the monitor on an external sync signal fed through the EXT SYNC connector on the rear panel.

# 19 LINE/RGB input selector

Select the program to be monitored. Keep this button in the off position (light off) to feed a signal through the LINE A, LINE B or LINE C connectors. Keep this button in the on position (light on) to feed a signal through the RGB connectors.

# 20 C/SDI selector

When the LINE/RGB input selector is set to LINE (light off), press this button (light on) to feed a signal through the LINE C connectors.

When the LINE/RGB input selector is set to RGB (light on), press this button (light on) to feed the SDI signal (optional board is needed).

# 21 B/COMPONENT selector

When the LINE/RGB input selector is set to LINE (light off), press this button (light on) to feed a signal through the LINE B connectors.


When the LINE/RGB input selector is set to RGB (light on), press this button (light on) to feed the component signal.

# 22 A/RGB selector

When the LINE/RGB input selector is set to LINE (light off), press this button (light on) to feed a signal through the LINE A connectors.

When the LINE/RGB input selector is set to RGB (light on), press this button (light on) to feed the RGB signal.

# Location and function of parts and controls



#### 1 AC IN socket

Connect the supplied AC power cord to this socket and to a wall outlet.

#### 2 LINE A, LINE B connectors

Two groups (A and B) of line input connectors for the composite video and audio signals and their loop-through output connectors.

To monitor the input signal fed through these connectors, keep the LINE/RGB selector in the LINE position (light off) and press the A/RGB or B/COMPONENT selector (light on) on the front panel.

#### VIDEO IN (BNC)

Connect to the video output of a video equipment, such as a VCR or a color video camera. For a loop-through connection, connect to the video output of another monitor.

#### VIDEO OUT (BNC)

Loop-through output of the VIDEO IN connector. Connect to the video input for a VCR or another monitor.

When the cable is connected to this connector, the 75-ohms termination of the input is automatically released, and the signal input to the VIDEO IN connector is output from this connector.

#### **AUDIO IN (phono jack)**

Connect to the audio output of a VCR or to a microphone via a suitable microphone amplifier. For a loop-through connection, connect to the audio output of another monitor.

# AUDIO OUT (phono jack)

Loop-through output of the AUDIO IN jack. Connect to the audio input of a VCR or another monitor.

#### 3 LINE C connectors Y/C IN (4pin mini DIN)

Connect to the Y/C separate output of a video camera, VCR or other video equipment.

#### Y/C OUT (4pin mini DIN)

Loop-through output of the Y/C IN connector. Connect to the Y/C separate input of a VCR or another monitor. When the cable is connected to this connector, the 75-ohms termination of the input is automatically released, and the signal input to the Y/C IN connector is output from this connector.

# AUDIO IN (phono jack)

Connect to the audio output of a VCR or a microphone (through a suitable microphone amplifier).

# **AUDIO OUT (phono jack)**

Loop-through output of the AUDIO IN connector. Connect to the audio input of a VCR or another monitor.

# 4 REMOTE connector (20pin)

Connect to the tally output of a control console, special-effect generator, etc. The tally lamp on the front panel will be turned on and off by the connected equipment. This connector can be used for connecting a remote controller. For the pin assignment of this connector, see "Specifications" on page 10.

4

#### 5 RGB/COMPONENT connectors

RGB signal or component signal input connectors and their loop-through output connectors. To monitor the input signal fed through these connectors, keep the LINE/RGB selector in the RGB position (light on), and press the A/RGB or B/COMPONENT selector (light on) on the front panel.

#### R/R-Y IN, G/Y IN, B/B-Y IN (BNC)

When the EXT SYNC selector on the front panel is in the off position (light off), the monitor operates on the sync signal from the G/Y channel.

# To monitor the RGB signal

Connect to the analog RGB signal outputs of a video camera.

#### To monitor the component signal

Connect to the R-Y/Y/B-Y component signal outputs of a Sony Betacam video camera.

#### R/R-Y OUT, G/Y OUT, B/B-Y OUT (BNC)

Loop-through outputs of the R/R-Y IN, G/Y IN, B/B-Y IN connectors

#### For RGB signal

Connect to the analog RGB signal inputs of a video printer or another monitor.

#### For component signal

Connect to the R-Y/Y/B-Y component signal inputs of a Betacam video recorder.

When the cables are connected to these connectors, the 75-ohms termination of the inputs is automatically released, and the signal inputs to the R/R-Y IN, G/Y IN, B/B-Y IN connectors are output from these connectors.

# AUDIO IN (phono jack)

Connect to the audio output of video equipment when the analog RGB or component signal is input.

#### AUDIO OUT (phono jack)

Loop-through outputs of the AUDIO IN connector.

# **6** EXT SYNC (external sync) connectors

To use the sync signal fed through this connector, press the EXT SYNC selector (light on).

#### IN (BNC)

When this monitor operates on an external sync signal, connect the reference signal from a sync generator to this connector.


#### OUT (BNC)

Loop-through output of the EXT SYNC IN connector. Connect to the external sync input of video equipment to be synchronized with this monitor.

When the cable is connected to this connector, the 75-ohms termination of the input is released, and the signal input to the IN connector is output from this connector.

# **Using on-screen menus**

The flow chart shows the different levels of on-screen menus that you can use to make various adjustments and settings. The boxed number is for instructions on the next page.



#### Operating through menus


There are five buttons for menu operations on the front of the monitor. To display the main menu, first press MENU. The buttons you can use appear at the bottom of the menu screen.

#### Functions of the buttons

Button	To select menu item	To adjust menu item selected
MENU	return to the previous menu	return to the previous menu
ENTER Select	decide a selected item	select an item
†	move the cursor (►) upwards	increase selected value
<b>↓</b>	move the cursor (►) downwards	decrease selected value
RESET		reset current adjustment value to the factory setting

(The above items in white type correspond to the marks in the menu.)

#### front of monitor



# 1 Main menu

Select an item and press ENTER to go to the following menu.

# 2 CHROMA SET UP menu

Set to ON to adjust the internal decoder for CHROMA and PHASE (NTSC signal only) after AUTO ADJUST (6). [OFF

# 3 COLOR TEMP/BAL menu

Select the color temperature from among 6500K, 9300K and USER. USER is set to 6500K in the factory setting. You can adjust or change the color temperature in USER mode (a measuring instrument is needed). [6500K]

# 4 USER CONFIG 1 menu

Select an item to adjust. To go to the USER CONFIG 2 menu, select NEXT PAGE.

# 5 USER CONFIG 2 menu

Select an item to adjust. To go to the USER CONFIG 1 menu select PREVIOUS PAGE.

#### 6 AUTO ADJUST screen

Select the color bar signal (full, SMPTE, EIA) and press ENTER to start auto adjusting for CHROMA SET UP (NTSC signal only).

# 7 ADJUST GAIN screen

Adjust GAIN in USER mode.

# 8 ADJUST BIAS screen

Adjust BIAS in USER mode.

Select the color temperature range in USER mode.

[5000K-10000K]

#### 10 COLOR SYSTEM DISPLAY menu

Select the color system display mode. In AUTO, the kind of color system being used appears on the screen each time you change the signal input. [AUTO]

# 11 358 TRAP FILTER menu

Color spill or color noise may be eliminated if you select ON (NTSC signal only). [OFF]

# 12 SUB CONTROL screen

You can finely adjust the controls on the front panel. CONTRAST, BRIGHT, CHROMA and PHASE control has a click at the center of its adjustment range. You can adjust the setting of the click position with this feature.

#### 13 USER PRESET menu

You can preset each control to a desired level and set it. If you set USER PRESET to ON, the REMOTE indicator lights up and the controls on the front panel do not work. The monitor operates with the internal memory settings. For adjustment, select PRESET ADJUST. [OFF]

# 14 PRESET ADJUST screen

Adjust CONTRAST, BRIGHT, CHROMA, PHASE, VOLUME, APERTURE in USER PRESET.

# 15 V HOLD screen

Adjust the vertical hold if the picture rolls vertically. When you cannot read the display, select the input that is not connected.

# 16 COMPONENT LEVEL menu

Select the component level from among three modes. N10/SMPTE for 100/0/100/0 signal BETA 7.5 for 100/7.5/75/7.5 signal

BETA 0 for 10

for 100/0/75/0 signal

[N10/SMPTE]

#### 17 NTSC SETUP LEVEL menu

Select the NTSC setup level from two modes. The 7.5 setup level is mainly used in north America. The 0 setup level is mainly used in Japan. [0]

# 18 ACC menu

Set ACC (Auto Color Control) circuit on or off. When the fine adjustment is needed, set ACC to OFF. Normally set it to ON. [ON]

#### 19 LANGUAGE menu

You can select the menu language from among the five languages (English, German, French, Italian, Spanish) on the menu.


[ENGLISH]

([] indicates the factory setting position.)


# **Power sources**

# House current

Connect the AC power cord (supplied) to the AC IN socket and to a wall outlet.



# To connect an AC power cord securely with an AC plug holder




# To remove the AC power cord

Pull out AC plug holder by squeezing the left and right sides.


# SECTION 2 DISASSEMBLY

# 2-1. TOP COVER AND REAR COVER REMOVAL




# 2-2. TERMINAL BOARD REMOVAL

# 2-2. TERMINAL BOARD REMOVAL




# 2-4. PICTURE TUBE REMOVAL



# REMOVAL OF ANODE-CAP


NOTE: Short circuit the anode of the picture tube and the anode cap to the metal chassis, CRT shield or carbon paint on the CRT, after removing the anode.

# REMOVING PROCEDURES



direction indicated by the arrow (a).


① Turn up one side of the rubber cap in the ② Using a thumb pull up the rubber cap firmly in the direction indicated by the arrow (b).




3 When one side of the rubber cap is separated from the anode button, the anode-cap can be removed by turning up the rubber cap and pulling up it in the direction of the arrow ©.

# · HOW TO HANDLE AN ANODE-CAP

- Don't hurt the surface of anode-caps with sharp shaped material!
- Don't press the rubber hardly not to hurt inside of anode-caps! A material fitting called as shatter-hook terminal is built in the rubber.
- Don't turn the foot of rubber over hardly! The shatter-hook terminal will stick out or hurt the rubber.





# SECTION 3 SET-UP ADJUSTMENTS

# 3-1. PREPARATIONS (1)

# Service Mode

This set is provided with a switch for service on the front panel that can be used to make various adjustments. The operation method of this switch is explained in detail below.

# 1. ENTERING THE SERVICE MODE

Simultaneously press the [ENTER] key and the [DEGAUSS] key shown on the display of the menu.

#### 2. SERVICE MODE DISPLAY

(1)	(5)	(4)	(3)	(6)	
(2)		. 88			

Range of Sevice Mode Display

- (1) The service items are largely classified into 16 types displayed by titles.
- (2) The names of the service items or READ / WRITE guidance, etc., are displayed. The names are dispalyed to the left and the guidance to the right.
- (3) This is the serial number for each of the service items. 1-120.
- (4) This is the adjustment data for the servise items that are now stored in the RAM. Adjustments can be made by changing these values, but as long as nothing is written to the ROM the adjustment values will be erased by turning off the power or by reading, so please be careful.
- (5) When the adjustment data than is now displayed is identical with the data in the ROM, the cursor ( > ) is displayed.
- (6) The present status is displayed.
  - [\*]: Writing to the ROM. Make sure not to turn off the power while this display is on.
  - [?]: ROM reading error. In this case, an image is output with the standard adjustment data that the microcomputer itself possesses.
  - [¿]: Problem in the I2C bus.

# 3. FINISHING THE SERVICE MODE

Simultaneously press the [ENTER] key and the [DEGAUSS] key shown on the display of the menu.

# 4. EASY ON / OFF OF THE SERVICE MODE

If once entering the service mode after having turned on the power, easy ON / OFF is possible by once more pressing the A, B or C switch on the front panel (the LED lights) as long as the power is not turned off or as long as the service mode is not finished.

# 5. CHANGE OF POSITION OF THE SERVICE MODE DISPLAY

If the switch is continuously pressed when turning on in the above easy mode, the display position moves in the V direction. This method is used when the display is outside of the effective screen area.

#### 6. CHANGE OF SERVICE ITEMS

The items are returned with the [MENU] key and forwarded with the [ENTER] key. When a key is continuously pressed, the operation will be repeated.

#### 7. CHANGE OF SERVICE DATA

The service data is made larger with the  $[\uparrow]$  key and smaller with the  $[\downarrow]$  key. When continuously pressing the keys, the operation will be repeated.

### 8. READING OF SERVICE DATA

When reading data from the ROM to the RAM, press the [B/D] key once and check than the READ display is shown in the guidance, and then press the [B/O] key once again. The adjustment data that is written will return to its previous state, so please be careful.

# 9. WRITING OF SERVICE DATA

When writing data from the RAM to the ROM, press the [DEGAUSS] key once and check that the WRITE display is shown in the guidance, and then press the [DEGAUSS] key once again. Not only the displayed data will be written, but all data, so please be careful.

#### 10. CARRYING OUT FACTORY RESETTING

In case the adjustment data has been destroyed for some reason, and you keep pressing the [B / O] key at the beginning of the above reading, the READ guidance will change to FACTRY RESET guidance in approximately 3 seconds so that the factory resetting can be carried out. By once again pressing the [B / O] key after this, resetting will be carried out ([\*] will be displayed as status) and factory resetting will be executed. However, in case the data available at the time of shipment from the factory has been destroyed, or if the ROM has been replaced, etc., or if factory setting mentioned later on has been carried out, factory resetting is executed.

### 11. CARRYING OUT FACTORY SETTING

Make sure to make possible the above factory resetting by making a copy of the adjustment data when replacing the ROM. If you keep pressing the [DEGAUSS] key at the beginning of the above writing, the WRITE guidance will change into FACTORY RESET guidance after approximately 3 seconds. By once again pressing the [DEGAUSS] key after this, setting will be carried out ([\*]will be dispalyed as status) and the data will be copied. By carrying out this operation, the selection items of the menu and the adjustment values will be reset to the standard conditions, so please be careful. If this operation is carried out once, it cannot be carried out again, but the FACTORY SET FLAG (No. 120) in the service mode can be set to 1.

# **ROM INITIAL WRITING VALUE OF SERVICE DATA**

NO.		5 . x (1-120)	N/A X	1 411	20"	NIC	7	PRIVICE ITEM	D. C. Line	. 1 :415	20"
		SERVICE ITEM	MAX		20"	NO.		SERVICE ITEM	MAX		
1	NOR 50 DEF	H FREQUENCY	255		107	61	C/T1??00K	BIAS (RED)	1023		
2		VIDEO PHASE		141		62		BIAS (GREEN)	1023		
3		V SIZE		165		63		BIAS (BLUE)	1023		
• 4		V CENTER		122		64		GAIN (RED)	1023		
5	NOR 60 DEF	H FREQUENCY	255	90	112	65		GAIN (GREEN)	1023		
6		VIDEO PHASE	255			66	1	GAIN (BLUE)	1023	536	536
. 7		V SIZE	255	157	161	67		B/O(RED)	255	120	120
8		V CENTER	255	128	111	- 68		B/O(GREEN)	255	125	125
9	NOR DEF	H SIZE	255	111	102	69	C/T2 ??00K	3200K SW	1	0	-0
10		PIN PHASE	255	108		70		BIAS (RED)	1023	263	263
11		PIN AMP		112		71		BIAS (GREEN)	1023		
12		U/L PIN		126		72		BIAS (BLUE)	1023		
13		SEXY		128		73		GAIN (RED)	1023		
14		V LINEARITY		132	82	74		GAIN (GREEN)	1023		
15		V BOW	* 63	32	32	75		GAIN (BLUE)	1023		
	14 T g 24 T S	L									
16		V ANGLE	* 63	32	32	76		B/O(RED)	255	86	<u> </u>
17	U/SDEF	V SIZE (50)	255			77		B/O(GREEN)	1		105
18		V SIZE (60)		116	~~~~	78	W/B	SUB CON (4:3, NORMAL)			210
19	- - 1 - 13	H SIZE	255	115	89	79		SUB CON (4:3, H/V DELAY)			122
20		PIN PHASE	255		112	80	a a	SUB CON (16:9, NORMAL)		165	165
21		PIN AMP	255	74	96	81		SUB CON (16: 9, H/V DELAY)	255	93	93
22	16:9 NOR DEF	V SIZE (50)	255	81	89	82		SUB BRIGHT	255	71	71
23		V SIZE (60)	255	85	100	83		USER B / O (RED)	255	120	120
24		PIN PHASÉ	255	113		84		USER B / O (GREEN)		125	125
25		PIN AMP	255	64	68	85	OTHER	OSD POSITION		129	129
26		U/L PIN	255	132		86	O 11121C	V HOLD	255		
27	16:9 U/S DEF	V SIZE (50)	255	41	59	87		H BLANKING	255	68	68
28	10.9 U/3 DEI	V SIZE (60)	255	35	55	88		V BLANKING (50)	255	63	63
29						89				37	
		PIN PHASE		124				16:9 BLANKING START(50)	255		37
30		PIN AMP	255	47	55	90		16:9 BLANKING END(50)			163
31	COMPONENT		255	140		91		V BLANKING (60)	255		117
32		SUB CHROMA (NORMAL)	255	_		92		16:9 BLANKING START(60)	255	40	40
33		SUB CHROMA (SMPTE)	255	168		93		16:9 BLANKING END(60)			215
34	Material .	R-Y LEVEL		155		94		H DELAY			165
	NTSC	BURST GATE PULSE WIDTH	255	22	22	95		V DELAY			101
36		CRYSTAL	255	51	51	96		HP POSITION	255	130	130
37		PHASE (NORMAL)		103		97		HP WIDTH (NORMAL)	255	90	
38	31 Acres 1444	PHASE (ACC OFF)	255	112	112	98	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	HP WIDTH (H / V DELAY)	255	35	35
39		B-Y PHASE		141			SYSTEM	SDI AUDIO	7	5	5
40		CHROMA (NORMAL)		123				358TRAP FILTER	1	0	
41	î.	CHROMA (ACC OFF)	255			101		ACC	1	0	<del> </del>
42		R-Y LEVEL	255	87		102		CAPTION VISION	7	0	
	NTSC 443	CRYSTAL	255			102	A	COMPONENT LEVEL	3	2	<del> </del> -
43	11100 440	PHASE (NORMAL)	255			103		NTSC SETUP LEVEL		0	-
45	<del></del>								1	0	
		PHASE (ACC OFF)	255			105	 	CHROMA SET UP	1		
46		B-Y PHASE		140				COLOR SYSTEM DISPLAY	3	0	
47		CHROMA (NORMAL)		117				COLOR TEMPERATURE	3	0	1
48		CHROMA (ACC OFF)	255			108		USER PRESET	1	0	1
49		R-Y LEVEL		100				LANGUAGE	7	0	
	PAL	PHASE (NORMAL)	255			110		RGB SYNC	1	0	
51		PHASE (ACC OFF)		72		111		OPTION BOARD	7	0	<u> </u>
. 52		B-Y PHASE	255	105	105	112		AGING MODE	1	0	0
53		CHROMA (NORMAL)	255	141	141	113		PAL-M	1	0	0
54		CHROMA (ACC OFF)	255			114		MODEL	15	* *	* *
55		R-Y LEVEL		120			-	COLOR TEMP DISP 1	127	65	
	SECAM	CHROMA		120	-			COLOR TEMP DISP 2	127	93	93
57	J.D.O. IIVI	R-Y LEVEL		229	_		<u> </u>	REMOTE ADDRESS	127	0	<del></del>
58				116						0	
58 59		COLOR BALANCE (R-Y)						RESERVED 1	1		
	I	COLOR BALANCE (B-Y)	255	98	98	119	1	RESERVED 2	1	0	ł
	C/T1 ??00K	3200K SW	<del>                                     </del>	0		120		FACTORY SET FLAG		0	0

<sup>\*</sup> Among the data 8 bits (MAX255) only the upper 6 bits can be changed. \* \* PVM-1954Q, PVM-1350/1351Q/1354Q.

# PREPARATIONS (2)

\* When composite video or component signals are supplied, they must be supplied as below.

Signal		Signal Contents	Standard Level P-W
		100% WHITE	0.714V
		75% WHITE	0.536V
COMPOSITE	358NT 443NT	BURST (GREEN) (This item only P-P)	286mV (632mV)
VIDEO		100% WHITE	0.7V
		75% WHITE	0.525V
	PAL SECAM	PAL BURST (GREEN) (This item only P-P)	300mV (632mV)
		100% WHITE Y	0.7V
		75% WHITE Y	0.525V
COMPONENT	BETA 0	75% COLOR B-Y, R-Y (This item only P-P)	0.7V
COMPONENT		100% WHITE Y	0.7V
		75% WHITE Y	0.525V
	SMPTE	75% COLOR B-Y, R-Y (This item only P-P)	0,525V

\* In this document, terms inside boxes \_\_\_\_\_ are names of service mode adjustments.

Example 60H-FREQ

- \* After making adjustments in service mode, write the adjustment data before cutting off the power. If you cut off the power without writing, the results of your adjustments are all lost.
- \* Standard inspection conditions

Unless specifically specified otherwise in this document, the following conditions are used for adjustments and inspections.

APERTURE

MIN

BRIGHT

50% (Center click)

CHROMA

50% (Center click)

PHASE

50% (Center click)

CONTRAST

80% (Center click)

VOLUME

50%

# 3-2. WRITING MODEL DATA

1. In service mode, write in the following model data at No. 114 MODEL.

PVM-2054OM

0

2. In service mode, write in the following data at No. 115 COLOR TEMP DISP 1.

PVM-2054QM

65

3. In service mode, write in the following data at No. 116 COLOR TEMP DISP 2.

PVM-2054OM

93


#### 3-3. PICTURE OUTPUT


- 1. Set the AC input voltage.
  - (1) Input the video and audio signals to the corresponding terminals on the connector panel.
  - (2) Set the sliduck AC voltage as shown on the right. (\*1-1)


Model	Voltage			
PVM-2054QM	AC220 ± 3V (Distortion rate : 3% or less)			

# 3-4. LANDING ADJUSTMENT

- 1. Preparations
- 1) To reduce the influence of geomagnetism, face the set's CRT screen east or west.
- 2) Loosen the deflection yoke fixture and lower the deflection yoke to the rear.
- 3) Switch on the Power switch and degauss with the degausser.
- 4) Adjust the deflection yoke tilt.
- 2. Adjustment
- 1) CONT ····· MAX
  - BRT..... Position providing good vision
- 2) The rough adjustments of the white balance, G2, and convergence must be completed already.
- 3) Set green-only.
- 4) Adjust the purity knob so that the green comes to the center of the screen. Make the red and blue about even. Fig. 1
- 5) Switch to blue only, red only, and green only and verify each. Fig. 1, 2, and 3
- 6) Bring the deflection yoke gradually forward and adjust the deflection yoke so that the R and B at both sides of the screen become green. Fig. 2→3
- 7) If the deflection yoke comes too far forward, you will see the pattern shown in Figure 4. If that happens, lower the deflection yoke to the rear. Fig.  $4 \rightarrow 3$
- 8) Switch the single color switch to B and verify the single color. Fig. 6
- 9) Switch the single color switch to R and verify the single color. Fig. 9
- 10) When one of the colors does not become the single color correctly, check by repeating Items 7 and 8 based on the single color not coming into adjustment.
  - If you can not obtain landing in the corners, paste on magnets.
- 11) Switch to an all-white signal and check the uniformity.
- (12) When the deflection yoke position is determined, fasten it with the fixture.











Fig. 9

Fig. 8

# 3-5. CONVERGENCE ADJUSTMENT

- Input a dot pattern signal.
   CONT ····· Position providing good vision BRT····· MIN
- 2. Align the horizontal R, G, and B dots at the center of the screen with the H-STAT VR. (\*1)
  - \*1: If the H-CENTER adjustment was after the H-STAT adjustment, re-adjust the H-STAT.

    (The H-CENT VR changes the H-STAT too.)
- 3. Align the R, G, and B at the center of the screen with the V-STAT magnets. (\*2)
  - \*2: After the V-STAT adjustment, paint on the knobs to lock them.



X A B B Y Bad example


V-STAT magnet knobs While keeping the angles for A and B equal (I=I'), align the

vertical convergence.


If the A and B knobs are not symmetrical (I#I'), this has bad effects. The focus may deteriorate and beam striking may occur.

4. For HMC, use the 6-pole magnet to adjust the R and B dots to be symmetrical left and right about the G dot. (\*1)

\*1:




The HMC adjustment changes the opening of the 6-pole magnet.




Adjust the 6-pole magnet so that A=A'. You must maintain the relationship  $I \neq I'$  while moving the magnet.

# <sup>2</sup>VM-2054QM

5. For VMC, use the 6-pole magnet to adjust the R and B dots to be symmetrical above and below the G dot. (\*2)



- 6. Adjust by repeating the adjustments in Items 2 through 5. (\*3)
  \*3: The above adjustment may affect the landing, so after this adjustment, check the landing again.
- 7. After the adjustment is complete, paint on the knobs to lock them.




# 3-6. DEFLECTION YOKE NECK ROTATION ADJUSTMENT


If there is misconvergence at both sides on the X or Y axis of the screen, turn the neck of the deflection yoke in the direction of the arrow to reduce the misconvergence for the entire CRT screen to within the tolerance.

1. Reverse misconvergence pattern


Turn the deflection yoke neck down.




Positive misconvergence pattern Turn the deflection yoke neck up.




Pattern when deflection yoke too far to the left






Pattern when deflection yoke too far to the right

2. Insert the three wedges in the deflection yoke and CRT funnel surface to fasten the deflection yoke.




Wedge positions


3. The pattern below can not be corrected by turning the neck.



\* Gun rotation
The beam is twisted at both sides on the X axis and Y axis.




\* HCR large (small)
At both sides of the screen,
the G raster horizontal
component is wider
(narrower) than those of the
R and B rasters.




\* VCR large (small)
At both sides of the screen,
the G raster vertical
component is wider
(narrower) than those of
the R and B rasters.


# 3-7. G2 ADJUSTMENT

- 1. Input a 525 monoscope signal.
- 2. Connect the oscilloscope to A board TP403.
- 3. Of the three reference pulses, measure the lowest one.
- 4. With the Screen VR, adjust so that left end of the waveform is :  $\underline{1.35~V}~\pm~0.05V$





Since the waveform is triangular as shown on the left, adjust the left end to be 1.35 V.



# 3-8. WHITE BALANCE ADJUSTMENT

For measuring equipment, use a color analyzer. (for example Minolta, etc.)

- Input a 525 monoscope signal. (Input from Line A or Line B, with no burst.)
- 2. Set:
  CONT ..... 0%
  BRT..... 50%
- 3. On a 20-tone gray scale, adjust service mode SUB BRIGHT so that
  0 and 5 IRE → cut off
  10 IRE → slight glow
- 4. Input 525 all-white (no burst, composite signal).
- 5. Set CONT to 80%.
- 6. Adjust the all-white signal luminance so that the screen luminance is 3 NIT.
- 7. Press MENU and select COL TEMP/BAL.
- 8. Select 6500 K.
- 9. Put the unit into service mode. (\*1)
   \*1 : Set 3200 K SW to 0 for both 9300K and 6500K.
- 10. Adjust to the standard values with C/T1 6500K BIAS (G must be fixed at "512".) (\*2)

  \*2: Adjust the cut-off to be 3 NIT.
- 11. Switch the all-white signal luminance to 100 IRE.
- 12. Adjust to the standard values with C/T1 6500K GAIN (G must be fixed at "700".)
- 13. Repeat Items 10, 11 and 12 until the adjustment is complete, then write the adjustment data.
- 14. Press MENU and select COL TEMP/BAL.
- 15. Select 9300 K.
- 16. In the same manner as in Items 10, 11, 12 and 13 make the C/T2 9300K BIAS and C/T2 9300K GAIN adjustments.

# 3-9. BLUE-ONLY WHITE-BALANCE ADJUSTMENT

- 1. Switch the user control SW Blue Only On (to set blue-only mode).
- Input an all-white signal (no burst composite signal). (\*1)
   The luminance of the all-white signal must be 100 IRE.
   CONT ····· 80%

CON1 ..... 50%

BRT..... 50%


- 3. Select COL TEMP/BAL.
- 4. Select 6500 K.
- 5. Adjust to the standard values with C/T1 6500K B/O (RED) and C/T1 6500K B/O (GREEN).
- 6. Select COL TEMP/BAL.
- 7. Select 9300 K.
- 8. Adjust to the standard values with C/T1 9300K B/O (RED) and C/T1 9300K B/O (GREEN).
- Check that the white balance is obtained when the all-white signal luminance is adjusted and the screen luminance is 8 NIT.

#### **3-10 SUB BRT ADJUSTMENT**

- 1. Input a 525 monoscope signal.
- 2. CONT ······ MIN BRT······· CENTER (50%)
- 3. Put the unit into service mode and select SUB BRIGHT.
- 4. Adjust SUB BRIGHT so that 10 IRE gives a slight glow and 10 IRE gives cut off.

# 3-11. FOCUS ADJUSTMENT

- 1. Input a 525 monoscope signal.
- 2. Adjust the focus to optimize the focus on the characters "30" at the center of the screen.
- 3. Switch to an all-white signal and check the uniformity.



# **SECTION 4** SAFETY RELATED ADJUSTMENT

The following adjustments should always be performed when replacing the following components (marked with M , I on the schematic diagram).

+B detection.... Tertiary coil detection...... 

R1536

Part replosed( ) Hold Down Circuit...... A board IC500, D533, R1537, C592, R1536, C523, R1560, R551, C549, R518, C506, C512,

IC507

D501, R506, R519, T501,

Beam Current Protector

Circuit...... A board R508, R515, R516, R517,

C513, Q500, Q511

B+ Regulator Circuit...... 🗖 A board C603, IC602, ☐ G board R1535

# B+ MAX VOLTAGE CONFIRMATION (RV601)

Standard: 115.0~117.0 VDC

Check Condition: Input voltage: 130~132 VAC

Note: Use NF Power Supply or make sure that

distortion factor is 3% or less.

# HOLD-DOWN CIRCUIT VOLTAGE CONFIRMATION

Check Condition: Input voltage: 130~132 VAC

Input signal: monoscope signal Controls : BRT & PIC ⇒ initial reset B+ voltage: Less than 117.0 V

(1) Hold down circuit (+B Actuation)

a) When IABL =  $1000 \pm 50 \mu$  A, raster goes out at less than 131.0 V of +B voltage (TP502) by adjusting  $\triangle$  R690 and RV601.

Input signal : ALL white △ R690 : 470-5.6k 1/4 W RN

b) When IABL = 120  $\pm$  20  $\mu$  A, raster goes out at less than 134V of +B voltage (TP502) by adjusting △ R690 and RV601.

Input signal: Dot


(2) Hold down circuit (Tertiary coil detection voltage) Confirmatory item: 110.0 V voltage should be applied to the (11) pin of IC500.


a) When IABL =  $1000 \pm 50 \mu$  A, raster goes out when applying less than DC 148.0 V voltage to the (11) pin (TP503) of IC500 from outside.


Input signal: ALL white

b) When IABL = 120  $\pm$  20  $\mu$  A, raster goes out when applying less than DC 148.5 V voltage to the (11) pin (TP503) of IC500 from outside.

Input signal: Dot








(CONDUCTOR SIDE)

# SECTION 5 CIRCUIT ADJUSTMENTS

# 5-1. A BOARD ADJUSTMENT

A BOARD - COMPONENT SIDE -



D516			
		Е В П_П	
		Q363	
		,	

# . I. Preparations

\* When composite video or component signals are supplied from connector CN301, they must be supplied taking into account the effect of the Q board as indicated on the right.

The levels of the signals supplied must be within  $\pm 2\%$  of the standard on the right.

Signal		Signal Contents	Standard Level (Pedestal-White)	Reduction Ratio	Connector Feed Level (Pedestal-White)
		100% WHITE	0.714V	93%	0.664V
	358NT	75% WHITE	0.536V	93%	0.498V
COMPOSITE VIDEO	443NT	BURST (GREEN) (This item only P-P)	286mV (632mV)	94% (94%)	269mV (594mV)
(75% COLOR BAR)		100% WHITE	0.7V	94%	0.651V
	PAL	75% WHITE	0.525V	94%	0.488V
	SECAM	PAL BURST (GREEN) (This item only P-P)	300mV (664mV)	94% (94%)	282mV (624mV)
	BETA0	100% WHITE Y	0.7V	94.8%	0.664V
		75% WHITE Y	0.525V	94.8%	0.498V
COMPONENT		75% COLOR B-Y, R-Y (This item only P-P)	0.7V	94.8%	0.664V
(75% COLOR BAR)		100% WHITE Y	0.7V	94.8%	0.664V
		75% WHITE Y	0.525V	94.8%	0.498V
	SMPTE	75% COLOR B-Y, R-Y (This item only P-P)	0.525V	94.8%	0.498V

\* The function or input can be selected by writing the corresponding data from the table below into microcomputer (IC101) RAM address 0006h.

BIT	FUNCTION	DATA
0-3	LINE A/RGB	1
	LINE B/COMPONENT	2
	LINE C/SDI	3
	LINE/RGB	4
	EXT SYNC	5
	DEGAUSS	6
	BLUE ONLY	7
	UNDER SCAN	8
	H/V DELAY	9
	16:9	10
4-7	MENU	1
	SELECT	2
	UP	3
	DOWN	4

*	In this	document,	terms inside	boxes	are	names	o
	service	mode adjus					

Example 60H-FREQ

\* CONT 80% is the center click position for the user control.

# II. Deflection System Adjustment


# 1. ADJUSTING THE HORIZONTAL OSCILLATION FREQUENCY

- 1. Input a 525 monoscope signal.
- 2. Set:

CONT ..... 80%

BRT ..... 50%

- 3. Put the unit into service mode.
- Drop A board IC507 Pin 1 to ground with a 100 μ/16V electrolytic capacitor. (Ground must use CN505 Pin 3.)
   Or plug the H-FREQ tool into CN505.
- 5. Adjust 60H-FREQ so that the diagonal lines on the screen become vertical lines. (Fig. 1)
- 6. Input a 625 monoscope signal.
- 7. Adjust 50H-FREQ so that the diagonal lines on the screen become vertical lines. (Fig. 1)






Fig. 1

# 2-1. H-BLK Adjustment

- 1. Input a 525 monoscope signal.
- 2. Set:

CONT ..... 80%

BRT.....50%

- 3. Put the unit into service mode.
- 4. Observe the anode of D516 or TP300 with the oscilloscope and adjust H-BLK to obtain the waveform in Fig. 2.




Fig. 2


#### 3-1. PICTURE PHASE Adjustment

- 1. Input a 525 monoscope signal.
- 2. Put the unit into under scan mode.
- 3. Set:

CONT ····· Min.

BRT.....Max.

- 4. Put the unit into service mode.
- 5. Use U/S H SIZE to adjust the size of the monoscope white frame to be about 1 cm to the inside of the limits of the effective screen.
- 6. Turn RV501 (H-CENT) and adjust so that B=B'.
- 7. Adjust 60 VIDEO PHASE so that the signal region comes to the center (A=A') of the deflection region. (Fig. 3)



- 8. Input a 625 monoscope signal.
- 9. Adjust 50 VIDEO PHASE in the same manner.

# 4-1. V•BLK Adjustment

- 1. Input a 525 monoscope signal.
- 2. Put the unit into under scan mode.
- 3. Set:

CONT ..... Min.

BRT.....Max.

- 4. Put the unit into service mode.
- 5. Adjust V BLK (60) so that before 0.5H of the white frame on the top of the monoscope is barely unblocked.
- End under scan mode and put the unit into Normal 16:9 mode
- 7. Adjust 16: 9 BLK START (60) and 16: 9 BLK END (60) so that the vertical direction frame count is 11.75 for the light emitting section of the screen and at the same time the top and bottom block amounts are the same.

**Note**: This must be done before the 16: 9 V-SIZE adjustment.

- 8. Input a 625 monoscope signal.
- 9. Adjust V BLK (50) in the same manner as in 5 above.
- 10. Adjust 16:9 BLK START (50) and 16:9 BLK END (50) in the same manner as in 7 and 8 above so that the vertical direction frame count is 11.2 for the light emitting section of the screen and at the same time the top and bottom block amounts are the same.

# PVM-2054QM

# 4-2. V-BLK Adjustment

- 1. Put the unit into service mode.
- 2. Input an adjustment value of 116 for 60-V BLK.
- 3. Input an adjustment value of 66 for 50-V BLK

# 5. VERTICAL DEFLECTION SECTION Adjustment

Normal V. Size Standards

		525	625
4:3		$11.75 \pm 0.2 \text{ frames}$	$11.2 \pm 0.2$ frames
16:9	14"	154 ± 2mm	4
	20 ″	217 ± 3mm	4

- 1. Input a 525 monoscope signal.
- 2. Set:

CONT ..... 80%

BRT.....50%

- 3. Put the unit into service mode.
- 4. Adjust the size to 12 frames with NOR 60 V SIZE

Adjust the vertical linearity with VLIN.

Adjust the vertical centering with 60 V CENT.

Note: The V.CENT adjustment must be re-evaluated after the V.LIN adjustment.

> Adjust the size to the standard value with NOR 60 V SIZE

- 5. Put the unit into 16:9 mode.
- 6. Adjust in the same manner with 16: 9 NOR V SIZE (60)
- 7. Put the unit into normal scan mode.
- 8. Input a 625 monoscope signal.
- 9. Roughly adjust NOR 50V SIZE so that the size is 11 frames. Adjust the vertical centering with 50 V CENT.

Note: The V.CENT adjustment must be re-evaluated after the V.LIN adjustment.

> Adjust the size to the standard value with NOR 50 V SIZE .

- 10. Put the unit into 16:9 mode.
- 11. Adjust in the same manner with 16:9 NOR V SIZE (50)

# 6. HORIZONTAL DEFLECTION SECTION ADJUSTMENT **NORMAL SCAN Adjustment**

- 1. Input a 525 monoscope signal.
- 2. Set:

CONT ..... 80%

BRT.....50%

- 3. Put the unit into service mode.
- 4. Roughly adjust NOR H SIZE so that the size is 15.75
- Adjust the horizontal deflection section with

NOR PIN AMP, NOR PIN PHASE, NOR U/L PIN,

SEXY, V BOW and V ANGLE.

(While adjusting the pincushion distortion and bow distortion with V-ANGL and BOW, adjust so that the horizontal and vertical of the screen are straight lines.)


- 6. Put the unit into 16:9 mode.
- 7. Adjust with 16: 9 NOR PIN AMP

16: 9 NOR PIN PHASE, and 16: 9 NOR U/L PIN in the

same manner as in Item 5.

Normal H.Size Standards

	525	625
4:3	$15.75 \pm 0.2 \text{ frames}$	$15.0 \pm 0.2$ frames
16:9	$15.75 \pm 0.2 \text{ frames}$	15.0 ± 0.2 frames



# 7. HORIZONTAL DEFLECTION SECTION Adjustment (UNDER SCAN adjustment)

Standard value

	525	625
U/S H-SIZE V-SIZE	$364 \pm 3$ mm $272 \pm 3$ mm	<b>—</b>
16:9 U/S V-SIZE	205 ± 3mm	<

- 1. Input a 525 monoscope signal.
- 2. Set:

CONT ..... 80%

BRT ..... 50%

- 3. Put the unit into U/S mode.
- 4. Put the unit into service mode.
- 5. Adjust U/S V SIZE (60) so that the under-scan vertical size meets the standard.
- 6. Adjust U/S H SIZE so that the under-scan horizontal size meets the standard.
- 7. Adjust U/S PIN AMP and U/S PIN PHASE. (The tracking must be adjusted for 5, 6 and 7.)
- 8. After adjustment, the four corners of the monoscope white frame must be within the effective screen.
- 9. Put the unit into 16:9 mode.
- 10. Adjust with 16:9 U/S V SIZE (60), 16:9 U/S PIN AMP 16:9 U/S PIN PHASE in the same manner as in Item 5, 7.
- 11. End 16: 9 mode.
- 12. Input a 625 monoscope signal.
- 13. Adjust U/S V SIZE (50) in the same manner as Item 5.
- 14. Put the unit into 16:9 mode.
- 15. Adjust 16: 9 U/S V SIZE (50) in the same manner as Item 10.

Note: If there is no leeway in the adjustment timing for 5 vertical deflection section adjustment and 6, 7 horizontal deflection section adjustment, after verifying that each section can be adjusted to operate normally, it is also possible to input the standard adjustment values.

# 8. H/V DELAY Adjustment

- 1. H-DELAY adjustment
  - 1) Input a 525 monoscope signal.
  - 2) Set:

CONT ..... 80%

BRT.....50%

- 3) Put the unit into H/V DELAY mode.
- 4) Put the unit into service mode.
- 5) Connect the oscilloscope probe to IC503 Pin 7, then adjust H DELAY so that the waveform is as in Fig. 5.


- 2. V-DELAY Adjustment
  - 1) Input a 525 monoscope signal.
  - 2) Set:

CONT ..... 80%

BRT.....50%

- 3) Put the unit into H/V DELAY mode.
- 4) Put the unit into service mode.
- 5) Connect the oscilloscope probe to IC502 Pin 7, then adjust V DELAY so that the waveform is as in Fig. 6.
- 3. Picture verification

Verify that the picture is as in Fig. 7.







Fig. 7

# PVM-2054QM

# 9. OSD POSITION Adjustment

- 1. Input a 525 color bar signal.
- Connect the oscilloscope probes to TP300 (H-BLK) and IC104 Pin 14.
- 3. Adjust OSD POSITION so that the gap between the rising edge of the H-BLK waveform and the right edge character (the right edge of the "  $\square$ " for service mode OSD POSITION) is: 57  $\mu$ S  $\pm$  0.2  $\mu$ S



#### 10. WRITING THE ADJUSTMENT

Write the adjustment results into memory.
 Note: If you cut off the power before writing, the results of your adjustments are all lost.

# III. SIGNAL SYSTEM ADJUSTMENT

#### 1. NORM AL AND H/V DL SUB CON ADJUSTMENT

1. Input a vertical white line signal.


Note: Use a vertical white line signal (525 no burst, H width  $3\mu$ S, 100IRE).


2. Set:

CONT..... 80% BRT.....50%

- 3. Connect the oscilloscope probe to A board CN401 Pin 3.
- 4. Put the unit into service mode.
- 5. Provisionally input an adjustment value of 69 for SUB BRT.
- 6. Adjust the pedestal or the distance between the sync tip and white with SUB CON (4: 3 NOR), SUB CON (4: 3 H/V DELAY), SUB CON (16: 9 NOR), and SUB CON (16: 9 H/V DELAY).


SUB CON (4:3 NOR). SUB CON (16:9 NOR) (Fig. 9) SUB CON (4:3 H/V DELAY) SUB CON (16:9 H/V DELAY) (Fig. 10).






# 2-1. SUB PHASE Adjustment

- 1. Input a component color bar (R-Y) and EXT SYNC (Beta 0 level signal).
- 2. Put the unit into Ext Sync mode.
- 3. Connect the oscilloscope probe to IC404 Pin 30 or TP402.
- 4. Put the unit into service mode.
- 5. Adjust SUB PHASE to minimize the output waveform (15 mVp-p max.) (Fig. 11)



#### 3-1. SUB CHROMA Adjustment

- 1. Input a component color bar (R-Y, Y, B-Y). (Beta 0 level signal).
- 2. From the menu, make the Component Level Beta 0.
- 3. Connect the oscilloscope probe to IC404 Pin 30 or TP402.
- 4. Put the unit into service mode.
- 5. Using SUB CHROMA NORMAL, adjust so that the tops of the waveform line up as in the diagram below. (Fig. 12)




Adjust so that the levels of the first peak and the fourth peak are the same.

Fig. 12

# 4. R-Y LEVEL ADJUSTMENT

- 1. Input a component color bar (R-Y, Y, B-Y). (Beta 0 level signal).
- 2. From the menu, make the Component Level Beta 0.
- 3. Connect the oscilloscope probe to IC404 Pin 41 or TP401.
- 4. Put the unit into service mode.
- 5. Using R-Y LEVEL COMPONENT, adjust so that the tops of the waveform line up as in the diagram below. (Fig. 13)




Adjust so that B=D above (20 mV max.) Check that the difference between D and C is no greater than 30 mV

#### 5. SUB CHROMA N10/SMPTE Adjustment

- 1. Input a component color bar (R-Y, Y, B-Y). (SMPTE level signal).
- 2. From the menu, make the Component Level N10/SMPTE.
- 3. Connect the oscilloscope probe to IC404 Pin 30 or TP402.
- 4. Put the unit into service mode.
- 5. In the same manner as in 4-5, adjust SUB CHROMA N10/SMPTE.

### 6. BURST GATE PULSE WIDTH Adjustment

- 1. Input an NTSC color bar.
- 2. Connect the oscilloscope probes to TP301 (COMP-SYNC) and Q363 or IC305 Pin 1. (Be careful! IC305 Pin 1 is a high-impedance line.)
- 3. Put the unit into service mode.
- 4. Adjust BGP WIDTH so that the output waveform has the relationship shown in Fig. 14.



# PVM-2054QM


#### 7. VXO Adjustment

- 1. X'tal 358
- 1) Input an NTSC color bar.
- 2) Connect the frequency counter to IC305 Pin 21.
- 3) Put the unit into service mode.
- 4) Connect the circuit on the right to IC305 Pin 1.
- 5) Adjust CRYSTAL 358 so that the counter reading meets the standard below. (You can also just adjust for where the color flicker stops.)

X'tal 358

Standard level

 $3.579545 \pm 20$ Hz



(For connecting to Pin 1, have the four diodes as close to Pin 1 as possible to reduce the length of the wires.)

#### 2. X'tal 443

- 1) Input a 443 NTSC color bar.
- 2) Connect the frequency counter to IC305 Pin 21.
- 3) Put the unit into service mode.
- 4) Connect to IC305 Pin 1 in the same manner as in 1-4).
- 5) Adjust Crystal 443 in the same manner as in 1-5).


X'tal 443

Standard level

 $4.433619 \pm 20$ Hz

#### 8. NTSC COLOR DEMODULATION Adjustment

- 1. NT 358 PHASE (NORMAL)
- 1) Input an NTSC color bar.
- 2) Connect the oscilloscope probe to TP306.
- 3) Put the unit into service mode.
- 4) Adjust PHASE NTSC 358 NOR so that the output waveform burst section is a straight line. (Fig. 15)



#### 2. NT358 PHASE (ACC OFF)

- 1) Switch ACC Off with the menu.
- 2) Adjust in the same manner as in 8.-1 above, but adjust with PHASE NTSC 358 ACC OFF. (Fig. 15)


#### 3. NT358 B-Y PHASE

The phase adjustment must be carried out before the chroma adjustment.

- Input an NTSC color bar.
   (Input only the R-Y component. Have B-Y and Y off.)
- 2) Connect the oscilloscope probe to TP305.
- 3) Put the unit into service mode.
- 4) Adjust B-Y PHASE NTSC 358 so that the color components form a straight line.

# 4. NT358 CHROMA (NORMAL)

- 1) Input an NTSC color bar.
- 2) Connect the oscilloscope probe to IC404 Pin 30 or TP402.
- 3) Put the unit into service mode.
- 4) Using CHROMA NTSC 358 NOR, adjust so that the tops of the waveform line up as in the diagram below. (Fig. 16)




Adjust so that the levels of the first peak and the fourth peak are the same.

# 5. NT 358 CHROMA (ACC OFF)

- 1) Switch ACC Off with the menu.
- 2) Adjust CHROMA NTSC 358 ACC OFF in the same manner as 8.-4 above. (Fig. 16)

#### 6. NTSC 358 R-Y LEVEL


- 1) Input an NTSC358 color bar.
- 2) Connect the oscilloscope probe to IC404 Pin 41 or TP401.
- 3) Put the unit into service mode.
- 4) Using R-Y LEVEL NTSC 358, adjust so that the tops of the waveform line up as in the diagram below. (Fig. 17)



Adjust so that B=D above (20 mV max.) Check that the difference between B and C is no greater than 60 mV.

# 7. NTSC 443 PHASE (NORMAL)

- 1) Input an NTSC 443 color bar.
- 2) Connect the oscilloscope probe to TP306.
- 3) Put the unit into H/V delay mode.
- 4) Put the unit into service mode.
- 5) Adjust PHASE NTSC 443 NOR so that the output waveform burst section is a straight line. (Fig. 18)




# 8. NTSC 443 PHASE (ACC OFF)

- 1) Switch ACC Off with the menu.
- 2) Adjust PHASE NTSC 443 ACC OFF in the same manner as in 7-5). above. (Fig. 20)
- 9. NTSC 443 B-Y PHASE

#### NTSC 443 CHROMA NOR


- 1) Input an NTSC 443 color bar.
- 2) Connect the oscilloscope probe to TP402.
- 3) Put the unit into service mode.
- 4) Adjust B-Y PHASE NTSC 443 and CHROMA NTSC 443

  NOR so that the tracking is normal and the tops of the waveform line up. (Fig. 19)



# 10. NTSC 443 CHROMA (ACC OFF)

- 1) Switch ACC Off with the menu.
- 2) Adjust CHROMA NTSC 443 ACC OFF in the same manner as 9-4). (Fig. 22)




#### 11. NTSC 443 R-Y LEVEL

- 1) Input an NTSC 443 color bar.
- 2) Connect the oscilloscope probe to TP401.
- 3) Put the unit into service mode.
- 4) Adjust R-Y LEVEL NTSC 443 in the same manner as 6-4). (Fig. 17)

# 12. PAL PHASE (NORMAL)

- 1) Input a PAL SP color bar.
- 2) Connect the oscilloscope probe to TP306.
- 3) Put the unit into service mode.
- 4) Adjust PHASE PAL NOR so that the B-Y anti-PAL signal waveform is 0. (Fig. 21)



\* Varies every H, although slightly, so adjust so that the average is 0.

Fig. 21

# 13. PLL PHASE (ACC OFF)


- 1) Switch ACC Off with the menu.
- 2) Adjust PHASE PAL ACC OFF in the same manner as 12-4).

# PVM-2054QM

#### 14. PAL B-Y PHASE

- 1) Input a PAL SP color bar.
- 2) Connect the oscilloscope probe to TP305.
- 3) Put the unit into service mode.
- 4) Adjust B-Y PHASE PAL so that the B-Y anti-PAL signal waveform is 0. (Fig. 22)

(R-Y OUT)



\* Varies every H, although slightly, so adjust so that the average is 0.

Fig. 22

#### 15. PAL CHROMA (NORMAL)

- 1) Input a PAL color bar.
- 2) Connect the oscilloscope probe to IC404 Pin 30 or TP402.
- 3) Put the unit into service mode.
- 4) Adjust CHROMA PAL NOR so that the tops of the waveform line up. (Fig. 23)

Adjust so that the B and D peaks are the same.


40 mV max.

### 16. PAL CHROMA (ACC OFF)

- 1) Switch ACC Off with the menu.
- 2) Adjust CHROMA PAL ACC OFF in the same manner as 15.-4). (Fig. 23)

#### 17. PAL R-Y LEVEL

- 1) Input a PAL color bar.
- 2) Connect the oscilloscope probe to IC404 Pin 41 or TP401.
- 3) Put the unit into service mode.
- 4) Adjust R-Y LEVEL PAL so that the tops of the waveform line up as in the diagram below. (Fig. 24)



#### 9. SECAM Adjustmnet

- \* This must be done after the deflection adjustment.
- Varies with H-FREQ, H-BLK, VIDEO-PHASE, ANGLE, BOW, H-DELAY, etc.

#### 1. HP EIDTH (NORMAL) ADJUSMTNET


The board adjustment in 9.-1. is a rough adjustment and this may also be managed with the IC317 Pin 10 pulse width.

- 1) Input a SECAM color bar.
- 2) Put the unit into under scan mode.
- 3) Put the unit into service mode.
- 4) Adjust HP WIDTH NOR so that the color of the color section at the top left of the screen almost disappears.

#### 2. HP POSITIOM ADJUSMTNET

- 9.-2. is the same as above. This adjustment can be managed with the phase relationship between the start of the pulse at IC317 Pin 10 and the input video signal.
- 1) Input a SECAM color bar.
- 2) Put the unit into H/V delay mode.
- 3) Put the unit into service mode.
- 4) Adjust HP POSITION as in the diagram on the right.
- 3. HP WIDTH (H/V -DL) ADJUSMTNET
- 1) Input a SECAM color bar.
- 2) Put the unit into H/V delay mode.
- 3) Put the unit into service mode.

Adjust HP WIDTH H/V DELAY as in the diagram below.
 Note: Check the HP POSITION and if it is off, repeat 2 and
 3.



#### 4. SECAM COL BALANCE


- 1) Input a SECAM color bar.
- 2) Connect the oscilloscope probe to TP306.
- 3) Put the unit into service mode.
- 4) Adjust SECAM COLOR BALANCE R-Y so that the non-color section forms a straight line.
- 5) Connect the oscilloscope probe to TP305.
- 6) Adjust SECAM COLOR BALANCE B-Y so that the non-color section forms a straight line.

### 5. SECAM CHROMA

- 1) Input a SECAM color bar.
- 2) Connect the oscilloscope probe to IC404 Pin 30 or TP402.
- 3) Put the unit into service mode.
- 4) Adjust CHROMA SECAM so that the tops of the waveform line up as in the diagram below. (Fig. 25)


#### IC404 30 pin

Adjust so that the B and D peaks are the same.



# 6. SECAM R-Y LEVEL

- 1) Input a SECAM color bar.
- 2) Connect the oscilloscope probe to IC404 Pin 41 or TP401.
- 3) Put the unit into service mode.
- 4) Adjust R-Y LEVE SECAM so that the tops of the waveform line up as in the diagram below. (Fig. 26)




#### 10. Writing the adjustment results

1. Write the adjustment results into memory.

#### 5-2. G BOARD ADJUSTMENT

G BOARD - COMPONENT SIDE -



- 1. Checking the output lines
- 1) Input a color bar signal.
- 2) Adjust RV601 so that the +B voltage is 115  $\pm$  0.1 V.
- 3) Check that the output lines meet the standards below.


15V	$16.0 \pm 1.0 \text{V}$
5V(A)	$5.0 \pm 0.3V$
5V(B)	$5.0 \pm 0.5 V$
7V	$7.2 \pm 0.5 V$
- 15V	$-16.3 \pm 1.0V$


# PVM-2054QM


MEMO	

# SECTION 6 DIAGRAMS


# 6-1. BLOCK DIAGRAMS (1)









# **BLOCK DIAGRAMS (2)**






## 6-2. FRAME SCHEMATIC DIAGRAM



E	
)Y	O N D O O O
5	[-   ∾   CN703
IT NE IT CN70 V S-MIC WI	
D	c
D CN702 NEW MIN	? I 6P

MEMO						
					·	
						······································
		·				
			·	·		
			······			 
		·				 
	***************************************					 
		•••••				
			·			
······						
······································						
······································			•			
	······				·	 
······································						 

## 6-3. CIRCUIT BOARDS LOCATION



# 6-4. PRINTED WIRING BOARDS AND SCHEMATIC DIAGRAMS

#### Note:

- All capacitors are in μF unless otherwise noted. pF: μμF
   50 WV or less are not indicated except for electrolytics.
- Indication of resistance, which does not have one for rating electrical power, is as follows.

Pitch: 5 mm Rating electrical power 1/4 W

- All resistors are in ohms.
- : nonflammable resistor.
- fusible resistor.
- △ : internal component.
- panel designation, and adjustment for repair.
- All variable and adjustable resistors have characteristic curve B, unless otherwise noted.
- Should replacement be required, replace only with the value originally used.

  When replacing components identified by [7]
- When replacing components identified by 

   ☐ , make the necessary adjustments indicated. If results do not meet the specified value, change the component identified by 
   ☐ and repeat the adjustment until the specified value is achieved. (Refer to R690 adjust on Page 21 and 22.)
- When replacing the part in below table, be sure to perform the related adjustment.

Part replaced (☑)	Adjustment (►)
C506, C512, C513, C523, C549, C592, D531, D533, IC500, IC507, Q500, Q511,R506, R508, R515, R516, R517, R518,R519, R551, R1535, R1536, R1537, R1560, T501	R1535, R1536 (HOLD-DOWN)

- e All voltages are in V.
- Voltage are dc with respect to gra
- e Readings are taken with a color-
- Voltage variations may be not tolerances.
- B + bus.
- e eman eman : B − bus.
- signal path.
- No mark: with PAL colour-bar signal voltage.
- For the respective voltage ratings
   S-VIDEO, and ANALOG RGB more


### Reference information

neigle information						
RESISTOR	: RN	METAL FIL				
	: RC	SOLID				
	: FPRD	NONFLAME				
	: FUSE	NONFLAM				
	: RW	NONFLAM				
	: RS	NONFLAM				
	: RB	NONFLAME				
COIL	: LF-8L	MICRO INC				
CAPACITOR	: TA	<b>TANTALUN</b>				
	: PS	STYROL				
	: PP	<b>POLYPROF</b>				
	: PT	MYLAR				
	: MPS	METALIZE				
	: MPP	METALIZE				
	: ALB	BIPOLAR				

: ALT : ALR HIGH TEM

HIGH RIPF

#### 6-3. CIRCUIT BOARDS LOCATION



# 6-4. PRINTED WIRING BOARDS AND SCHEMATIC DIAGRAMS

#### Note:

- All capacitors are in  $\mu F$  unless otherwise noted. pF:  $\mu \mu F$ 50 WV or less are not indicated except for electrolytics.
- Indication of resistance, which does not have one for rating electrical power, is as follows.

Pitch: 5 mm Rating electrical power 1/4 W

- · All resistors are in ohms.
- : nonflammable resistor.
- two: fusible resistor.
- \( \triangle \) : internal component.
   \( \triangle \) : panel designation, and adjustment for repair.
- · All variable and adjustable resistors have characteristic curve B, unless otherwise noted.
- The components identified by  $\blacksquare$  in this basic schematic diagram have been carefully factory-selected for each set in order to satisfy regulations regarding X-ray radiation. Should replacement be required, replace only with the value originally used.
- ullet When replacing components identified by  $oldsymbol{\square}$  , make the necessary adjustments indicated. If results do not meet the specified value, change the component identified by  $oldsymbol{\mathbb{H}}$  and repeat the adjustment until the specified value is achieved. (Refer to R690 adjust on Page 21 and 22.)
- When replacing the part in below table, be sure to perform the related adjustment.

Part replaced (☑)	Adjustment (►)
C506, C512, C513, C523, C549, C592, D501, D533, IC500, IC507, Q500, Q511,R506, R508, R515, R516, R517, R518,R519, R551, R1535, R1536, R1537, R1560, T501 (A BOARD) C603, IC602 (G BOARD)	R1535, R1536 (HOLD-DOWN)

- All voltages are in V.
- Voltage are dc with respect to ground unless otherwise noted.
- Readings are taken with a color-bar signal input.
- Voltage variations may be noted due to normal production tolerances.
- : B bus.
- :: signal path.
- No mark: with PAL colour-bar signal sreceived or common voltage.
- For the respective voltage ratings in SECAM, NTSC 3.58, NTSC 4.43, S-VIDEO, and ANALOG RGB modes, see the table

#### Reference information

RESISTOR : RN METAL FILM

	: RC	SOLID
	: FPRD	NONFLAMMABLE CARBON
	: FUSE	NONFLAMMABLE FUSIBLE
	: RW	NONFLAMMABLE WIREWOUND
	: RS	NONFLAMMABLE METAL OXIDE
	: RB	NONFLAMMABLE CEMENT
COIL	: LF-8L	MICRO INDUCTOR
CAPACITOR	: TA	TANTALUM
	: PS	STYROL
	: PP	POLYPROPYLENE
	: PT	MYLAR
	: MPS	METALIZED POLYESTER
	: MPP	METALIZED POLYPROPYLENE
	: ALB	BIPOLAR
	: ALT	HIGH TEMPERATURE
	: ALR	HIGH RIPPLE

Note: The components identified by shading and mark A are critical for safety. Replace only with part number specified.

[MICON, RGB-MATRIX, DAC, ON SCREEN DISPLAY, ON/OFF MUTE, VOL OFF SW, BLACK-SAMPLING, RGB SW] [CHROMA DEMOD, SECAM CHROMA SELECT, SYSTEM SW, SYNC SELECT, B/B-Y SW, R/R-Y SW, G/Y SW, AUDIO SELECT, SECAM DECORDER, HOLD AMP] [H/V OUT, DEFLECTION SYSTEM, SUDIO OUT]

• : Pattern from the

• Pattern of the rea


### COMPONENT SIDE

COMPONE	ENT SIDE							
IC	<u> </u>	IC503	G - 6	Q410	D-4	D332	E-3	1
10101	D 2	IC504	C-7	Q411	B-5	D335	F-1	
IC101	B - 2	IC505	E-6	0412	C-5	D336	F-1	
IC102	B - 1	IC506	E-6	Q413	C-5	D338	E-3	
IC103	C - 1	IC507	D-7	Q414	D-5	D339	E-2	
IC104	B - 1	IC508	C-7	Q415	D-5	D341	C-3	
IC105	B – 3	IC509	C - 7	Q416	D-5	D348	E-5	1
IC106	C – 3	IC510	E - 2	Q425	D-5	D349	E-5	
IC107	C – 2	TDANK	1.07.00	Q426	D-5	D350	E-4	
IC109	C – 3	IRANS	SISTOR	Q429	C-5	D351	B-3	
IC110	C – 3	Q102	C-2	Q430	D-5	D352	E-4	
IC111	B - 2	Q103	C-2	Q432	C-5	D360	C-3	
IC200	A - 5	Q104	B-2	Q433	C-4	D361	C-3	
IC301	G – 2	Q105	A - 3	Q435	D-4	D362	E-2	
IC302	G – 2	Q107	A - 3	Q436	D-4	D365	G - 4	
IC303	E – 1	Q108	C-2	Q437	D-4	D380	D-2	
IC304	G – 1	Q109	B-3	Q438	C-5	D381	D-2	
IC305	G – 2	Q110	A - 1	Q440	C-4	D406	C-1	
IC306	F – 3	Q112	D-5	Q441	C-4	D413	E-5	
IC309	F – 3	Q200	A-6	Q442	C-4	D414	D-4	
IC310	D – 3	Q300	G - 2	Q445	C-5	D415	E-5	
IC311	E – 3	Q308	G-3	Q501	D-9	D416	D-4	
IC312	E – 3	Q311	G - 3	Q502	D-8	D417	D-4	
IC313	F – 2	Q314	F-4	Q503	B-7	D418	D-3	
IC314	G – 4	Q316	F-5	Q512	A - 10	D423	C-6	
IC315	D - 2	Q324	G - 1	Q513	A-9	D424	B-5	1
IC316	G - 5	0335	D-1	Q515	B-8	D502	E-9	
IC317	D – 1	Q341	E-3	Q518	B-7	D504	D-8	İ
IC318	D – 2	Q342	E-3	Q520	B-7	D505	E-10	
IC320	F-5	Q343	E-4	Q523	B-6	D506	D-9	
IC321	F-5	Q346	F-1	Q524	A - 6	D510	F-6	
IC322	E-5	Q347	E – 2	Q525	A-6	D512	D-9	
IC323	E-5	Q348	E-2	Q527	B-8	D514	E-7	1
IC324	E-4	Q353	D-3			D515	F-10	
IC325	E-4	Q354	E-3	DIO	DF	D520	E-6	
IC326	E-2	Q355	F-5			D522	D-6	
IC350	D-2	Q356	D - 2	D104	B - 1	D524	C-8	
IC401	B-4	Q357	G – 2	D105	B – 1	D525	C-9	
IC402	D-4	Q358	G – 1	D109	A – 1	D527	B-8	
IC403	B - 5	Q359	G – 1	D110	E-5	D528	A - 10	
IC404	D-4	Q360	D-2	D112	A – 1	D529	A - 8	
IC405	C-5			D113	B – 4	D530	A – 10	
IC406	B - 5	0362	D-3	D114	F-2	D533	G - 10	
IC407	C-5	0365	E-3	D300	G-2	D535	B-6	
IC408	C-6	Q366	E-3	D301	D-2			
IC409	C-6	Q372	C-3	D305	G-3	D537	A - 7	
IC410	B-4	0373	D-3	D313	G-5	D538 D539	D-6	
IC411	B-5	0374	C-3	D314	C-1		B-7 E-6	
IC412	B-4	Q404	B-5	D318	E-4	D540		
IC413	C-4	Q406	B-5	D319	E-5	D541	F-3	
IC502	G-6	Q408	B-5	D327	D-3			
L		J			1			

0)	(0)	(0)	*	***************************************	
-					
			<u> </u>	8	
		<b>P</b>			
Γ	-				


#### NOTE:

The circuit indicated as left contains high voltage of over 600 Vp-p. Care must be paid to prevent an electric shock in inspection or repairing.




#### Note

- Pattern from the side which enables seeing.
- Pattern of the rear side.





### CONDUCTOR SIDE


		^	Q345	T D - 8	0517	T C 4	Dan	T 5 =
	10	С	Q349	E-9	Q517 Q519	C-4	D408	B-5
	IC101	A - 9	0350	D-8	Q520	C-4	D410	C-5
	IC102	B - 10	0351	D-8	Q520 Q522	B-4 E-5	D411	B-6
	IC108	B - 8	0352	D-8	Q524	A-5	D421	C-5
	IC200	A - 5	Q361	F-8	Q524 Q525	A-3	D422	C-5
	IC303	E-9	Q363	G-9	Q526	A - 4 A - 3	D425	C-5
	IC404	D-6	Q364	D-8	4526	A-3	D426	C-6
	IC505	E-4	0367	E-8	DIC	יחר	D427	B-6
	IC507	D-4	Q368	E-8	DIC	DDE	D500	G-5
			0369	E-8	D101	B - 10	D501 D502	G-2
	TRANS	DOTOE	0375	D-8	D102	B-9	D502	E-2 C-2
			Q401	B-6	D103	B-9	D503	D-2
	Q101	A - 9	0402	B-6	D107	B-9	D505	E-1
	Q111	C - 10	Q403	B-6	D200	A - 4	D506	D-2
	Q113	A-7	Q405	C-6	D301	G-8	D507	G-5
	Q201	A-6	Q407	C-7	D302	F-9	D508	G-5
	Q301	G-8	Q409	D-7	D303	F-7	D509	G-5
	Q302	G - 10	Q417	C-6	D304	G-7	D510	F-5
	Q303	G-6	Q418	B-5	D307	G-8	D512	D-2
	Q304 Q305	G – 6 G – 8	Q419	C-6	D309	G-8	D513	E-5
	Q306	G - 8 G - 7	Q420	C-6	D310 D311	G-8	D514	E-4
	Q307	G-8	Q421	B-5	D311	G-9 E-8	D515	F-1
	0309	G-8	Q422	B - 5	D317	D-9	D516	F-5
	Q310	G = 7	0423	C-5	D320	D-9	D517	D-4
	Q312	G - 8	Q424	C-5	D320	D-9	D518	E-5
	0313	G - 8	Q428	D-6	D323	C - 9	D519	C-4
i	Q315	G-8	Q431	B-5	D324	E-9	D522	A-4
l	Q318	G-8	Q434	C-5	D325	D-8	D523	A – 2
1	Q319	F - 7	Q439	C-6	D326	E - 9	D524	C-2
	Q321	G-8	Q443	C-5	D333	D - 8	D525	C-2
	Q323	G - 10	Q444	B-5	D337	E – 8	D526	B-4
	0325	F-8	Q500	F-2	D344	D - 8	D527	B-3
	Q326	F-6	Q501	D-2	D345	E-7	D528	A – 1
- 1	Q327	F-6	Q502 Q503	D-3	D346	E-7	D529	A – 2
	0328	G-9	Q505	B-3 E-5	D347	E - 7	D530	A – 1
	Q329	G - 9	Q506	B-4	D353	D-8	D531	A-4
- 1	0330	F-9	Q507	E-5	D354	B-7	D532	A – 4
	Q331 ·	F-9	.0508	C-4	D355	C - 7	D533	G-1
	Q332	G 10	Q509	G-5	D363	E-8	D534	B-4
	0333	D-9	Q511	F-2	D364	E-8	D536	A-5
	Q334	F-9	Q512	A-1	D401	B-7		
	Q336	E-10	Q512 Q513	A-1	D404	D-6	VARIA	ABLE
	Q337	E-10	Q514	B-4	D405	B-5		
	Q338	C - 9	Q515	B-4 B-2	D407	D-7	RESIS	
L	0339	D-8	20.0	5 2			RV501	B – 2




PVM-2054QM










23



3.6 Vp-p ( V)

#### · A BOARD WAVEFORMS

3.6 Vp-p ( V )

· A BOARD WAVE	FORMS	
1) 4.3 Vp-p(H)	2 5.6 Vp-p (10MHz)	3 4.8 Vp-p ( V )
PAL 0.3 Vp-p ( H ) SECAM 0.32 Vp-p ( H )	(4) NISC3.58. 4.43 0.28 Vp-p ( H ) 5-VIBEO 0.35 Vp-p ( H )	5 -24 M 24 M 24 0 . 45 Vp-p ( H ) SEC M 0 . 5 Vp-p ( H )
5 ~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~	5 -~Ml~Ml~ 5-VIDEO 0.45 Vp-p ( H )	6 PAL 0.57 Vp-p ( H ) SECAM 0.45 Vp-p ( H )
6 1 4 43 (H) (H) (S-V1860 (H)	PAL 2. 4 Vp-p ( H ) SECAM 2. 3 Vp-p ( H )	7
7 	7 	ANALOG RGB 0.6 Vp-p ( H )
ANALOG RGB 0.6 Vp-p ( H )	ANALOG RGB 0.6 Vp-p(H)	2.6 Vp-p ( H ) SECAM 2.5 Vp-p ( H )
NTSC3.58 2.4 Vp-p(H) NTSC4.43 2.5 Vp-p(H)	5-V1BEO 2.4 Vp-p(H)	ANALDG RGB 3.0 Vp-p(H)
4.6 Vp-p ( V )	PAL 1. 8 Vp-p ( H ) secam 1. 9 Vp-p ( H )	NTSC3.58 NTSC4.43 Vp-p(H)
1.9 Vp-p ( H )	ANALDG RGB 2.4 Vp-p(H)	3.7 Vp-p ( H )
(15)		

### A BOARD \* MARK

0101 ②	PAL 2.3	SECAM 2.4	N°S( 3.58	1150 4,1: 2.2	8-VIDEO   2.0	ANALOG PGB 2.3
3 6	4.5 4.1	4.6	2.2 4.5	4.4 0.1	2.0 4.4	4.5 0
0	3.4	3.4 3.5	0 3.5	3.5	3.1	3.5
(f) (g)	0	0	0 -	()	4.8	0 4,9
- Ti	4.9 5.0	5.0 5.0	- 5 -	0 5.0	0	0
(a)	5.0	5.0 5.0		0		0 0 0
<b>Q</b> \$	0.1	()	1.1		4.9	0.1
(B)	5.0 5.0	5.0 5.0		- Ši		5.0 0.1 0.1
(P) (S)	5.0 4.2	5.0 4.1	5.C 4.6	5.	7.0 5.0 7.0 7.0 7.0 7.0 7.0 7.0	0.1 
\$ D	4.0	4,4	46	50	3.5	3.7
\$	4.2	C.I	3.3	$\frac{3}{4}$	1112	0.1
\$ \$	4.0 0.5	3.4 0.9	3. <u>6</u> 1.0	3 : 0 E	3.1	7.0 1.9 2.2
(1) (8)	3.0 3.6	2.5 3.0	2.6	0 E		3.0
103 (6)	4.0	4.0	4.0	4	2.0	4.0
C104 @	2.3	2.3	2.2	40 02 20 9	20	0 2.3
(1) C105 (3)	3.5 2.3	3.5 2.3 0.1	2.5	31	7.1	3.5 2.3 0
<u>(5)</u>	2.6	0.1	2.7		2.8	2.6
(J) C106 (3)	5.4 2.3	5.4 2.3	1.4	5 -	28	2.6 8.1
(\$)	5.4	5.4	5.4 7.2 5.4	Ē	1 31 -	2.3 5.4
① ⑤	2.4 7.8	2.4 7.8	6			2.4 4.8
.9	5.1 0.1	5.1		5 10		7.8 5.1 0.5 2.5 3.2 3.7
(T)	3.1 2.4	3.1. 4.6	2.6		1 - 3.7 -	2.5
(1)	6.3	6.3	31.0	97		3.7 3.5
<u>ති</u> ව	3.6 0.8	3.6 1.8 4.5	0.2	INTERPOLATION OF TRAINING		2.5 3.1
C107 ② ③	4.6 2.3	4.5 2.3	4.5		1-31-	1 4.0
(A)	2.8	2.3 2.8 1.4	2000 2000 2000 2000 2000 2000 2000 200	21	2.3	2.8 2.8
1	2.9	2.9	1	2 :		2.9
(8) (9)	2.6 2.9	2.6	2.5	2	26	2.5 2.9 2.8
(f) (f)	2.6 3.2	2.6 3.2	1 52	Nonimical Nation Nation	20 16 16 16 16 16 16 16 16 16 16 16 16 16	5.4
<b>1</b>	4.5 6.3	6.3	= <u>5(</u> -	1 5	6.0 - 1.3	5.0 6.1
IC109 ②	4.6	45	1 5			4.4
10	11.9	11.9	11.5	1	1-11-	0.1
® IC110 ③	11.9 2.3	11.9 2.4	2.2	2	01 00 80 62	1.8
(4) (18	7.2 5.8	7.2 5.8	5.8		8.3	7.2 5.8 11.9
(1)	11.9	5.8	11.9	0 0 0 0	1-45-	1.9
(1) (2)	3.7	7.9	2.5	1 2	1 3.5	7.9
IC111 @	0.3	0.3	0.3 0.1 5.0	C.2	0.1	0.3 0.1
13	5.0	5.0 5.0	5.0 5.0	ξ.	3	5.0
IC402 ②	3.1	3.9	2.72	i i	Z.X.	3.5
<u>③</u>	2.9	2.3	2.9	-	2.5	3.0 5.0 3.5 2.2 2.9
IC403 ①	0.8	0.8	0.0	C.		0.9
(3)	1.4	1.3	0.0	13		0
(4) (5)	0.8 0.6	0.8	0.6	13	<u> </u>	0.5
(S)	0.5	0.6	1 - 5.6 - 7	+ -		0
9 10	1.6	1.5				1.6
(1)	0.9	1.0	1 0	1 1	0.9	1.1
10404 ®	- 0.6 3.0	0.6 3.0	3.0	1-88		0.6
① (1)	4.9 5.6	4.9 5.6	1 56			6.1 5.8
(i)	5.6	5.6 0.1	5.6	E .	1.56.	5.8 4.4
3	3.8	4.0	2.1	13	120	3.5
38 30	7.1	6.6 1.3 7.3	85	13	7.7	7.9 1.4
3 3	7.0 1.4	1.3		1-76		7.8
<u>@</u>	7.8	7.8		1 34	9.0	7.7
40	1.2	1.2		14	177	1.3
<b>&amp;</b>	7.2 7.2	7.2	1.0	13.	13 5.9	7.2 7.0
€ IC405 ①	6.6	6.6 1.5	3.6	T E.S	3.5	1.6
② ③	1.4	1.4	0.9	1-1		1.5
( <u>4</u> )	1.4	1.3	10	1=6.		1.4
(S)	0.5	0.5		13		0.2
<u>(1)</u>	0.5	1.2	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	1 -		0.2 0.2 1.3
0	1.4	1.3	1 5 B	13	3	1.4
(§ IC406 ①	1.4	1.3	4.8	1 2	4.8	1.5
3	0.8	0	0.9	1-0	2.8	1.0
6	1.0	0.9 1.0	1.0		2.8	1.1
① IC407 ①	5.1	5.1	1.9			5.1 1.3
(3)	0.4	0.1	3.6			0.5
( <u>a</u> )	0.6	1.3 0 1.8 10.7 5.5 5.5 1.4 - 0.1	2.0			0.7
⑤ ⑤	2.0	1.8	1. 11.	1 1		0.7 2.0 11.2
<u>§</u>	5.5 5.5	5.5	5.5 5.5 1.0 3.7 2.0	E .	1.4	9.5 9.4
0	1.4	1.4	1 10		5.4 2 - 0.5	1.5
(I) (I)	0.6 2.0	1.7	2.0	1 2.0	20	2.0
(3) IC408 (1)	2.0 3.1	1.7	1 37	200	3.7	2.0
1	4.1	3.8	2.0 3.0 0.0 0.4	4 4 .	4.2	4.1
IC409 ①	0	0.6	0.4	9	0 0.3 3.9 5.9	7.5 1.6
(5)	5.9 5.9	5.9 5.9	6.3 6.3 3.3	€.	5.9 5.9 5.0	5.9 5.9
<u>©</u>	5.9	5.9				5.9

			5.55	4.40		1,00
IC410 ①	3.8	4.0	4.0	4.0	0	3.9
2	3.0	3.1	2.4	3.1	0	4.0
3	1.3	0.7	1.4	1.6	2.3	1.5
	1.5					
4	3.5 0.6	3.6	3.0	3.8	3.9	3.9
(5)	0.6	1.3	1.1	1.1	3.1	1.7
6	4.0	4.0	4.0	3.9	0	0
	0	2.0	1.9	1.8	2.5	1.4
9		6.0				
10	2.0	2.3	2.3	2.0	1.8	3.0
IC411 ①	4.1	4.0	3.9	3.8	4.2	4.1
0	1.8	2.0	1.9	1.8	2.5	1.3
10	2.0	2.3	2.3	2.1	1.8	3.0
10412 ②	0.4	0.5	0.4	0.4	5.9	0.6
<u>(4)</u>	8.9	8.9	8.9	8.9	8.9	8.3
3	9.0	8.9	9.0	8.9	8.9	8.3
1	6.0	€.0	6.0	6.0	6.0	0
						1
13	0.4	0.5	0.4	0.4	5.9	0.5
10/13 (2)	7.9	8.0	8.0	8.0	0	6.9
3	0	5.5	5.5	5.5	5.4	0
5	5.5	5.5	5.5		5.4	
	3.3	0.0		5.5		8.6
10	3.1 3.1	3.1	3.1	3.1	0	5.1
19	3 1	3.1	3.1	3.1	6.0	5.1
	7.9	7.9				
3			0.8	7.9	6.3	6.9
anda B	10.9	10.9	10.9	10.9	10.7	10.9
C	8.1	8.1	8.1	8.1	0	8.1
L	11.5	11.5	11.5	1-1.5	11.3	11.5
0104   B 0107 B	- 0.2	0	- 0.2	0	0	- 0.2
0107 B	5.0	5.0	5.0	5.0	5.0	0.1
Fa 21 3						
C	0	0	0	0	0	5.0
0:08 C	2.6	2.6	2.6	2.6	2.9	2.6
E	2.6	2.5	2.6	2.6	2.9	2.6
2111 3	5.0					
		5.0	0	0	4.9	4.9
0	0.4	0.4	0	0	0.4	0.4
Q113 C Q401 B	4.1	4.3	4.2	4.2	3.8	4.0
0401 8	1.1	0.8	1.5	1.6	1.2	1.0
C	7.5	5.5	6.0	5.2	8.4	10.0
3	1.4	1.6	3.2	3.4	3.1	1.0
Q402 B	0.5	0.5	0.5	0.5	2.4	0.5
		7.7				
0	9.5	An extraoria conservances	8.1	7.4	10.4	6.9
E	1.4	1.6	3.2	3.3	3.2	1.0
0404 B	5.3	4.1	4.9	5.2	5.3	5.2
E	6.1	6.3	6.0	6.1		6.2
		1 2.3			6.1	
0406 B	1.3	L	1.2	1.1	1.2	1.4
0406 8	0.7	0.7	0	0.7	0.7	0.7
1	1.6	1.5	1.0	1.5	1.4	1.6
		L	The second second second second second			
0407.9	0	0	0	0	0	0.6
C	6.6	5.5	6.6	6.6	5.4	0
0408 B	5.3	4.7	4.9	5.0	5.2	5.2
5	6.0	6.2	5.9	6.1	6.0	6.1
0409 B	1.9	1.6	1.6	1.6	1.7	1.6
E.	2.0	2.2	2.2	2.2	2.3	2.2
	1 4	1.4				
0411 0	1.4		0.9	1.3	1.3	1.4
0412 8	1.3	1.3	1.0	1.3	1.1	1.4
E	2.0	1.9	1.7	1.9	1.8	2.0
Q413 G	1-30	- 15.1	1.6	- 2.2	1.8	- 2.1
	2.0					- 2.1
	2.0	1.9	- 4.3	0	2.2	2.0
S	2.0	1.9	1.7	1.9	1.8	2.0
Q417 B	1,4	1.4	1.2	1.2	1.2	1.4
		An exercise section recovery				
0418 C	2.1	2.1	1.7	1.7	1.7	2.0
Q419 B	1.4	1,4	1.2	1.1	1.2	1.5
F	- 2.0	1.9	1.7	1.7	1.8	2.0
Q420 B	1.2	1.2	1.0	1.0	1.2	1.3
E	1.8	1.8	1.6	1.6	1.8	1.9
Q422 C	2.1	2.1	1.7	1.7	1.8	2.0
0423 8	0.5	0.3	0.4	0.4	0.4	0.2
C425 C	4.5	4.5	4.5	4.5	4.7	4.5
Q426 C	0.8	0.8	0.7	0.7	0.7	0
Q429 B	0.1	0.8	0.4	0.4	0.1	0.1
E	0	- 2.3	- 1.2	- 1.2	0.4	0.4
0432 B	- 0.3	- 3.8	- 3.4	- 2.7	- 0.1	- 3.9
0	11.9	11.6	11.8	.11.8	12.0	11.6
Q433_B	- c	- 0.1	0	0	0	2.7
	3.0				Access to the second	
		3.0	3.0	3.0	4.5	0
C			0	0	- 0.1	0.4
Q434_B	- 0.1	0			2.9	0
Q434 B	- 0.1		4.5	4.8	1 2.29	
0434 B	- 0.1 3.6	4.7	4.5	4.8		-24
Q434 B C Q438 B	- 0.1 3.6 - 0.4	4.7 - 2.9	- 3.1	- 2.4	.0	- 2.4
Q434 B C Q438 B C	- 0.1 3.6 - 0.4 11.7	4.7 - 2.9 11.4	- 3.1 11.7	4.8 - 2.4 11.7	0	11.7
Q434 B C Q438 B	- 0.1 3.6 - 0.4	4.7 - 2.9	- 3.1	- 2.4	.0	
Q434 B C Q438 B C Q439 B	- 0.1 3.6 - 0.4 11.7 -2.0	4.7 - 2.9 11.4 1.9	- 3.1 11.7 1.8	- 2.4 11.7 1.7	0 11.6 1.8	11.7
O434 B C O438 B C O439 B	- 0.1 3.6 - 0.4 11.7 - 2.0 2.6	4.7 - 2.9 11.4 1.9 2.5	- 3.1 11.7 1.8 2.4	- 2.4 11.7 1.7 2.4	0 11.6 1.8 0	11.7 2.0 2.6
O434 B C O438 B C O439 B E O440 B	- 0.1 3.6 - 0.4 11.7 -2.0	4.7 - 2.9 11.4 1.9 2.5 2.5	- 3.1 11.7 1.8	- 2.4 11.7 1.7 2.4 2.5	0 11.6 1.8 0 2.4	11.7 2.0 2.6 2.7
O434 B C O438 B C O439 B	- 0.1 3.6 - 0.4 11.7 - 2.0 2.6	4.7 - 2.9 11.4 1.9 2.5	- 3.1 11.7 1.8 2.4	- 2.4 11.7 1.7 2.4	0 11.6 1.8 0	11.7 2.0 2.6
O434 B C O438 B C O439 B E O440 B O341 G	- 0.1 3.6 - 0.4 11.7 - 2.0 2.6 2.6 - 1.1	4.7 - 2.9 11.4 1.9 2.5 2.5 - 13.0	- 3.1 11.7 1.8 2.4 2.5 1.7	- 2.4 11.7 1.7 2.4 2.5 - 4.8	0 11.6 1.8 0 2.4	11.7 2.0 2.6 2.7 - 0.7
O434 B C O438 B C Q439 B E O440 B O341 G	- 0.1 3.6 - 0.4 11.7 2.0 2.6 2.6 - 1.1 2.0	4.7 - 2.9 11.4 1.9 2.5 2.5 - 13.0 1.9	- 3.1 11.7 1.8 2.4 2.5 1.7 - 8.1	- 2.4 11.7 1.7 2.4 2.5 - 4.8 1.9	0 11.6 1.8 0 2.4 0	11.7 2.0 2.6 2.7 - 0.7 2.0
Q434 B Q438 B Q439 B Q440 B Q441 G D	- 0.1 3.8 - 0.4 11.7 2.0 2.6 2.6 - 1.1 2.0 2.0	4.7 - 2.9 11.4 1.9 2.5 2.5 - 13.0 1.9	- 3.1 11.7 1.8 2.4 2.5 1.7 - 8.1	- 2.4 11.7 1.7 2.4 2.5 - 4.8 1.9 1.9	0 11.6 1.8 0 2.4 0 1.8	11.7 2.0 2.6 2.7 -0.7 2.0 2.0
O434 B C O438 B C Q439 B E O440 B O341 G	- 0.1 3.6 - 0.4 11.7 2.0 2.6 2.6 - 1.1 2.0	4.7 - 2.9 11.4 1.9 2.5 2.5 - 13.0 1.9	- 3.1 11.7 1.8 2.4 2.5 1.7 - 8.1	- 2.4 11.7 1.7 2.4 2.5 - 4.8 1.9	0 11.6 1.8 0 2.4 0	11.7 2.0 2.6 2.7 - 0.7 2.0
O434 B C O438 B C O439 B C O440 B O441 G D O442 B	- 0.1 3.8 - 0.4 11.7 2.0 2.6 2.6 - 1.1 2.0 2.0	4.7 - 2.9 11.4 1.9 2.5 2.5 - 13.0 1.9 1.9	-3.1 11.7 1.8 2.4 2.5 1.7 -8.1 1.6	- 2.4 11.7 1.7 2.4 2.5 - 4.8 1.9 1.9	0 11.6 1.8 0 2.4 0 1.8 1.8	11.7 2.0 2.6 2.7 - 0.7 2.0 2.0 2.1
Q434 B C Q439 B C Q440 B Q441 G S Q442 B	- 0.1 3.6 - 0.4 11.7 2.0 2.6 2.6 2.6 2.0 2.0 1.3	4.7 - 2.9 11.4 1.9 2.5 2.5 - 13.0 1.9 1.9 1.3	-3.1 11.7 1.8 2.4 2.5 1.7 -8.1 1.6 1.1	- 2.4 11.7 1.7 2.4 2.5 - 4.8 1.9 1.9 1.1 0.7	0 11.6 1.8 0 2.4 0 1.8 1.8 1.1	11.7 2.0 2.6 2.7 -0.7 2.0 2.0 2.1 1.5
O434 B C O438 B C O439 B C O440 B O441 G D O442 B	- 0.1 3.8 - 0.4 11.7 2.0 2.6 2.6 - 1.1 2.0 2.0	4.7 - 2.9 11.4 1.9 2.5 2.5 - 13.0 1.9 1.9	-3.1 11.7 1.8 2.4 2.5 1.7 -8.1 1.6	- 2.4 11.7 1.7 2.4 2.5 - 4.8 1.9 1.9	0 11.6 1.8 0 2.4 0 1.8 1.8	11.7 2.0 2.6 2.7 -0.7 2.0 2.0 2.1


NTSC S. VIDEO ANALOG RGB

### A BOARD \* MARK


	PAL	SECAM	NTSC 3.58	NTSC 4.43	S-VIDEO	ANALOG RGB
C301 ①	2.8	0	2.8	3.0	3.0	2.3
2	2.0	0	1.8	1.7	1.7	3.5
C302 ①	2.9	2.9	2.9	0.3	2.9	2.9
(5)	5.3	5.1	4.5	4.5	4.5	4.5
7	10.5	8.4	0	0	0	0
C303 ®	2.3	2.6	2.2	2.2	2.6	2.8
(4)	0.1	4.2	0.6	0.6	0.6	0.1
16	3.9	2.8	3.1	3.1	3.3	3.9
C304 @	2.2	2.6	2.2	2.2	2.2	2.2
. 9	9.4	0.1	9.4	9.4	9.4	9.4
(0)	7.3	7.3	2.5	2.5	2.6	2.5
0	7.3	7.3	2.5	2.6	2.6	2.5
10	1.9	1.9	2.2	2.2	2.2	2.2
(5)	2.5	2.5	2.2	2.2	2.3	2.2
C305 ①	2.8	2.8	2.8	0	2.8	2.8
(4)	2.5	1,1	2.5	2.4	2.4	1.3
	4.1	4.1	4.1	4.1	4.2	4.5
7					0	
9	0.4	0.2	0	0		0.1
10	2.6	2.6	2.5	2.4	2.5	2.7
@	0	0	0.8	0.8	0.9	0.9
23	2.1	2.7	1.9	1.9	1.9	2.7
C306 ①	8.1	8.1	8.1	8.1	8.1	0
2	0	0	0	0.1	0.1	4.4
IC309 ②	3.6	0	3.6	3.6	3.6	3.6
4	0	0	0	0	0	4.4
IC310 ①	6.2	6.2	6.2	6.2	6.2	5.9
3	6.3	6.3	6.2	6.2	6.2	5.9
13	5.9	5.9	6.0	6.3	5.9	5.9
	0		6.2	6.2	6.2	6.2
IC311 ①		6.2				
2	6.2	6.2	6.2	6.2	6.2	5.9
<u>(4)</u>	6.2	6.3	6.3	6.2	6.2	5.9
6	3.3	3.3	2.9	2.9	2.9	0
10	5.9	5.9	5.9	6.2	5.8	5.9
13	0.4	0.4	0.4	0.4	0.5	0.7
IC312 ②	3.6	0,	3.6	3.6	3.6	3.6
4	0	0	0	12.0	0.1	4.5
IC313 ①	0	6.3	0	6.3	6.3	6.3
IC314 ②	0	3.0	7.6	0	3.0	0
4	0	0	0	0	2.9	0.1
IC315 ①	0.4	0.4	0.4	0.4	0.4	0.6
<u>(4)</u>	0.6	0	0.6	0.6	0.6	0.6
9	9.4	9.3	9.3	9.2	9.3	9.4
	2.5	2.5	2.5	2.5	2.5	7.2
<u> </u>	0.4	0.4	0.4	0.4	0.4	0.6
(5)	0.4	0.4	0.4	0.4	0.4	0.6
IC317 @	2.0	0	2.0	2.1	2.0	12.0
6	12.0	0	12.0	12.0	12.0	12.0
9	10.7	10.6	10.6	10.6	10.5	10.7
(4)	9.4	9.4	9.4	9.4	9.1	9.4
IC318 ⑤	11.5	11.5	0	11.4	11.4	11.4
IC320 ①	6.3	6.3	6.3	6.3	6.3	0
2	3.0	0	0	3.1	0	0
4	0	.0	0	0	3.3	0
IC321 ②	0	0.1	0.1	0	2.9	0
4	0	0	0	0	0.1	2.7
IC322 ⑤	5.8	5.9	6.0	6.3	5.9	5.9
IC323 ⑤	6.2	6.3	6.2	6.2	6.2	5.9
7	0.2	5.6	5.6	5.6	5.6	5.6
	6.2	6.2	6.2	6.2	6.2	5.9
1C324 ⑤				6.3	5.9	5.9
IC326 ①	5.9	5.9	6.0			
2	5.9	5.9	5.9	6.2	5.8	5.9
3	5.9	5.9	5.9	6.2	5.8	5.9
6	1.7	1.9	1.6	1.6	2.1	2.1
6	2.4	1.0	2.3	2.3	2.3	4.6
7	0	- 0.1	10.8	0	0.1	0
8	6.3	6.3	6.3	6.3	6.2	5.9
9	6.3	6.3	6.3	6.3	6.2	5.9
0	6.3	6.3	6.2	6.2	6.2	5.9

IC326 (2)	PAL	SECAM	N7 SC 3.58	NTSC 4.43	S-VIDEO	ANALOG
13	6.2		6.2	6.2	6.2	RGB 5.9
		6.2		6.3	6.2	
(140	6.2	6.2	6.2	6.2		5.9
	6.2	6.2	6.4	6.3	6.2	5.9 6.9
IC350 ①	6.6	6.5	6.2	6.3	6.0	6.4
3	6.2	6.2	6.2	6.3	6.0	6.4
Q300 B	2.5	2.5	2.2	- 55	2.2	2.2
C C	10.2	10.2	10.4	105	10.4	10.5
E	1.9	1.9	1.6	1.6	1.6	1.6
Q301 E	8.6	8.5	8.2	3.3	8.5	9.8
Q303 E	5.7	5.7	5.7	5.7	5.5	5.7
Q304 B	6.3	6.3	6.3	3.4	6.2	6.3
E	5.7	5.7	5.7	0.7	5.5	5.7
Q305 B	8.6	8.5	8.2	3.3	8.5	9.8
E	7.9	7.9	7.6	7.7	7.9	9.1
.Q307 E	1.4	1.4	1.1	1.2	1.4	2.7
Q309 B	1.4	1.4	1.1	0.1	1.4	2.6
C	0.1	0.1	0.2	0.1	0.1	0
E	0.7	1.8	17	1.3	0	1.8
Q312 C	8.2	8.2	8.6	3.3	8.3	8.1
Q313 B	8.2	8.2	8.6	3.3	8.2	8.1
Е	8.8	8.8	9.3	3.0	8.9	8.7
Q314 B	11.9	6.4	11.9	1.9	11.9	11.9
С	0	11.9	0	C	0	0
Q315 B	3.3	3.2	2.9	3.1	3.2	3.3
E	3.9	3.9	3.5	3.8	3.8	4.0
Q318 B	12.1	12.0	11.7	1.9	12.1	12.1
C	1.0	1.0	1.2	1.0	1.0	0.9
Q322 B	2.4	2.4	2.3	2.3	5.6	2.4
E	1.8	1.8	1.8	1.8	5.0	1.8
Q323 B	5.0	5.0	0	0	0	0
C	0	0	3.5	3.5	3.5	3.6
Q324 B	4.1	4.2	0	0	0	0
C	0	0	9.6	3.6	0.8	0.9
Q328 B	2.2	2.2	2.2	2 2 8 2 8 2 4	2.0	1.3
C	2.8	2.8	2.8	2.8	0	0
Q329 D	2.1	2.1	2.2		0	2.2
G	0	0	1.6	0	2.9	2.8
Q332 B	4.9	5.0	0	4.9	0	0
С	0	0	4.4	0	4.3	4.4
Q333 B	1.7	1.7	1.9	1.8	1.7	1.7
E	1.5	1.5	1.7	1.:	1.5	1.4
Q336 G	4.7	4.6	4.6	4./	4.2	4.8
D	and the same of th	4.3	4.3	4.3	4.5	4.3
Q339 B		12.5	12.5		12.5	12.3
Q347 B		4.2	0.1	<u>C.1</u>	0.6	0.1
0010.0	9.4	0.1	9.4	2.7	9.4	9.4
Q349 B		2.7	2.7	4.	2.2	2.8
C 25 4 B		3.3	3.4	3,4	2.8	3.4
Q354 B		0.6	0		0	- 0.2
Q358 E		2.2	0	2.1	2.2	2.2
0360 1	6.2	6.2	6.2	63	6.1	6.4
3300 1		6.2	6.2	6.3	6.0	6.4
5		4.7	2.2	2.1	5.3	3.8
		4.9	5.0	T F. 1	5.0	0.8
0361 P		0	0	E. I	0.1	4.9
Q361 B		9.0	9.0	T c -	9.2	8.5
C		3.3	2.9	+ 5 -	2.8	2.9
Q362 C			0.3	2.3 C.3	0.4	0.4
Q362 C	***	1 0		1 6.5	0.9	4.9
Q362 C Q364 C Q365 B	0.4	0.9	0.8		0.5	1 4.0
Q362 C Q364 C Q365 B Q369 B	0.4	0.9	0.8	1 0 -	0.5	4.9
Q362 C Q364 C Q365 B Q369 B Q372 B	0.4 0.8 0	0.9	0		0	
Q362 C Q364 C Q365 B Q369 B Q372 B	0.4 0.8 0	0.9 0 11.7	0 11.8	0 118		4.9
Q362 C Q364 C Q365 B Q369 B Q372 B Q374 B	0.4 0.8 0 11.7 10.4	0.9	0 11.8 10.1 0	0	0 11.7	4.9
Q362 C Q364 C Q365 B Q369 B Q372 B Q374 E	0.4 0.8 0 11.7 10.4	0.9 0 11.7 10.3	0 11.8 10.1 0	0 11.6 10.3	0 11.7 10.7	4.9 0 6.4
Q362 C Q364 C Q365 B Q369 B Q372 B Q374 E	0.4 0.8 0 11.7 10.4 0 6.4	0.9 0 11.7 10.3	0 11.8 10.1	11 6 10 3 10 3	0 11.7 10.7 6.2	4.9 0 6.4 6.7
Q362 C Q364 C Q365 B Q369 B Q372 B Q374 B Q375 B	0.4 0.8 0 11.7 10.4 0 6.4 10.7	0.9 0 11.7 10.3 0 6.4	0 11.8 10.1 0 6.3	0 11.6 10.3 C 6.3	0 11.7 10.7 6.2 6.1	4.9 0 6.4 6.7 6.7
Q362 C Q364 C Q365 B Q369 B Q372 B Q374 E	0.4 0.8 0 11.7 10.4 0 6.4 10.7	0.9 0 11.7 10.3 0 6.4 10.8	0 11.8 10.1 0 6.3 10.7	0 11.8 10.9 6.3 10.7	0 11.7 10.7 6.2 6.1 10.7	4.9 0 6.4 6.7 6.7 5.9

# A BOARD IC303 CXA1214P





# A BOARD IC305 M51279FP





## • A BOARD WAVEFORMS

· A BOARD WAVEF	URIVIS	
(1)	(16)	(1)
7	البيئة البيئة	ما لسمممال
1.0 Vp-p ( H )	s-VIDEO 0.94 Vp-p ( H )	0.85 Vp-p(H)
1.0 4 5 7 7 7	(18)	(19)
	<b>1 1 1</b>	
S-VIĐEO	S-VIĐEO	S-VIĐEO
0.94 Vp-p(H)	0.6 Vp-p ( H )	0.6 Vp-p(H)
20		
	NTSC3.58	
0.2 Vp-p(H)	NTSC3.58 0.24 Vp-p(H) NTSC4.43 0.12 Vp-p(H)	
2)	2)	2)
<b>10</b> -11 <b>(10)</b> 11 -11 (10)		NTSC3.58, 4.43
PAL 0.27 Vp-p ( H )	SECAM 0.17 Vp-p ( H )	NTSC3.58.4.43 0.24 Vp-p ( H ) s-vibeo 0.27 Vp-p ( H )
23	22	2
Mynny	Marray	
PAL 0.4 Vp-p ( H )	MTSC3.58 O.37 Vp-p ( H ) NTSC4.43	S-VIĐEO O.4 Vp-p ( H )
U.36 Vp-p ( H )	4.0 Vp-p(H)	
ANALOG RGB	l v v v	PAL PAL
1.9 Vp-p (H)	1.0 Vp-p(H)	0.26 Vp-p( H )
25	25	29
the best of the state of the	10 11 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	
0.2 Vp-p ( H )	NTSC3.58. 4.43 0.23 Vp-p ( H )	0.18 Vp-p ( H )
20	27	2
	+of-loop-loop-loop	NTSC3.58. 4.43
5.4 Vp-p ( H )	1.0 Vp-p ( H )	S-VIDEO 1.1 Vp-p ( H )
28	28	29
PAL MANAGEMENT	MISC4: 43	l nnnn nnnr l
0.8 Vp-p ( H ) NTSC3.58 0.85 Vp-p ( H )	MTSC4.43 0.73 Vp-p(H) s-VIDEO 0.9 Vp-p(H)	O.7 Vp-p ( H )
(30)	(31)	(3)
		nunnun
ANALOG RGB 0.7 Vp-p ( H )	ANALOG RGB 0.7 Vp-p(H)	5-V10EO 1.7 Vp-p ( H )
(32)	33	(3) II II
	44 44	
ANALOG RGB 1.4 Vp-p(H)	5-VIĐEO 1.3 Vp-p ( H )	ANALOG RGB
		1.4 Vp-p ( H )
34	39 	
~\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\	ANALOG RGB	PAL
1.3 Vp-p ( H )	ANALOG RGB 1.4 Vp-p ( H )	PAL (0.3 Vp-p ( H )
33	<u>35</u>	(3)
	(B)+(B)(B)+(B)(B)+	<u> </u>
0.1 Vp-p ( H )	0.15 Vp-p ( H )	NTSC4.43 0.3 Vp-p ( H )
33	36	33
5-VIDEO 0.2 Vp-p ( H )	0.3 Vp-p(H)	O.1 Vp-p( H )
38	38	33
	Dodlinos.	
NTSC3.58 0.07 Vp-p(H)	NTSC4.43 0.28 Vp-p ( H )	s-vieco 0.07 Vp-p ( H )
37	38	
	1 1	
3.0 Vp-p ( H )	3.2 Vp-p ( H )	
3.0 VP-P(H)	J. Z V V P V ( 17 )	














**— 66** 





























150.8

153.4

148.0 154.1

144.4 150.5


140.6 141.2

1449

149.6 140.4 140.0

10


M49KGH20X PICTURE TIBE




EYZ:

NC EY29


[R. G. B OUT]




- Q BOARD -




## - H BOARD -



### - X BOARD -




### - J BOARD -




Schemat




- Q BOARD -







- H BOARD -




- X BOARD -



- J BOARD -




- C BOARD -



Schematic diagram

#### 6-5. SEMICONDUCTONS



## **SECTION 7 EXPLODED VIEWS**

specified.

- · Items with no part number and no description are not stocked because they are seldom required for routine service.

  The construction parts of an assembled part are indicated with a collation
- number in the remark column.
- Items marked " \* " are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.

\*4-043-690-01


\*4-043-689-01 BRACKET, G

The components identified by shading and mark A are critical for safety. Replace only with part number

# $O: + B4 \times 12$ $\nabla$ : +BVTT4 × 1

7-2. PICTURE TU ●: +BVTP3 × 1 ■: +BVTP4×1





# REF. NO. PART NO.

51	X-4031-758-
52	*4-043-669-0
53	4-043-680-0
54	*4-043-670-0
55	*4-043-673-0
56	*4-043-672-0
57	*A-1390-390-
58	*4-043-671-0
59	1-544-252-1
60	*A-1371-971-
61	X-4030-162-
62	4-043-681-0

63 4-043-683-0 64 **A**.1-692-921-1 65 \*A-1388-166-66 \*X-4031-740-67 \*4-043-674-0 68 4-901-947-0 69 \( \Delta \).8-736-122-0\( \)


\*3-704-372-0


70



\*4-044-256-01 SHEET METAL, G REINFORCEMENT

4-386-618-01 RIVET, T TYPE





## **SECTION 7 EXPLODED VIEWS**


- NOTE:
   Items with no part number and no description are not stocked because they are seldom required for routine service.
   The construction parts of an assembled part are indicated with a collation number in the remark column.
- Items marked " \* " are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.

#### The components identified by shading and mark 🐧 are critical for safety.

Replace only with part number specified.

#### 7-1. CHASSIS






REF.NO.	PART NO.	DESCRIPTION RE	EMARK	REF.NO	. PART NO.	DESCRIPTION	REMARK
1 2 3 4 5	4-847-802-11	HANDLE COVER, TOP RIVET, NYLON SCREW (OS), CASE, CLAW BRACKET, MAIN		12 13	4-043-688-01	SHEET, AC COVER TERMINAL BOARD ASSY, I/O (A) PANEL, CONNECTOR TERMINAL, GROUND COVER, REAR	
7 A 8 A 9	3. 1-453-164-11 3. 1-576-231-11 *A-1316-175-A	A BOARD, COMPLETE TRANSFORMER ASSY, FLYBACK FUSE (H.B.C.) (4.0A/250V) G BOARD, COMPLETE BRACKET, G		16 17		RIVET, T TYPE SHEET METAL, G REINFORCEMENT	

### 7-2. PICTURE TUBE

<b>:</b> :	+ BVTP3 × 12 + BVTP4 × 16 + B4 × 12 + BVTT4 × 12 (S)	7-685-684-79 7-685-663-79 7-682-563-09 7-685-833-09
		_



The components identified by shading and mark A are critical for safety. Replace only with part number specified.

REMARK

REF	.NO. PART NO.	DESCRIPTION	REMARK	REF.NO.	PART NO.
5 5 5	2 <b>*</b> 4-043-669-01 4-043-680-01	BEZEL ASSY REINFORCEMENT (L), HANDLE HANDLE, PROTECTOR REINFORCEMENT (R), HANDLE BRACKET (B), PICTURE TUBE	52-56,83,84	72 <b>∆</b> 73 74	3-703-961 .1-451-349 *4-382-050 *A-1331-30 *4-379-167
5 5 5	7	BRACKET (A), PICTURE TUBE X BOARD, COMPLETE REFLECTOR, LED SPEAKER H BOARD, COMPLETE		77 ∆∆   78   79	*4-379-160 -1-426-505 4-365-808 4-308-870 1-452-032
6 6 6		CUVER, AC SWITCH		82 83 84	1-452-094 X-4309-60 *4-043-797 4-391-833 4-044-606
6 6 6	7 *4-043-674-01 8 4-901-947-01 9 <b>A.</b> 8-736-122-05				

i			
	72 73 74	3-703-961-01 <b>Δ</b> . 1-451-349-11 *4-382-050-01 *A-1331-300-A *4-379-167-01	SPACER, DY DEFLECTION YOKE (Y20FZA) BAND, C PC BOARD C BOARD, COMPLETE COVER (MAIN), CV
	78. 79		
the same of the same of the same of the same of	81 82 83 84 85	X-4309-608-0 *4-043-797-01 4-391-833-01	MAGNET, ROTATABLE DISK; 15MM Ø PERMALLOY ASSY, CONVERGENCE PLATE, BLIND CLOTH, PROTECTION CUSHION, TALLY

DESCRIPTION

## **SECTION 8 ELECTRICAL PARTS LIST**

#### NOTE:

The components identified by shading and mark A are critical for safety.

Replace only with part number specified.

- Items marked " \* " are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.
- All variable and adjustable resistors have characteristic curve B, unless otherwise noted.

#### RESISTORS

- All resistors are in ohms
   F: nonflammable

When indicating parts by reference number, please include the board name.

CAPACITORS COILS • MF : μF, PF : μμF • MMH : inH, UH : μH

- The components identified by M in this manual have been carefully factory-selected for each set in order to satisfy regulations regarding X-ray radiation. Should replacement be required, replace only with the value originally used.
- \* : Selected to yield optimum performance.
- · There are some cases the reference number on one board overlaps on the other board. Therefore, when ordering parts by the reference number, please

	•						include the	board name.	sterice mainber,	, piease	
REF.NO. PA	RT NO.	DESCRIPTION			REMARK	REF.NO.	PART NO.	DESCRIPTION			REMARK
*A- 1- *4-	1297-197-A 540-044-11 030-359-01	A BOARD, COM ************************************	PLETE *****			C169 C171 C174 C200 C201	PART NO. 1-164-232-11 1-163-251-11 1-163-243-11 1-124-927-11 1-106-383-00 1-163-017-00 1-124-907-11 1-124-360-00 1-126-375-11	CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP ELECT MYLAR	0.01MF 100PF 47PF 4.7MF 0.047MF	10% 5% 5% 20% 10%	50V 50V 50V 50V 100V
*4- *4- 4-	043-154-01 043-994-01 363-414-00	PLATE (CF), SPACER, MICA	SHIELD			C202 C203 C204	1-163-017-00 1-124-927-11 1-124-907-11	CERAMIC CHIP ELECT ELECT	4.7MF 10MF	10% 20% 20%	50V 50V 50V
4	J62 654 II	SCREW (MSX10,	/, r, ɔw (+)			C206	1-126-375-11	ELECT ELECT	1000MF 100MF	20% 20%	16V 25V
	\DANI	A LASS LILIER				C207 C208 C209 C300	1-124-478-11 1-124-907-11 1-124-927-11	ELECI	100MF 10MF	20% 20%	25V 50V
BPF400 1-		FILTER, BAND ACITOR>	PASS			C209 C300 C304	1-124-927-11 1-163-031-11 1-164-004-11	ELECT CERAMIC CHIP CERAMIC CHIP	0.01MF	20% 10%	50V 50V 25V
C105 1-			10006	5%	50 <b>V</b>	C305 C306	1-163-125-00 1-163-031-11		220PF	5%	50V 50V
C106 1- C114 1- C115 1- C116 1-	163-251-11 163-031-11 163-031-11 163-031-11	CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP	100PF 0.01MF 0.01MF 0.01MF	5%	50V 50V 50V 50V	C309 C310 C311	1-163-031-11 1-164-004-11 1-163-809-11	CERAMIC CHIP	0.01MF 0.1MF	10% 10%	50V 25V 25V
C117 1- C118 1- C119 1- C121 1-	163-031-11 163-125-00 165-319-11 163-237-11 165-319-11	CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP	0.01MF 220PF 0.1MF 27PF 0.1MF	5% 5%	50V 50V 50V 50V 50V	C312 C313 C314 C315 C316	1-124-925-11 1-163-145-00 1-163-249-11 1-124-907-11 1-124-477-11	CERAMIC CHIP CERAMIC CHIP ELECT ELECT	82PF 10MF 47MF	20% 5% 5% 20% 20%	50V 50V 50V 50V 25V
C124 1- C132 1- C133 1- C134 1-	163-251-11 163-141-00 163-251-11	CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP	100PF 0.001MF 100PF 100PF		50V 50V 50V 50V 50V	C317 C318 C319 C320 C322	1-163-097-00 1-124-907-11 1-163-222-11 1-163-031-11 1-163-119-00	CERAMIC CHIP ELECT CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP	0.01MF 120PF	5% 20% 0.25PF 5%	50V 50V 50V 50V 50V
C136 1- C140 1- C141 1- C142 1-	163-251-11 164-004-11 164-161-11	CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP	100PF 0.1MF 0.0022MF 220PF	5% 10% 10% 5%	50V 25V 50V 50V 50V	C323 C324 C325 C326 C327	1-163-097-00 1-163-235-11 1-124-907-11 1-164-004-11 1-164-004-11	CERAMIC CHIP CERAMIC CHIP ELECT CERAMIC CHIP CERAMIC CHIP	15PF 22PF 10MF 0.1MF 0.1MF	5% 5% 20% 10% 10%	50V 50V 50V 25V 25V
C144 1- C145 1- C154 1- C155 1-	165-319-11 165-319-11 163-037-11 163-023-00	CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP	0.1MF 0.1MF 0.022MF 0.015MF	10% 10% 10%	50V 50V 25V 50V 50V	C328 C329 C330 C331 C332	1-163-243-11 1-163-097-00 1-164-004-11	CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP	100PF 47PF 15PF 0.1MF	5% 5% 5% 10%	50V 50V 50V 50V 25V
C157 1- C158 1- C159 1- C161 1-	163-019-00	CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP ELECT CERAMIC CHIP	0.0068MF 0.047MF 0.022MF 47MF	10% 10% 10% 20% 5%	50V 25V 25V 16V 50V	C333 C334 C335 C336 C337	1-163-031-11 1-163-141-00 1-163-141-00 1-124-477-11 1-163-031-11	CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP ELECT CERAMIC CHIP	0.001MF 47MF	5% 20%	50V 50V 50V 25V 50V
C164 1- C165 1- C166 1- C167 1-	165-319-11 165-319-11 164-004-11 124-472-11 124-472-11	CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP ELECT ELECT	0.1MF 0.1MF	10% 20% 20%	50V 50V 25V 10V	C338 C339 C340 C341 C342	1-163-119-00 1-163-097-00 1-163-031-11 1-163-119-00 1-163-018-00	CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP	15PF 0.01MF	5% 5% 5%	50V 50V 50V 50V 50V
	v.m +r	-2001		2010 -	!	C343	1-163-031-11	CERAMIC CHIP	0.01MF	,	50 <b>V</b>

# PVM-2054QM

Λ	

REF.NO. PART NO	. DESCRIPTION	-	REMARK	REF.NO.	PART NO.	DESCRIPTION			REMARK
C344 1-163-1 C345 1-163-1 C346 1-124-9 C347 1-163-2 C348 1-164-0	41-00 CERAMIC CHIP 0.00 41-00 CERAMIC CHIP 0.00 03-11 ELECT 1MF 43-11 CERAMIC CHIP 47PF 04-11 CERAMIC CHIP 0.1M	1MF 5% 50 1MF 5% 50 20% 50 5% 50 F 10% 25	0V 0V 0V 0V 5V	C411 C414 C415	1-124-916-11 1-164-004-11 1-163-031-11 1-124-907-11	CERAMIC CHIP CERAMIC CHIP ELECT	0.1MF 0.01MF 10MF	20%	50V 25V 50V 50V
C349 1-163-1 C350 1-163-1 C351 1-124-4 C352 1-163-0 C353 1-165-3	41-00 CERAMIC CHIP 0.00 41-00 CERAMIC CHIP 0.00 77-11 ELECT 47MF 31-11 CERAMIC CHIP 0.01 19-11 CERAMIC CHIP 0.1M	1MF 5% 50 LMF 5% 50 20% 25 MF 50	1	C417 C418 C419 C420 C421	1-164-232-11 1-164-232-11 1-164-182-11 1-124-472-11 1-163-809-11 1-164-222-11	CERAMIC CHIP CERAMIC CHIP ELECT CERAMIC CHIP	0.01MF 0.0033MF 470MF 0.047MF 0.22MF	10% 10% 20% 10%	50V 50V 50V 10V 25V 25V
C356 1-124-9 C357 1-163-0 C358 1-163-0	31-11 CERAMIC CHIP 0.01	20% 50 F 20% 50 MF 50 MF 50	0 V 0 V 0 V	C423 C424 C425 C426	1-163-809-11 1-163-809-11 1-163-031-11 1-163-243-11	CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP	0.047MF 0.047MF 0.01MF 47PF	10%	50V 25V 25V 50V 50V
C361 1-163-0 C362 1-163-0 C363 1-163-0	32-11 CERAMIC CHIP 0.01 31-11 CERAMIC CHIP 0.01 31-11 CERAMIC CHIP 0.01 99-00 CERAMIC CHIP 18PF	√F 50 5% 50	OV OV	C428 C429 C430 C431	1-163-031-11 1-124-119-00 1-163-031-11 1-124-119-00 1-165-319-11 1-164-004-11	ELECT CERAMIC CHIP ELECT CERAMIC CHIP	330MF 0.01MF 330MF	20% 20%	16V 50V 16V 50V
C366 1-163-0 C367 1-163-0 C368 1-124-9	43-00 MYLAR 0.00 31-11 CERAMIC CHIP 0.01 31-11 CERAMIC CHIP 0.01 07-11 ELECT 10MF	1MF 10% 10 MF 50 MF 50 20% 50	OV OV	C433 C434 C435	1-163-235-11 1-163-031-11 1-163-089-00		22PF 0.01MF 6PF 0.1MF	5% 0.25PF	25V 50V 50V 25V
	98-11 CERAMIC CHIP 0.15 77-11 ELECT 47MF 77-11 ELECT 47MF 31-11 CERAMIC CHIP 0.01 41-00 CERAMIC CHIP 0.00	20% 25 20% 25 4F 50 LMF 5% 50	5V 5V 0V	C437 C438 C439 C440	1-164-004-11 1-163-809-11 1-163-809-11 1-163-031-11	CERAMIC CHIP CERAMIC CHIP	0.1MF 0.047MF 0.047MF 0.01MF	10%	25V 25V 25V 50V 50V
C375 1-163-1 C376 1-124-9 C377 1-163-8 C378 1-163-8	09-11 CERAMIC CHIP 0.04 09-11 CERAMIC CHIP 0.04	7 5% 50 MF 20% 50 7MF 10% 25 7MF 10% 25	OV OV	C442 C443 C444 C445	1-163-809-11 1-163-107-00 1-165-319-11 1-163-809-11	CERAMIC CHIP	0.047MF 39PF 0.1MF 0.047MF	10% 5% 10%	50V 50V 25V 50V
	72-11 ELECT 470M 31-11 CERAMIC CHIP 0.01 43-11 CERAMIC CHIP 47PF 77-11 ELECT 47MF	20% 25	OV OV OV 5V	C448 C449 C450	1-163-263-11 1-163-107-00 1-163-227-11 1-163-809-11 1-164-004-11	CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP	330PF 39PF 10PF 0.047MF	5% 0.5PF	50V 50V 50V 25V 25V
C384 1-163-2 C385 1-124-4 C386 1-124-9 C387 1-163-1 C388 1-124-9	49-11 CERAMIC CHIP 82PF 77-11 ELECT 47MF 07-11 ELECT 10MF 41-00 CERAMIC CHIP 0.00 07-11 ELECT 10MF	5% 50 20% 25 20% 50 1MF 5% 50 20% 50	0V 5V 0V	C452 C453 C454 C455	1-163-263-11 1-163-031-11 1-163-107-00 1-163-263-11 1-163-229-11	CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP	330PF 0.01MF 39PF 330PF	5%	50V 50V 50V 50V 50V
C389 1-124-4 C390 1-163-2 C391 1-124-4 C392 1-164-2 C393 1-164-2	77-11 ELECT 47MF 43-11 CERAMIC CHIP 47PF 77-11 ELECT 47MF 98-11 CERAMIC CHIP 0.15		0V 5V	C457 C458 C459 C460	1-163-031-11	CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP	0.01MF 82PF 0.1MF 0.1MF	5% 10% 5%	50V 50V 50V 25V 50V
C394 1-124-4 C395 1-163-2 C396 1-164-2 C397 1-124-4 C398 1-124-4	35-11 CERAMIC CHIP 22PF 99-11 CERAMIC CHIP 0.22 77-11 ELECT 47MF	20% 25 5% 50 10% 25 20% 25 20% 25	3V 5V	C462 C463 C464 C465	1-163-031-11 1-163-031-11	CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP	0.01MF 0.01MF 0.22MF 15PF	10% 5% 5%	50V 50V 25V 50V 50V
C399 1-124-4 C400 1-164-0 C401 1-164-3 C402 1-124-9 C403 1-164-2	04-11 CERAMIC CHIP 0.1M 46-11 CERAMIC CHIP 1MF 10-11 ELECT 47MF	20% 50	5V 6V 0V	C467 C469 C470 C471	1-163-119-00 1-163-037-11 1-163-243-11	CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP	120PF 0.022MF 47PF 33PF	5% 10% 5% 5%	25 V 50 V 50 V 50 V 50 V
C406 1-124-9 C407 1-124-4 C408 1-164-2 C409 1-163-0	77-11 ELECT 47MF 32-11 CERAMIC CHIP 0.01	20% 50 20% 25 4F 10% 50 4F 50	5 <b>V</b>	C473 C475	1-163-031-11 1-163-031-11	CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP	0.01MF		50V 50V 50V

The components identified by shading and mark  $\triangle$  are critical for safety.
Replace only with part number specified.



											1	,
REF.NO.	PART NO.	DESCRIPTION			REMARK	REF.NO.	PART NO.	DESCRIPTION			REMARK	
C477 C478	1-164-299-11	CERAMIC CHIP	0.22MF	10%	25 <b>V</b> 50 <b>V</b>	C549	1-124-667-11		10MF	20%	50V	
	1-164-299-11 1-124-907-11 1-163-121-00 1-124-472-11 1-163-249-11				50V 10V 50V	C550 C551 C552 C553	1-126-163-11 1-106-375-12 1-126-336-11 1-106-389-00 1-130-736-11	ELECT MYLAR ELECT MYLAR	4.7MF 0.022MF 220MF 0.082MF	10%	50V 100V 25V 200V	
C484 C485 C486 C487	1-163-113-00 1-163-113-00 1-163-249-11 1-163-235-11	CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP	68PF 68PF 82PF 22PF	5% 5% 5% 5%	50V 50V 50V 50V		1-130-736-11 1-124-907-11 1-124-907-11 1-106-381-12 1-124-903-11 1-136-173-00		10MF	5% 20% 20%	50V 50V 50V	
C488 C490		CERAMIC CHIP			50V 25V	C557 C558 C559	1-106-381-12 1-124-903-11 1-136-173-00	MYLAR ELECT FILM	0.039MF 1MF 0.47MF	10% 20% 5%	100V 50V 50V	
C491 C492 C493 C494	1-164-336-11 1-164-336-11 1-104-760-11 1-104-760-11	CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP		10% 10%	25V 25V 25V 50V 50V	•	1-136-159-00 1-163-249-11 1-124-907-11 1-124-903-11 1-106-367-00				50V 50V 50V 50V	
C495 C496	1-124-907-11 1-163-249-11	ELECT CERAMIC CHIP	10MF 82PF	20% 5%	50V 50V	C566	1-106-367-00	MYLAR	0.01MF	10%	100V 50V	
C497 C498 C499 C500	1-124-907-11 1-163-249-11 1-163-011-11 1-124-925-11 1-163-031-11	CERAMIC CHIP	0.0015MF 2.2MF 0.01MF	20%	50V 50V 50V	C567 C568 C569 C570 C571	1-136-499-11 1-124-903-11 1-131-350-00 1-124-360-00 1-164-232-11	ELECT TANTALUM ELECT CERAMIC CHIP	1MF 3.3MF 1000MF	5% 20% 10% 20% 10%	50V 50V 25V 16V 50V	
C501 C502 C503	1-164-004-11 1-164-182-11 1-163-141-00 1-163-251-11	CERAMIC CHIP CERAMIC CHIP	0.0033MF 0.001MF	10% 5% 5% 5%	50V	!	1-104-709-11 1-136-177-00 1-249-383-11		4.7MF 1MF 1.5 5%		160V 50V	
C504 C505	1 100 110 00	CEDYMIC CRID	ECODE -	0/ د	50V	C574 C575 C576	1-249-383-11 1-163-031-11 1-102-244-00	CERAMIC CHIP	1.5 5% 0.01MF 220PF	1/4W 10%	F 50V 500V	
C506 C507 C508	1-126-375-11	ELECT ELECT MYLAR	0.47MF 100MF 0.1MF 470MF	20% 5%	50V 25V 50V	1			10MF 1MF	20%	50V 200V	
C509 C511	1-124-935-11			20% 10%	100V 200V	C579 C580 C581	1-124-907-11 1-136-111-00 1-126-804-11 1-136-105-00 1-124-927-11	ELECT FILM ELECT	100MF 0.33MF 4.7MF	5% 20% 5% 20%	50V 200V 50V	
C512	1-108-700-11 1-124-902-00 1-126-096-11 1-129-718-00	EN PERMIT	0.047MF 0.47MF 10MF 0.022MF	20% 20%	50V	C582 C583 C584	1-102-002-00 1-136-541-11 1-123-267-00 1-124-666-11 1-124-557-11	CERAMIC FILM	680PF 1.5MF	10%	500V 200V	
C515 C516	1-163-809-11	CERAMIC CHIP	0.047MF	10%	500V	C584 C585 C586	1-123-267-00 1-124-666-11 1-124-557-11	ELECT ELECT ELECT	2.2MF 4.7MF 1000MF	20% 20% 20%	160V 250V 25V	
C517 C518 C519 C520	1-163-024-00 1-107-995-11 1-163-017-00 1-163-257-11	CERAMIC CHIP ELECT CERAMIC CHIP CERAMIC CHIP	0.018MF 100MF 0.0047MF 180PF	10% 0 10% 5%	50V 160V 50V 50V	C587 C588 C589	1-102-030-00 1-124-667-11 1-102-030-00 1-126-387-11 1-106-371-00	CERAMIC ELECT CERAMIC	330PF 10MF 330PF	20% 10%	500V 50V 500V	
C521 C522	1-162-114-00	CERAMIC	0.0047MF	20%	257					20% 10%	50V 200V	
C523 C525 A C526 A	1-120-373-11 1-126-801-11 \(\Lambda\) 1-136-904-11 \(\Lambda\) 1-162-116-91	ELECT FILM CERAMIC	1MF 0.0115MF 680PF	20% 3% 10%	50V 2KV 2KV	C592 C593 C594	1-123-932-00 1-165-319-11 1-163-229-11	ELECT CERAMIC CHIP CERAMIC CHIP	4.7MF 0.1MF 12PF	20% 5%	160V 50V 50V	
C527	1-162-133-00 1-104-797-11	CERAMIC ELECT	390PF 0.47MF	10% 20%	2KV 50V	C595 C596	1-126-336-11 1-124-478-11	ELECT ELECT	220MF 100MF	20% 20%	25V 25V	•
C529 C530 C531 C532	1-124-120-11 1-124-477-11 1-163-031-11	ELECT ELECT CERAMIC CHIP	220MF 47MF	20% 20%	25V 25V 50V	C597 C598 C599	1-164-346-11 1-164-346-11 1-126-157-11	CERAMIC CHIP CERAMIC CHIP ELECT		20%	16V 16V 16V	
C533	1-102-212-00 1-123-948-00	CERAMIC ELECT	820PF 22MF	10% 20%	500V 250V	C1300	1-124-477-11 1-124-477-11	ELECT ELECT	47MF 47MF	20% 20%	25V 25V	
C534 C537 C538 C539	1-124-913-11	ELECT MYLAR FILM	470MF 0.01MF 0.0056MF	20% 10% 5%	50V 100V 50V	C1304	1-163-131-00 1-124-477-11 1-124-477-11	CERAMIC CHIP ELECT ELECT	390PF 47MF 47MF	5% 20% 20%	50V 25V 25V	
C540	1-163-133-00 1-124-927-11	CERAMIC CHIP		5% 20%	50V 50V	C1306 C1307	1-163-031-11 1-163-031-11	CERAMIC CHIP CERAMIC CHIP	0.01MF		50V 50V	
C541 C542 C543 C544	1-106-351-00 1-106-351-00 1-106-367-00	MYLAR MYLAR MYLAR	0.0022MF 0.0022MF 0.01MF	10% 10% 10%	100V 100V 100V	C1309	1-124-443-00 1-163-257-11 1-163-031-11	ELECT CERAMIC CHIP CERAMIC CHIP	100MF 180PF 0.01MF	20% 5%	10V 50V 50V	
C545 C546	1-102-212-00 1-163-119-00	CERAMIC CERAMIC CHIP	820PF	10%	500V 50V	C1311	1-124-477-11 1-163-031-11	ELECT CERAMIC CHIP	47MF	20%	25V 50V	
C547 C548	1-163-119-00 1-163-251-11 1-102-212-00	CERAMIC CHIP CERAMIC		5% 5% 10%	50V 500V	C1313 C1314	1-163-031-11 1-124-477-11	CERAMIC CHIP ELECT	0.01MF 47MF	20%	50 <b>V</b> 25 <b>V</b>	

# PVM-2054QM

REF.NO.	PART NO.	DESCRIPTION			REMARK	REF.NO.	PART NO.	DESCRIPTION			REMARK	
C1318 C1319	1-124-477-11	CERAMIC CHIP	4/MF 0.022MF	20% 10%	25V	i				5%	50V 50V 50V 50V	
C1320 C1321 C1322 C1323 C1324	1-124-477-11 1-124-477-11 1-124-120-11 1-163-031-11 1-163-031-11	ELECT ELECT ELECT CERAMIC CHIP CERAMIC CHIP	47MF 47MF 220MF 0.01MF 0.01MF	20% 20% 20%	25V 25V 16V 50V 50V	C1402 C1403 C1404 C1405	1-163-031-11 1-136-173-00 1-164-299-11	FILM CERAMIC CHIP	0.47MF 0.22MF	5% 10% 5%	50V 50V 25V 50V	
C1325 C1326 C1327 C1328 C1329	1-163-031-11 1-124-477-11 1-163-031-11 1-163-031-11 1-124-907-11	CERAMIC CHIP ELECT CERAMIC CHIP CERAMIC CHIP ELECT	0.01MF 47MF 0.01MF 0.01MF 10MF	20%	50V 25V 50V 50V 50V	C1407				0.25PF	50V 50V 10V 10V	
C1330 C1331 C1332 C1333 C1334	1-163-031-11 1-124-477-11 1-124-477-11 1-124-477-11 1-163-227-11	CERAMIC CHIP ELECT ELECT ELECT CERAMIC CHIP	0.01MF 47MF 47MF 47MF 10PF	20% 20% 20% 0.5PF	50V 25V 25V 25V 50V	C1504 C1505 C1506	1-124-907-11 1-136-165-00 1-124-119-00	ELECT FILM ELECT	10MF 0.1MF 330MF	20% 5% 20%	50V 50V 16V	
C1335 C1336 C1338 C1339 C1340	1-124-477-11 1-124-477-11 1-163-031-11 1-163-031-11	ELECT ELECT CERAMIC CHIP CERAMIC CHIP	47MF 47MF 0.01MF 0.01MF 0.01MF	20% 20%	25V 25V 50V 50V 50V	C1508 C1509 C1510 C1511 C1512	1-124-927-11 1-124-907-11 1-124-927-11 1-164-182-11 1-124-927-11	ELECT ELECT CERAMIC CHIP	4.7MF 10MF 4.7MF 0.0033MF	20% 20% 20% 10% 20%	50V 50V 50V 50V 50V	
C1341 C1342 C1343 C1344 C1345	1-163-275-11 1-102-963-00 1-163-113-00 1-163-083-00 1-124-907-11	CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP ELECT	0.001MF 33PF 68PF 1PF 10MF	5% 5% 5% 0.25PF 20%	50V 50V 50V 50V 50V	C1513 C1514 C1515 C1516 C1517	1-163-133-00 1-130-477-00 1-124-907-11 1-163-063-00 1-126-101-11	MYLAR ELECT CERAMIC CHIP ELECT	0.0033MF 10MF 0.022MF 100MF	5% 20% 10% 20%	50V 50V 50V 10V	
C1346 C1347 C1348 C1349 C1350	1-124-477-11 1-163-031-11 1-163-127-00 1-163-117-00 1-164-232-11	CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP			25V 50V 50V 50V 50V	C1519 C1520 C1521					25V 2KV 50V	
C1351 C1352 C1353 C1354 C1355	1-124-903-11 1-163-023-00 1-163-031-11 1-163-121-00 1-163-125-00	CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP	1MF 0.015MF 0.01MF 150PF 220PF	20% 10% 5% 5%	50V 50V 50V 50V 50V	CN101 CN102			OARD TO BOARD TOR 11P	) 11P		
C1359	1-163-263-11	CERAMIC CHIP	330PF	5% 20% 20% 5% 10%	50V 16V 25V 50V 50V	CN301 CN302	*1-564-514-11 *1-564-510-11	PLUG, CONNEC	TOR 11P TOR 7P	) 12P		
C1362 C1363 C1364 C1365	1-163-249-11 1-163-235-11 1-163-133-00 1-163-227-11	CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP	22PF 470PF 10PF	5% 5% 5% 0.5PF	50V 50V 50V 50V	CN304 CN305 CN401	*1-564-509-11 *1-565-504-11* *1-564-511-11	PLUG, CONNEC CONNECTOR, B PLUG, CONNEC	TOR 6P OARD TO BOARD TOR 8P	) 13P		
C1367 C1369 C1370 C1372	1-124-477-11 1-163-237-11 1-163-237-11 1-124-477-11	ELECT CERAMIC CHIP CERAMIC CHIP ELECT	47MF 27PF 27PF 47MF	20% 5% 5% 20%	25V 50V 50V 25V	CN501 CN502 CN503 CN504	*1-580-798-11 *1-573-964-11 *1-573-964-11 *1-564-508-11	CONNECTOR PI PIN, CONNECT PIN, CONNECT PLUG, CONNEC	N (DY) 6P OR (PC BOARD) OR (PC BOARD) TOR 5P	) 6P ) 6P		
C1374 C1375 C1378 C1380	1-124-477-11 1-124-927-11 1-163-097-00 1-163-101-00	ELECT ELECT CERAMIC CHIP CERAMIC CHIP	47MF 4.7MF 15PF 22PF	20% 20% 5% 5%	25V 50V 50V 50V	CN506	1-249-383-11 *1-535-419-00	CARBON TAB, FASTEN	1.5 5% (PCB)	1/4W	F	
C1382 C1383	1-124-443-00 1-124-477-11 1-163-038-00	ELECT ELECT CERAMIC CHIP	100MF 47MF 0.1MF	20% 20%	10V 25V 25V 50V		1-236-366-11 1-236-365-11 1-808-654-21 1-466-162-61	MODULE, TRAP		, . ) .		
	C1315 C1316 C1317 C1318 C1319 C1320 C13212 C1323 C1324 C1325 C1326 C1327 C1328 C1329 C1330 C1331 C1332 C1333 C1334 C1335 C1336 C1338 C1339 C1340 C1341 C1342 C1343 C1341 C1342 C1345 C1346 C1347 C1346 C1347 C1346 C1347 C1348 C1349 C1357 C1368 C1368 C1368 C1377 C1378 C1368 C1378	C1315 1-124-477-11 C1316 1-163-031-11 C1317 1-124-477-11 C1318 1-124-477-11 C1319 1-163-037-11 C1320 1-124-477-11 C1321 1-124-477-11 C1322 1-124-120-11 C1323 1-163-031-11 C1324 1-163-031-11 C1325 1-163-031-11 C1326 1-124-477-11 C1327 1-163-031-11 C1328 1-163-031-11 C1329 1-124-907-11 C1330 1-163-031-11 C1331 1-124-477-11 C1332 1-124-477-11 C1332 1-124-477-11 C1333 1-124-477-11 C1334 1-163-031-11 C1338 1-163-031-11 C1339 1-163-031-11 C1338 1-163-031-11 C1340 1-163-031-11 C1341 1-163-031-11 C1342 1-102-963-00 C1343 1-163-031-11 C1344 1-163-031-11 C1345 1-124-907-11 C1346 1-124-477-11 C1347 1-163-031-11 C1348 1-163-113-00 C1344 1-163-031-11 C1345 1-124-907-11 C1356 1-124-907-11 C1367 1-124-907-11 C1357 1-124-907-11 C1358 1-163-125-00 C1359 1-163-125-00 C1359 1-163-235-11 C1351 1-124-907-11 C1351 1-124-907-11 C1352 1-163-235-11 C1353 1-163-125-00 C1353 1-163-125-00 C1354 1-163-125-00 C1355 1-163-227-11 C1357 1-124-477-11 C1359 1-163-235-11 C1359 1-163-235-11 C1359 1-163-235-11 C1360 1-163-237-11 C1374 1-124-477-11 C1375 1-124-477-11 C1376 1-163-237-11 C1377 1-124-477-11 C1378 1-163-031-11 C1364 1-163-237-11 C1379 1-163-237-11 C1370 1-163-237-11 C1371 1-124-477-11 C1372 1-124-477-11 C1373 1-124-477-11 C1374 1-124-477-11 C1375 1-124-477-11 C1376 1-163-237-11 C1377 1-124-477-11 C1378 1-163-031-11 C1382 1-163-097-00 C1382 1-124-477-11 C1374 1-124-477-11 C1375 1-124-477-11 C1376 1-163-097-00 C1381 1-163-101-00 C1382 1-124-477-11 C1374 1-124-477-11 C1375 1-124-477-11 C1376 1-124-477-11 C1377 1-124-477-11 C1378 1-163-097-00 C1388 1-163-101-00 C1388 1-163-101-00	C1319 1-163-037-11 CERAMIC CHIP  C1320 1-124-477-11 ELECT C1321 1-124-477-11 ELECT C1322 1-124-120-11 ELECT C1323 1-163-031-11 CERAMIC CHIP  C1324 1-163-031-11 CERAMIC CHIP  C1325 1-163-031-11 CERAMIC CHIP C1326 1-124-477-11 ELECT C1327 1-163-031-11 CERAMIC CHIP C1328 1-163-031-11 CERAMIC CHIP C1329 1-124-907-11 ELECT C1330 1-163-031-11 CERAMIC CHIP C1331 1-124-477-11 ELECT C1332 1-124-477-11 ELECT C1333 1-124-477-11 ELECT C1334 1-163-027-11 CERAMIC CHIP C1335 1-124-477-11 ELECT C1336 1-124-477-11 ELECT C1337 1-163-031-11 CERAMIC CHIP C1339 1-163-031-11 CERAMIC CHIP C1340 1-163-031-11 CERAMIC CHIP C1341 1-163-031-11 CERAMIC CHIP C1342 1-102-963-00 CERAMIC CHIP C1343 1-163-031-11 CERAMIC CHIP C1344 1-163-031-11 CERAMIC CHIP C1345 1-124-907-11 ELECT C1346 1-124-477-11 ELECT C1347 1-163-031-11 CERAMIC CHIP C1348 1-163-117-00 CERAMIC CHIP C1349 1-163-117-00 CERAMIC CHIP C1349 1-163-117-00 CERAMIC CHIP C1350 1-164-232-11 CERAMIC CHIP C1351 1-124-907-11 ELECT C1358 1-124-119-00 CERAMIC CHIP C1355 1-163-237-11 CERAMIC CHIP C1356 1-163-235-11 CERAMIC CHIP C1357 1-124-119-00 CERAMIC CHIP C1358 1-124-477-11 ELECT C1358 1-124-477-11 ELECT C1358 1-124-477-11 ELECT C1364 1-163-125-00 CERAMIC CHIP C1365 1-163-235-11 CERAMIC CHIP C1366 1-163-235-11 CERAMIC CHIP C1367 1-124-477-11 ELECT C1378 1-163-235-11 CERAMIC CHIP C1368 1-163-235-11 CERAMIC CHIP C1369 1-163-235-11 CERAMIC CHIP C1360 1-163-237-11 CERAMIC CHIP C1361 1-163-237-11 CERAMIC CHIP C1362 1-163-237-11 CERAMIC CHIP C1370 1-163-237-11 CERAMIC CHIP C1371 1-124-477-11 ELECT C1373 1-124-477-11 ELECT C1374 1-124-477-11 ELECT C1375 1-124-477-11 ELECT C1376 1-163-237-11 CERAMIC CHIP C1376 1-163-237-11 CERAMIC CHIP C1382 1-124-477-11 ELECT C1378 1-163-038-00 CERAMIC CHIP C1382 1-124-477-11 ELECT C1378 1-163-038-00 CERAMIC CHIP C1384 1-163-038-00 CERAMIC CHIP C1384 1-163-038-00 CERAMIC CHIP C1384 1-163-038-00 CERAMIC CHIP C1386 1-163-203-00 CERAMIC CHIP C1381 1-163-2038-00 CERAMIC CHIP C1382 1-124-477-11 ELECT C1376 1-164-232-10 CERAMIC CHIP C1384 1-163-038-00 CERAMIC CHIP C1	C1315 1-124-477-11 ELECT 47MF C1316 1-163-031-11 CERAMIC CHIP 0.01MF C1317 1-124-477-11 ELECT 47MF C1318 1-124-477-11 ELECT 47MF C1320 1-124-477-11 ELECT 47MF C1321 1-124-477-11 ELECT 47MF C1321 1-124-477-11 ELECT 47MF C1322 1-124-120-11 ELECT 220MF C1323 1-163-031-11 CERAMIC CHIP 0.01MF C1324 1-163-031-11 CERAMIC CHIP 0.01MF C1325 1-163-031-11 CERAMIC CHIP 0.01MF C1326 1-124-477-11 ELECT 47MF C1327 1-163-031-11 CERAMIC CHIP 0.01MF C1328 1-124-477-11 ELECT 47MF C1329 1-124-907-11 ELECT 47MF C1330 1-163-031-11 CERAMIC CHIP 0.01MF C1331 1-124-477-11 ELECT 47MF C1333 1-124-477-11 ELECT 47MF C1333 1-124-477-11 ELECT 47MF C1334 1-163-227-11 CERAMIC CHIP 0.01MF C1335 1-124-477-11 ELECT 47MF C1336 1-124-477-11 ELECT 47MF C1337 1-163-031-11 CERAMIC CHIP 0.01MF C1340 1-163-031-11 CERAMIC CHIP 0.01MF C1341 1-163-275-11 CERAMIC CHIP 0.01MF C1342 1-102-963-00 CERAMIC CHIP 0.01MF C1343 1-163-131-10 CERAMIC CHIP 0.01MF C1344 1-163-031-11 CERAMIC CHIP 0.01MF C1345 1-124-907-11 ELECT 47MF C1346 1-124-907-11 ELECT 47MF C1347 1-163-031-11 CERAMIC CHIP 0.01MF C1348 1-163-117-00 CERAMIC CHIP 0.01MF C1349 1-163-117-00 CERAMIC CHIP 0.01MF C1351 1-124-907-11 ELECT 47MF C1352 1-163-032-01 CERAMIC CHIP 0.01MF C1351 1-124-907-11 ELECT 47MF C1352 1-163-031-11 CERAMIC CHIP 0.01MF C1351 1-124-907-11 ELECT 47MF C1352 1-163-031-11 CERAMIC CHIP 0.01MF C1351 1-124-907-11 ELECT 47MF C1352 1-163-031-11 CERAMIC CHIP 0.01MF C1351 1-124-907-11 ELECT 47MF C1352 1-163-227-10 CERAMIC CHIP 0.01MF C1351 1-124-00-11 CERAMIC CHIP 0.01MF C1351 1-124-00-11 CERAMIC CHIP 0.01MF C1351 1-124-00-11 CERAMIC CHIP 0.01MF C1351 1-124-477-11 ELECT 47MF C1362 1-163-235-11 CERAMIC CHIP 22PF C1363 1-163-235-11 CERAMIC CHIP 22PF C1363 1-163-237-11 CERAMIC CHIP 22PF C1363 1-163-031-00 CERAMIC CHIP 22PF C1361 1-163-247-11 ELECT 47MF C1375 1-124-477-11 ELECT 47MF C1375 1-124-477-11 ELECT 47MF C1376 1-163-237-11 CERAMIC CHIP 22PF C1371 1-163-031-00 CERAMIC CHIP 22PF C1381 1-163-031-00 CERAMIC CHIP 22PF C1381 1-163-031-00 CERAMIC CHIP 22PF C1381 1-163-031-00 CERAMIC CHIP 22PF	C1315 1-124-477-11 ELECT 47MF 20% C1316 1-163-031-11 CERAMIC CHIP 0.01MF 20% C1318 1-124-477-11 ELECT 47MF 20% C1318 1-124-477-11 ELECT 47MF 20% C1320 1-124-477-11 ELECT 47MF 20% C1321 1-124-127-11 ELECT 20MF 20% C1322 1-124-127-11 ELECT 20MF 20% C1323 1-163-031-11 CERAMIC CHIP 0.01MF 20% C1323 1-163-031-11 CERAMIC CHIP 0.01MF 20% C1324 1-163-031-11 CERAMIC CHIP 0.01MF 20% C1325 1-163-031-11 CERAMIC CHIP 0.01MF 20% C1326 1-124-477-11 ELECT 47MF 20% C1327 1-163-031-11 CERAMIC CHIP 0.01MF 20% C1328 1-163-031-11 CERAMIC CHIP 0.01MF 20% C1329 1-124-907-11 ELECT 47MF 20% C1330 1-163-031-11 CERAMIC CHIP 0.01MF 20% C1331 1-124-477-11 ELECT 47MF 20% C1332 1-163-031-11 CERAMIC CHIP 0.01MF 20% C1333 1-124-477-11 ELECT 47MF 20% C1334 1-163-031-11 CERAMIC CHIP 0.01MF 20% C1335 1-124-477-11 ELECT 47MF 20% C1336 1-124-477-11 ELECT 47MF 20% C1337 1-163-031-11 CERAMIC CHIP 0.01MF 20% C1338 1-163-031-11 CERAMIC CHIP 0.01MF 20% C1336 1-124-477-11 ELECT 47MF 20% C1337 1-163-031-11 CERAMIC CHIP 0.01MF 20% C1338 1-163-031-11 CERAMIC CHIP 0.01MF 20% C1341 1-163-031-11 CERAMIC CHIP 0.01MF 20% C1342 1-102-963-00 CERAMIC CHIP 0.01MF 20% C1343 1-163-113-00 CERAMIC CHIP 0.01MF 20% C1344 1-163-031-11 ELECT 10MF 20% C1347 1-163-031-11 ELECT 20% C1348 1-163-113-00 CERAMIC CHIP 0.01MF 20% C1347 1-163-031-11 ELECT 10MF 20% C1348 1-163-113-00 CERAMIC CHIP 0.01MF 20% C1349 1-163-113-00 CERAMIC CHIP 0.01MF 20% C1341 1-163-031-11 CERAMIC CHIP 0.01MF 20% C1345 1-124-907-11 ELECT 10MF 20% C1356 1-163-235-11 ELECT 47MF 20% C1357 1-124-109-00 ELECT 47MP 20% C1358 1-163-031-11 CERAMIC CHIP 20PF 5% C1356 1-163-235-11 ELECT 47MP 20% C1357 1-124-477-11 ELECT 47MP 20% C1358 1-163-031-11 CERAMIC CHIP 20PF 5% C1356 1-163-235-11 CERAMIC CHIP 20PF 5% C1357 1-124-477-11 ELECT 47MF 20% C1358 1-163-031-00 CERAMIC CHIP 20PF 5% C1356 1-163-235-11 CERAMIC CHIP 20PF 5% C1357 1-124-477-11 ELECT 47MF 20% C1358 1-163-037-10 CERAMIC CHIP 20PF 5% C1358 1-163-037-10 CERAMIC CHIP 20PF 5% C1358 1-163-037-11 CERAMIC CHIP 20PF 5% C1368 1-163-235-11 CERAMIC CHIP 20PF 5% C1368	C1315 1-124-477-11 ELECT 47MF 20\(\chicksymbol{2}\) 25V C1316 1-163-031-11 ELECT 47MF 20\(\chicksymbol{2}\) 25V C1319 1-163-037-11 ELECT 47MF 20\(\chicksymbol{2}\) 25V C1319 1-163-037-11 ELECT 47MF 20\(\chicksymbol{2}\) 25V C1320 1-124-477-11 ELECT 47MF 20\(\chicksymbol{2}\) 25V C1321 1-124-477-11 ELECT 47MF 20\(\chicksymbol{2}\) 25V C1322 1-124-120-11 ELECT 20MF 20\(\chicksymbol{2}\) 1-163-031-11 CERAMIC CHIP 0.01MF 50V C1323 1-163-031-11 CERAMIC CHIP 0.01MF 50V C1326 1-124-477-11 ELECT 47MF 20\(\chicksymbol{2}\) 25V C1322 1-124-120-11 ELECT 47MF 20\(\chicksymbol{2}\) 25V C1322 1-163-031-11 CERAMIC CHIP 0.01MF 50V C1326 1-124-907-11 ELECT 47MF 20\(\chicksymbol{2}\) 25V C1328 1-163-031-11 CERAMIC CHIP 0.01MF 50V C1329 1-124-907-11 ELECT 10MF 20\(\chicksymbol{2}\) 50V C1333 1-124-477-11 ELECT 47MF 20\(\chicksymbol{2}\) 25V C1334 1-163-23-11 CERAMIC CHIP 0.01MF 50V C1338 1-163-33-11 CERAMIC CHIP 0.01MF 50V C1338 1-163-33-11 CERAMIC CHIP 0.01MF 50V C1338 1-163-33-11 CERAMIC CHIP 0.01MF 50V C1339 1-163-031-11 CERAMIC CHIP 0.01MF 50V C1340 1-163-031-11 ELECT 47MF 20\(\chicksymbol{2}\) 25V C1334 1-163-031-11 ELECT 47MF 20\(\chicksymbol{2}\) 25V C1334 1-163-031-11 ELECT 47MF 20\(\chicksymbol{2}\) 25V C1343 1-163-031-11 ELECT 47MF 20\(\chicksymbol{2}\) 25V C1343 1-163-031-11 ELECT 47MF 20\(\chicksymbol{2}\) 20V 25V C1349 1-163-031-11 ELECT 47MF 20\(\chicksymbol{2}\) 20V 25V C1349 1-163-031-11 ELECT 47MF 20\(\chicksymbol{2}\) 20V 25V 25V C1349 1-163-031-11 ELECT 47MF 20\(\chicksymbol{2}\) 20V 25V 25V 25V 25V 25V 25V 25V 25V 25V 25	C1315   -124-477-11   ELECT	Class   1-124-477-11   CRANTIC CHIP   0.01MF   20%   25%   Class   1-163-031-11   CIRANTIC CHIP   0.01MF   20%   25%   Class   1-163-031-11   CIRANTIC CHIP   0.022MF   10%   25%   Class   1-163-031-11   CIRANTIC CHIP   0.022MF   10%   25%   Class   1-163-031-11   CIRANTIC CHIP   0.022MF   10%   25%   Class   1-163-031-11   CIRANTIC CHIP   0.022MF   20%   25%   Class   1-163-031-11   CIRANTIC CHIP   0.022MF   20%   25%   Class   1-163-031-11   CIRANTIC CHIP   0.022MF   20%   25%   Class   1-163-031-11   CIRANTIC CHIP   0.01MF   20%   25%   Class   1-163-031-11   CIRANTIC CHIP   0.01MF   50%   Class   1-164-03-11   CIRANTIC CHIP   0.01MF   50%   Class   1-163-031-11   CIRANTIC CHIP   0.01MF   50%   Class   1-164-03-11   CIRANTIC CHIP   0.01MF	C1315   124-477-11   ELECT	C1315 1-124-477-11 ELECT 47MF 207 25V C1387 1-163-031-11 CERAMIC CRIP 0.01MF 207 207 25V C1387 1-163-031-11 CERAMIC CRIP 0.01MF 207 207 25V C1387 1-163-031-11 CERAMIC CRIP 0.01MF 207 25V C1387 1-163-031-11 CERAMIC	C1315 1-124-477-11 ELECT 479F 20X 25V C1386 1-165-031-11 CBRAMIC CHIP 0.01MF 10371 1-124-477-11 ELECT 479F 20X 25V C1397 1-165-031-11 CBRAMIC CHIP 0.01MF 5X C1391 1-155-031-11 CBRAMIC CHIP 0.01MF 5X C1391 1-165-031-11 CBRAMIC CHIP 0.01MF 5X C1392 1-124-907-11 ELECT 7MF 20X 25W C1392 1-124-907-11 ELECT 100MF 5X C1392 1-124-907-11 ELECT 7MF 20X 25W C1392 1-124-907-11 ELECT 7MF 20X 25W C1392 1-124-907-11 ELECT 100MF 5X C1392 1-124-907-11 ELECT 100MF 5	C1315 1-124-477-11 ELECT CIP 0.01W 50V C1316 1-163-031-11 CERANIC CRIP 0.01W 50V C1316 1-163-031-11 CERANIC CRIP 0.01W 50V C1318 1-124-477-11 ELECT 47W 20X 50V C1319 1-163-037-11 CERANIC CRIP 0.01W 5X 50V C1318 1-163-037-11 CERANIC CRIP 0.01W 5X 50V C1320 1-163-031-11 CERANIC CRIP 0.01W 5X 50V C1400 1-164-039-11 CERANIC CRIP 0.01W 5X 50V C1500 1-164-039-11 CERANIC CRIP 0.01W 5X

	Α
REMAR	K
	-

	REF.NO.	PART NO.	DESCRIPTION	REMARK	REF.NO.	PART NO.	DESCRIPTION	
<diode></diode>				D355 D360 D361	8-719-800-76 8-719-104-34 8-719-104-34	DIODE 1SS226 DIODE 1S2836 DIODE 1S2836		
	D101 D102 D103 D104 D105	8-719-800-76 8-719-800-76 8-719-045-70 8-719-800-76 8-719-800-76	DIODE 1SS226 DIODE 1SS226 DIODE 1SV230TPH3 DIODE 1SS226 DIODE 1SS226		D362 D363 D364 D365	8-719-158-40 8-719-158-40 8-719-104-34 8-719-404-46 8-719-404-46	DIODE RD10SB1 DIODE RD10SB1 DIODE 1S2836 DIODE MALLO	
	D106 D107 D108 D109 D110	8-719-901-33 8-719-800-76 8-719-901-33 8-719-801-78 8-719-404-46	DIODE 1SS133 DIODE 1SS226 DIODE 1SS133 DIODE 1SS184 DIODE MA110		D401 D404 D405 D406	8-719-404-46 8-719-800-76 8-719-801-78 8-719-404-46	DIODE MAIIO DIODE 1SS226 DIODE 1SS184 DIODE MAIIO	
	D111 D112 D113 D114 D115	8-719-977-05 8-719-404-46 8-719-159-06 8-719-404-46 8-719-977-05	DIODE DTZ6.2 DIODE MAIIO DIODE RD4.7SB-T2 DIODE MAIIO DIODE DTZ6.2		D407 D408 D410 D411 D414	8-719-404-46 8-719-404-46 8-719-404-46 8-719-801-78	DIODE MAIIO DIODE MAIIO DIODE MAIIO DIODE MAIIO DIODE 185184	
	D116 D200 D300 D301 D302	8-719-404-46 8-719-977-46 8-719-025-07 8-719-404-46 8-719-159-06	DIODE MA110 DIODE DTZ13C DIODE 1SV232-TPH3 DIODE MA110 DIODE RD4.7SB-T2		D415 D416 D417 D418 D421	8-719-801-78 8-719-801-78 8-719-801-78 8-719-801-78 8-719-404-46	DIODE 1SS184 DIODE 1SS184 DIODE 1SS184 DIODE 1SS184 DIODE MAIIO	
	D303 D304 D305 D306	8-719-977-05 8-719-801-78 8-719-800-76 8-719-104-34	DIODE DTZ6.2 DIODE 1SS184 DIODE 1SS226 DIODE 1S2836		D422 D423 D424	8-719-404-46 8-719-800-76 8-719-800-76	DIODE MAIIO DIODE 1SS226 DIODE MAIIO DIODE 1SS226	
	D307 D308 D309 D310	8-719-404-46 8-719-901-33 8-719-404-46	DIODE MAIIO  DIODE ISSI33  DIODE MAIIO		D426 D427 D500	8-719-159-06 8-719-404-46 8-719-404-46	DIODE RD4.7SB-T2 DIODE MAIIO DIODE MAIIO	
	D311 D313 D314	8-719-045-70 8-719-801-78	DIODE 1SV230TPH3 DIODE 1SS184  DIODE MAIIO	1,	D502 D503 D504 D505	8-719-977-03 8-719-979-80 8-719-404-46 8-719-901-83 8-719-028-72	DIODE UF5406 DIODE MAI10 DIODE 1SS83 DIODE RGP02-17EL-6433	
	D315 D317 D318 D319	8-719-404-46 8-719-404-46 8-719-800-76 8-719-800-76	DIODE MAITO DIODE MAITO DIODE 1SS226 DIODE 1SS226	e <sup>r</sup>	D506 D507 D508 D509	8-719-945-80 8-719-800-76 8-719-800-76 8-719-404-46	DIODE ERCO6-15S DIODE 1SS226 DIODE 1SS226 DIODE MA110	
	D320 D322 D323 D324 D325	8-719-404-46 8-719-404-46 8-719-045-70 8-719-801-78	DIODE MAITO DIODE MAITO DIODE MAITO DIODE 1SV230TPH3 DIODE 1SS184		D512 D513 D514	8-719-302-43 8-719-979-80 8-719-404-46 8-719-971-20	DIODE UF5406 DIODE MALIO DIODE ERC38-06 DIODE ERC38-06	1+
	D326 D327 D332 D333	8-719-045-70 8-719-104-34 8-719-404-46 8-719-404-46	DIODE 1SV230TPH3 DIODE 1S2836 DIODE MA110 DIODE MA110		D516 D517 D518	8-719-404-46 8-719-404-46 8-719-404-46	DIODE MA110 DIODE MA110 DIODE MA110	
	D335 D336 D337 D338	8-719-404-46 8-719-404-46 8-719-404-46 8-719-404-46	DIODE MA110 DIODE MA110 DIODE MA110 DIODE MA110	-	D519 D520 D521 D522	8-719-404-46 8-719-801-78 8-719-901-33 8-719-977-05	DIODE MAILO DIODE 1SS184 DIODE 1SS133 DIODE DTZ6.2	
	D339 D341 D344 D345	8-719-404-46 8-719-159-06 8-719-801-78 8-719-104-34	DIODE MA110 DIODE RD4.7SB-T2 DIODE 1SS184 DIODE 1S2836		D523 D524 D525 D526	8-719-404-46 8-719-200-02 8-719-200-02 8-719-404-46	DIODE MA110 DIODE 10E-2 DIODE 10E-2 DIODE MA110	
	D346 D347 D348	8-719-104-34 8-719-104-34 8-719-800-76 8-719-800-76	DIODE 1S2836 DIODE 1S2836 DIODE 1SS226 DIODE 1SS226		D527 D528 D529 D530 D531	8-719-200-02 8-719-300-76 8-719-200-02 8-719-300-76 8-719-977-32	DIODE 10E-2 DIODE RH-1A DIODE 10E-2 DIODE RH-1A DIODE DTZ11B	
	D350 D351 D352 D353	8-719-800-76 8-719-800-76 8-719-800-76 8-719-800-76	DIODE 1SS226 DIODE 1SS226 DIODE 1SS226 DIODE 1SS226		D532 D533 D534 D535	8-719-800-76 8-719-302-43 8-719-404-46 8-719-404-46	DIODE 1SS226 DIODE EL12 DIODE MAIIO DIODE MAIIO	
	D354	8-719-800-76	DIODE 1SS226		D536	8-719-800-76	DIODE 1SS226	



The components identified by shading and mark A are critical for safety.

Replace only with part number specified.

REF.NO.	PART NO.	DESCRIPTION	REMARK	REF.NO.	PART NO.	DESCRIPTION		REMARK
D537 D538 D539 D540 D541	8-719-800-76 8-719-404-46 8-719-404-46 8-719-801-78	DIODE 1SS226 DIODE MA110 DIODE MA110 DIODE MA110 DIODE 1SS184  DIODE 1SS133  AY LINE> DELAY LINE, Y DELAY LINE, Y DELAY LINE, Y DELAY LINE	•	IC410 IC411 IC412 IC413	8-759-509-19	IC BU4052BCF IC MC14024BF IC XRU4053BCF- IC XRU4053BCF-	E2 E2	
DL300 DL301	<del 1-415-633-11 1-415-632-11</del 	AY LINE> DELAY LINE, Y DELAY LINE, Y		IC500 IC502 IC503 IC504 IC505 IC506	8-759-009-51	IC H8D7249  IC MC14538BF IC MC14538BF IC CXA1211M IC XRA17812T IC MC14538BF		
FL300	1-409-547-11 <fil 1-236-547-11</fil 	TER>		IC507 IC508	8-759-100-60 8-752-053-21	IC UPC1377C IC CXA1211M IC LM358D IC MC14538BF	4	
FL401	1-236-364-11	FILTER, BAND PASS		 	<01	L>		
10102 10103 10104	8-759-168-37 8-759-008-48	IC UPD78013YCW-Y03		L101 L102 L104 L105 L300	1-408-609-41 1-408-417-00 1-408-425-00 1-410-482-31 1-410-478-11	INDUCTOR INDUCTOR INDUCTOR INDUCTOR INDUCTOR	33UH 47UH 220UH 100UH 47UH	
IC105 IC106 IC107 IC108	8-759-196-70 8-759-196-70 8-759-196-70 8-759-042-02 8-759-196-70	IC M62358FP-E1 IC M62358FP-E1 IC M62358FP-E1 IC S-80743AL-A7-S IC M62358FP-E1		L301 L302 L303 L304 L305	1-408-411-00 1-412-008-31 1-408-416-00 1-412-008-31 1-410-196-11	INDUCTOR INDUCTOR CHIP INDUCTOR INDUCTOR CHIP INDUCTOR CHIP	150H 150H 39UH 150H 2.2UH	
IC111 IC200 IC301 IC302	8-759-009-22 8-759-420-04 8-752-053-21 8-759-998-98	IC CXA1211M IC LM358D	!	L306 L307 L308 L309 L311	1-408-416-00 1-408-411-00 1-410-466-41 1-410-470-11 1-410-470-11	INDUCTOR INDUCTOR INDUCTOR INDUCTOR INDUCTOR	39VH 15VH 4.7VH 10VH 10VH	
1C304 1C305 1C306 1C309	8-759-509-19 8-759-631-08 8-759-711-32 8-759-711-32	IC CXA1214P  IC XRU4053BCF-E2 IC M51279FP IC NJM2245M IC NJM2245M		L312 L314 L316 L317 L319	1-412-011-31 1-412-011-31 1-412-011-31 1-410-090-41 1-408-421-00	INDUCTOR CHIP INDUCTOR CHIP INDUCTOR CHIP INDUCTOR INDUCTOR	270H 270H 270H 18MMH 1000H	
IC311 IC312 IC313 IC314	8-759-509-05 8-759-711-32 8-759-501-21 8-759-501-21	IC XRU4053BCF-E2  IC XRU4066BCF IC NJM2245M IC MM1149XF IC MM1149XF		L320 L401 L402 L403 L404	1-410-215-31	INDUCTOR INDUCTOR INDUCTOR CHIP INDUCTOR CHIP INDUCTOR CHIP	470H 470H 820H 820H 82UH	
1C316 1C317 1C318 1C320	8-759-048-09 8-759-009-51 8-759-509-57 8-759-501-21	IC MM1148XF IC MC14538BF IC XRU4584BF IC MM1149XF		L405 L406 L407 L408 L409	1-408-419-00 1-408-419-00 1-408-413-00 1-408-413-00 1-410-215-31		68UH 68UH 22UH 22UH 82UH	
1C322 1C323 1C324 1C325	8-759-501-21 8-759-501-21 8-759-501-21 8-759-501-21 8-759-501-21	IC MM1149XF IC MM1149XF IC MM1149XF IC MM1149XF IC MM1149XF		L500 L501 L502 L503 L504	1-459-155-00 1-407-365-00 1-407-365-00 1-410-093-11 1-410-666-31	COIL (WITH CORI COIL, CHOKE COIL, CHOKE INDUCTOR INDUCTOR	33MMH 18UH	
1C350 1C401 1C402 1C403	8-759-060-00 8-759-100-96 8-759-196-69 8-752-053-21 8-759-509-05	IC BA10324AF  IC UPC4558G2 IC BA7655AF-E2 IC CXA1211M IC XRU4066BCF		L505 L506 L507 L508 L509	1-410-671-31 1-459-104-00 1-410-686-11 1-412-530-31 1-459-087-00	INDUCTOR COIL, DUST CORNINDUCTOR INDUCTOR COIL, HCC DUST	1MMH 27UH CORE 3.9MMH	
I C405 I C406 I C407	8-752-052-62 8-759-509-19 8-759-998-98 8-759-509-05 8-759-509-91	IC CXA1478S  IC XRU4053BCF-E2 IC LM358D IC XRU4066BCF IC XRA10393F		L510 A L512 A L513 L514 L515	1-412-447-11 1-459-104-00	COIL, DUST CORE COIL, CORE INDUCTOR COIL, DUST CORE COIL, DUST CORE	3.9MMH	

	A
REMAR	K

REF.NO.	PART NO.	DESCRIPTION		REMARK	REF.NO.	PART NO.	DESCRIPTIO	DŃ 
L517	1-412-547-21 <neo< td=""><td>INDUCTOR 680UH</td><td></td><td></td><td>Q342 Q343 Q345 Q346</td><td>8-729-920-39 8-729-920-39 8-729-120-28 8-729-120-28 8-729-901-01</td><td>TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR</td><td>IMT1US IMT1US 2SC1623-L5L6 2SC1623-L5L6</td></neo<>	INDUCTOR 680UH			Q342 Q343 Q345 Q346	8-729-920-39 8-729-920-39 8-729-120-28 8-729-120-28 8-729-901-01	TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR	IMT1US IMT1US 2SC1623-L5L6 2SC1623-L5L6
NL5UU	1-519-526-11	LAMP, NEON			Q348 Q349	8-729-216-22 8-729-216-22	TRANSISTOR TRANSISTOR	2SA1162-G
Q101	<tra 8-729-901-01</tra 	NSISTUR> TRANSISTOR DTC144EK			Q350 Q351 Q352	8-729-216-22 8-729-120-28 8-729-120-28		2SA1162-G 2SC1623-L5L6 2SC1623-L5L6
Q102 Q103 Q104 Q105	8-729-216-22 8-729-216-22 8-729-907-26 8-729-901-06	LAMP, NEON  NSISTOR>  TRANSISTOR DTC144EK TRANSISTOR ZSA1162-G TRANSISTOR ZSA1162-G TRANSISTOR DTA144EK  TRANSISTOR DTA144EK  TRANSISTOR DTA144EK  TRANSISTOR DTA144EK  TRANSISTOR ZSC1623-L5L6			Q353 Q354 Q355 Q356	8-729-120-28 8-729-120-28 8-729-120-28 8-729-901-01	TRANSISTOR TRANSISTOR TRANSISTOR	2SC1623-L5L6 2SC1623-L5L6 2SC1623-L5L6 DTC144EK
Q107 Q108 Q109 Q110 Q111	8-729-901-06 8-729-120-28 8-729-120-28 8-729-120-28 8-729-901-06	TRANSISTOR DTA144EK TRANSISTOR 2SC1623-L5L6 TRANSISTOR 2SC1623-L5L6 TRANSISTOR 2SC1623-L5L6 TRANSISTOR DTA144EK			Q357 Q358 Q359 Q360	8-729-120-28 8-729-120-28 8-729-216-22 8-729-907-26	TRANSISTOR TRANSISTOR TRANSISTOR	IMX1
Q112 Q113	8-729-120-28 8-729-120-28	TRANSISTOR 2SC1623-L5L6 TRANSISTOR 2SC1623-L5L6			Q361 Q362	8-729-901-06 8-729-120-28	TRANSISTOR TRANSISTOR	DTA144EK 2SC1623-L5L6
Q114 Q200 Q201 Q300	8-729-119-78 8-729-140-96 8-729-120-28 8-729-120-28	TRANSISTOR 2SC2785-HFE TRANSISTOR 2SD774-34 TRANSISTOR 2SC1623-L5L6 TRANSISTOR 2SC1623-L5L6			0363 0364 0365 0366	8-729-120-28 8-729-901-01 8-729-901-01 8-729-216-22 8-729-216-22	TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR	DTC144EK 2SA1162-G
Q301 Q302 Q303	8-729-120-28 8-729-216-22 8-729-120-28 8-729-120-28	TRANSISTOR 25C1623-L5L6 TRANSISTOR 25A1162-G TRANSISTOR 25C1623-L5L6 TRANSISTOR 25C1623-L5L6			Q368 Q369 Q372	8-729-216-22 8-729-901-06	TRANSISTOR	2SA1162-G DTA144EK DTC144EK
Q305 Q306 Q307	8-729-120-28 8-729-120-28 8-729-120-28	TRANSISTOR 2SC1623-L5L6 TRANSISTOR 2SC1623-L5L6 TRANSISTOR 2SC1623-L5L6			Q374	8-729-216-22 8-729-216-22	TRANSISTOR	2SA1162-G
Q308 Q309	8-729-120-28 8-729-216-22	TRANSISTOR 2SC1623-L5L6 TRANSISTOR 2SA1162-G			Q376 Q377 Q378	8-729-901-01 8-729-901-06 8-729-901-01	TRANSISTOR TRANSISTOR TRANSISTOR	DTC144EK DTA144EK
Q310 Q311 Q312 Q313 Q314	8-729-216-22 8-729-216-22 8-729-120-28 8-729-216-22 8-729-901-06	TRANSISTOR 2SC1623-L5L6 TRANSISTOR 2SC1623-L5L6 TRANSISTOR 2SC1623-L5L6 TRANSISTOR 2SC1623-L5L6 TRANSISTOR 2SC1623-L5L6 TRANSISTOR 2SA1162-G TRANSISTOR 2SA1162-G TRANSISTOR 2SA1162-G TRANSISTOR 2SC1623-L5L6 TRANSISTOR 2SA1162-G TRANSISTOR 2SA1162-G TRANSISTOR 2SA1162-G TRANSISTOR 2SA1162-G TRANSISTOR 2SA1162-G TRANSISTOR 2SA1162-G TRANSISTOR 2SC1623-L5L6 TRANSISTOR 2SC1623-L5L6 TRANSISTOR 2SC1623-L5L6 TRANSISTOR 2SC1623-L5L6 TRANSISTOR 2SC1623-L5L6			Q401 Q402 Q403	8-729-120-28 8-729-120-28 8-729-901-01 8-729-216-22	TRANSISTOR	2SC1623-L5L6 2SC1623-L5L6 DTC144EK
Q315 Q316	8-729-216-22 8-729-130-28	TRANSISTOR 2SA1162-G			Q405 Q406	8-729-216-22 8-729-120-28	TRANSISTOR	
Q318 Q319 Q320	8-729-110-28 8-729-120-28 8-729-119-78	TRANSISTOR 25C1023-L5L6 TRANSISTOR 25C1623-L5L6 TRANSISTOR 25C2785-HFE	•		Q407 Q408 Q409 Q410	8-729-120-28 8-729-216-22 8-729-216-22 8-729-907-26	TRANSISTOR TRANSISTOR TRANSISTOR	2SA1162-G IMX1
Q321 Q322 Q323 Q324	8-729-120-28 8-729-120-28 8-729-901-01	TRANSISTER 2501623-1516			í	8-729-120-28 8-729-216-22	TRANSISTOR	2SC1623-L5L6 2SA1162-G
Q324 Q325	8-729-901-01	TRANSISTOR DTC144EK TRANSISTOR DTC144EK TRANSISTOR 2SC1623-L5L6			Q412 Q413 Q414 Q415	8-729-141-53 8-729-216-22 8-729-216-22	TRANSISTOR TRANSISTOR TRANSISTOR	2SK94-X2X3X4 2SA1162-G
Q326 Q327 Q328	8-729-120-28 8-729-216-22 8-729-141-53	TRANSISTOR 2SC1623-L5L6 TRANSISTOR 2SA1162-G TRANSISTOR 2SK94-X2X3X4			Q416 Q417	8-729-216-22 8-729-216-22	TRANSISTOR TRANSISTOR	2SA1162-G 2SA1162-G
0329 0330	8-729-141-53 8-729-216-22	TRANSISTOR 2SK94-X2X3X4 TRANSISTOR 2SA1162-G			Q418 Q419 Q420	8-729-120-28 8-729-216-22 8-729-216-22	TRANSISTOR TRANSISTOR TRANSISTOR	2SC1623-L5L6 2SA1162-G
Q331 Q332 Q333	8-729-216-22 8-729-901-01 8-729-120-28	TRANSISTOR 2SA1162-G TRANSISTOR DTC144EK TRANSISTOR 2SC1623-L5L6			Q421 Q422	8-729-901-01 8-729-120-28	TRANSISTOR	
Q334 Q335	8-729-216-22 8-729-120-28	TRANSISTOR 2SA1162-G TRANSISTOR 2SC1623-L5L6			Q423 Q424 Q425	8-729-120-28 8-729-901-01 8-729-901-01	TRANSISTOR TRANSISTOR TRANSISTOR	2SC1623-L5L6 DTC144EK DTC144EK
Q336 Q337 Q338	8-729-109-44 8-729-120-28 8-729-120-28	TRANSISTOR 2SK94-X4 TRANSISTOR 2SC1623-L5L6 TRANSISTOR 2SC1623-L5L6			Q426 Q428	8-729-901-01 8-729-216-22	TRANSISTOR TRANSISTOR	DTC144EK 2SA1162-G
Q339 Q341	8-729-216-22 8-729-920-39	TRANSISTOR 2SC1623-L5L6 TRANSISTOR 2SC1623-L5L6 TRANSISTOR 2SC1623-L5L6 TRANSISTOR 2SK94-X2X3X4 TRANSISTOR 2SK94-X2X3X4 TRANSISTOR 2SA1162-G TRANSISTOR 2SA1162-G TRANSISTOR 2SC1623-L5L6 TRANSISTOR 1MT1US			Q429 Q430 Q431	8-729-216-22 8-729-120-28 8-729-120-28	TRANSISTOR TRANSISTOR	2SA1162-G 2SC1623-L5L6 2SC1623-L5L6

4											
	REF.NO.	PART NO.	DESCRIPTION	REMARK	REF.NO.	PART NO.	DESCRIPTION				REMARK
	Q432 Q433 Q434 Q435 Q436	8-729-120-28 8-729-901-01 8-729-120-28 8-729-901-01	TRANSISTOR 2SC1623-L5L6 TRANSISTOR DTC144EK TRANSISTOR DTC14EK TRANSISTOR DTC14AEK TRANSISTOR DTC14AEK		R120 R121 R122	1-216-295-00 1-216-295-00 1-216-295-00	METAL GLAZE METAL GLAZE METAL GLAZE			1/10W 1/10W 1/10W 1/10W	
	Q436 Q437 Q438 Q439 Q440	8-729-901-01 8-729-120-28 8-729-216-22 8-729-120-28	TRANSISTOR DTC144EK TRANSISTOR 2SC1623-L5L6 TRANSISTOR 2SA1162-G TRANSISTOR 2SC1623-L5L6		R124 R125 R126 R127	1-216-295-00 1-216-295-00 1-216-295-00 1-216-295-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE			1/10W 1/10W 1/10W 1/10W	
	Q441 Q442 Q443 Q444 Q445	8-729-141-53 8-729-120-28 8-729-216-22 8-729-120-28 8-729-901-01	TRANSISTOR DTC144EK TRANSISTOR DTC144EK TRANSISTOR DTC144EK TRANSISTOR DTC144EK TRANSISTOR DTC144EK TRANSISTOR DTC144EK TRANSISTOR ZSC1623-L5L6		R128 R129 R130 R131 R132	1-216-295-00 1-216-295-00 1-216-099-00 1-216-295-00 1-216-065-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	0 0 120K 0 4.7K		1/10W 1/10W 1/10W 1/10W 1/10W	
	Q500 Q501 Q502 Q503	8-729-216-22 8-729-800-35 8-729-119-80 8-729-313-42	TRANSISTOR 2SC1623-L5L6 TRANSISTOR DTC144EK TRANSISTOR 2SA1162-G  TRANSISTOR 2SD1397-CA TRANSISTOR 2SC2688-L TRANSISTOR 2SD1134-C TRANSISTOR 2SC1623-L5L6 TRANSISTOR 2SC1623-L5L6		R133 R134 R135 R136 R137	1-216-091-00 1-216-065-00 1-216-085-00 1-216-295-00 1-216-065-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	56K 4.7K 33K 0 4.7K	5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W	
	9505 9506 9507 9508 9509	8-729-120-28 8-729-120-28 8-729-120-28 8-729-216-22 8-729-901-06	TRANSISTOR 2SD1397-CA TRANSISTOR 2SC2688-L TRANSISTOR 2SC1623-L5L6 TRANSISTOR 2SC1623-L5L6 TRANSISTOR 2SC1623-L5L6 TRANSISTOR 2SC1623-L5L6 TRANSISTOR 2SC1623-L5L6 TRANSISTOR DTA144EK TRANSISTOR DTC144EK TRANSISTOR 2SC2958-L TRANSISTOR 2SC2958-L TRANSISTOR DTC124EK TRANSISTOR 2SC2690A-Q TRANSISTOR 2SC2690A-Q TRANSISTOR 2SC2690A-Q TRANSISTOR DTC124EK TRANSISTOR DTC144EK TRANSISTOR 2SC1623-L5L6 TRANSISTOR 2SC1623-L5L6 TRANSISTOR 2SC1623-L5L6 TRANSISTOR 2SC1623-L5L6 TRANSISTOR 2SC1623-L5L6 TRANSISTOR 2SC1623-L5L6		R138 R139 R140 R141 R142	1-216-295-00 1-216-295-00 1-216-033-00 1-216-085-00 1-216-295-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	0 0 220 33K 0	5%	1/10W 1/10W 1/10W 1/10W 1/10W	
	Q510 Q511 Q512 Q513	8-729-900-89 8-729-120-28 8-729-195-82 8-729-122-03	TRANSISTOR DTC144ES TRANSISTOR 2SC1623-L5L6 TRANSISTOR 2SC2958-L TRANSISTOR 2SA1220A-P TRANSISTOR DTC34EV		R143 R144 R145 R147	1-216-295-00 1-216-295-00 1-216-295-00 1-216-295-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE		5%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%	1/10W 1/10W 1/10W 1/10W 1/10W	
	Q514 Q515 Q517 Q518 Q519	8-729-901-00 8-729-169-02 8-729-901-06 8-729-901-01 8-729-901-01	TRANSISTOR DTC124EK TRANSISTOR ZSC2690A-Q TRANSISTOR DTA144EK TRANSISTOR DTC144EK TRANSISTOR DTC144EK		R149 R150 R151 R152	1-216-065-00 1-216-295-00 1-216-061-00 1-216-295-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	4.7K 0 3.3K 0		1/10W 1/10W 1/10W 1/10W	
	Q520 Q522 Q523 Q524	8-729-905-67 8-729-120-28 8-729-120-28 8-729-119-78	TRANSISTOR 2SD1944-K TRANSISTOR 2SC1623-L5L6 TRANSISTOR 2SC1623-L5L6 TRANSISTOR 2SC2785-HFE		R153 R154 R155 R156	1-216-295-00 1-216-065-00 1-249-434-11 1-216-295-00	METAL GLAZE METAL GLAZE CARBON METAL GLAZE	0 4.7K 27K 0 4.7K 0		1/10W 1/10W 1/4W 1/10W	
	Q525 Q526 Q527	8-729-119-76 8-729-216-22 8-729-120-28	TRANSISTOR 2SA1175-HFE TRANSISTOR 2SA1162-G TRANSISTOR 2SC1623-L5L6		R157 R158 R159 R160 R162	1-216-065-00 1-216-295-00 1-216-063-00 1-216-061-00 1-216-065-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	4.7K 0 3.9K 3.3K 4.7K		1/10W 1/10W 1/10W 1/10W 1/10W	
	JR122 JR123 JR302	1-216-295-00 1-216-295-00 1-216-295-00 1-216-025-00	ISTOR>  METAL GLAZE 0 5% 1/10 METAL GLAZE 0 5% 1/10 METAL GLAZE 0 5% 1/10 METAL GLAZE 100 5% 1/10 METAL GLAZE 100 5% 1/10	DW DW	R163 R164 R165 R167	1-216-065-00 1-216-065-00 1-216-067-00 1-216-295-00 1-216-061-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	4.7K 5.6K 0 3.3K	5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W	
	R101 R102 R103 R104 R105	1-216-025-00 1-216-025-00 1-216-073-00 1-216-059-00	METAL GLAZE 100 5% 1/10 METAL GLAZE 10K 5% 1/10 METAL GLAZE 2.7K 5% 1/10	OW OW	R168 R169 R170	1-216-085-00 1-216-107-00 1-216-295-00 1-216-031-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	33K 270K 0	5%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%	1/10W 1/10W 1/10W 1/10W	
	R106 R107 R108 R109	1-216-065-00 1-216-065-00 1-216-065-00 1-216-065-00	METAL GLAZE 4.7K 5% 1/10	OW OW OW	R172 R173 R174 R175	1-216-295-00 1-216-295-00 1-216-295-00 1-216-295-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	0 0 0 0	5%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%	1/10W 1/10W 1/10W 1/10W	
	R110 R111 R112 R113	1-216-073-00 1-216-295-00 1-216-295-00 1-216-085-00	METAL GLAZE 10K 5% 1/16 METAL GLAZE 0 5% 1/16 METAL GLAZE 0 5% 1/16 METAL GLAZE 33K 5% 1/16	OW OW	R177 R180 R181 R183 R184	1-216-065-00 1-216-295-00 1-216-065-00 1-216-295-00 1-216-649-11	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL CHIP	4.7K 0 4.7K 0 820	5% 5% 5% 5% 0.50%	1/10W 1/10W 1/10W 1/10W 1/10W	
	R114 R115 R116 R117	1-216-295-00 1-216-295-00 1-218-761-11 1-216-089-91 1-216-295-00	METAL GLAZE 0 5% 1/10 METAL CHIP 240K 0.50% 1/10 METAL GLAZE 47K 5% 1/10	OW OW OW	R185 R186 R187 R188 R188	1-216-073-00 1-216-295-00 1-216-061-00 1-216-295-00 1-216-073-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	10K 0 3.3K 0 10K	5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W	
	R119	1-216-689-11	METAL GLAZE 0 5% 1/10 METAL GLAZE 39K 5% 1/10	ŎŴ	1.107	0 015 00					100

A

REF.NO.	PART NO.	DESCRIPTION				REMARK	REF.NO.	PART NO.	DESCRIPTION				REMARK
R190 R192 R193 R194 R195	1-216-049-00 1-216-073-00 1-216-295-00 1-216-295-00 1-216-071-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	1K 10K 0 0 8.2K	5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W		R347 R348 R349 R350 R351	1-216-065-00 1-216-031-00 1-216-694-11 1-216-085-00	METAL GLAZE METAL CHIP METAL GLAZE METAL GLAZE METAL GLAZE	4.7K 180 62K 33K 3.3K	5% 0.50% 5%	1/10W 1/10W 1/10W 1/10W 1/10W	
R197 R198 R199 R200 R201	1-216-061-00 1-216-295-00 1-216-295-00 1-216-686-11 1-216-049-00	METAL GLAZE METAL CHIP METAL GLAZE	3.3K 0 0 30K 1K	5% 0.50% 5%	1/10W 1/10W 1/10W 1/10W 1/10W		R352	1-216-061-00 1-216-675-11 1-216-049-00 1-247-901-11 1-216-059-00 1-216-689-11	METAL CHIP	10K 1K 820K 2.7K 39K	5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W	
R202 R203 R204 R205 R206	1-212-857-00 1-260-095-11 1-260-072-11 1-216-647-11 1-216-073-00	FUSIBLE CARBON CARBON METAL CHIP METAL GLAZE	10K	0.50% 5%	1/4W 1/2W 1/2W 1/10W 1/10W		į	1-216-121-00 1-216-053-00 1-216-065-00 1-216-039-00 1-216-017-00	METAL GLAZE	1.5K 4.7K 390 47 5.6K	5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W	
R207 R208 R209 R210 R211	1-216-065-00 1-216-065-00 1-216-073-00 1-216-061-00 1-249-393-11	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE CARBON	4.7K 4.7K 10K 3.3K 10	5%	1/10W 1/10W 1/4W		R363 R364 R366 R367	1-216-067-00 1-216-113-00 1-216-113-00 1-216-065-00 1-216-051-00	METAL GLAZE	5.6K 470K 470K 4.7K 1.2K 1.K		1/10W 1/10W 1/10W 1/10W 1/10W	
R237 R301 R302 R303 R304	1-216-089-91 1-216-025-00 1-216-025-00 1-216-025-00 1-216-025-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	47K 100 100 100 100		1/10W 1/10W 1/10W 1/10W 1/10W		R368 R371 R372 R373 R374 R375	1-216-049-00 1-216-069-00 1-216-053-00 1-216-645-11 1-216-647-11	METAL CHIP	6.8K 1.5K	5%	1/10W 1/10W 1/10W	
R305 R306 R307 R308 R311	1-216-295-00 1-216-295-00 1-216-115-00 1-216-065-00 1-216-055-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	0 0 560K 4.7K 1.8K		1/10W 1/10W 1/10W 1/10W 1/10W		R376 R378 R379 R380	1-216-053-00 1-216-111-00 1-216-111-00 1-216-069-00 1-216-065-00	METAL GLAZE METAL GLAZE	390K 390K 6.8K 4.7K 39K		1/10W 1/10W 1/10W 1/10W	
R312 R313 R314 R315 R316	1-216-073-00 1-216-649-11 1-216-099-00 1-216-099-00 1-216-049-00	METAL GLAZE METAL CHIP METAL GLAZE METAL GLAZE METAL GLAZE	820 120K 120K 1K	0.50% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W		R381 R382 R383 R384 R385	1-216-689-11 1-216-107-00 1-216-061-00 1-216-073-00 1-216-065-00	METAL GLAZE METAL GLAZE METAL GLAZE	39K 270K 3.3K 10K 4.7K 56K	5%	1/10W 1/10W 1/10W 1/10W 1/10W	
R317 R318 R319 R320 R321	1-216-057-00 1-216-049-00 1-216-069-00 1-216-057-00 1-216-051-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	2.2K 1K 6.8K 2.2K 1.2K		1/10W 1/10W 1/10W 1/10W 1/10W		R386 R387 R388 R389 R390	1-249-438-11 1-216-029-00 1-216-033-00 1-216-645-11 1-249-393-11	METAL CHIP CARBON	150 220	5% 5% 0.50%	1/4W	F
R322 R323 R324 R325 R326	1-216-035-00 1-216-109-00 1-216-101-00 1-216-037-00 1-216-033-00	METAL GLAZE	270 330K 150K 330 220	5%	1/10W 1/10W 1/10W 1/10W 1/10W		R391 R393 R394 R395 R396	1-216-113-00 1-216-073-00 1-216-083-00 1-216-647-11 1-216-113-00	METAL CHIP METAL GLAZE	10K 27K 680 470K		1/10W	
R328 R329 R330 R331 R332	1-216-121-00 1-216-055-00 1-216-089-91 1-216-093-00 1-216-097-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	1M 1.8K 47K 68K 100K	5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W		R397 R398 R399 R401 R402	1-216-113-00 1-216-105-00 1-216-111-00 1-216-053-00 1-216-053-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	470K 220K 390K 1.5K 1.5K	5% 5%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%	1/10W 1/10W 1/10W 1/10W 1/10W	
R333 R334 R335 R336 R337	1-216-097-00 1-216-093-00 1-216-083-00 1-216-065-00 1-216-073-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	100K 68K 27K 4.7K 10K	5% 5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W		R403 R404 R405 R406 R407	1-216-069-00 1-216-029-00 1-216-121-00 1-216-083-00 1-216-085-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	6.8K 150 1M 27K 33K	5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W	
R338 R339 R340 R341 R342	1-216-091-00 1-216-071-00 1-216-089-91 1-216-673-11 1-216-065-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL CHIP METAL GLAZE	56K 8.2K 47K 8.2K 4.7K	5%	1/10W 1/10W 1/10W 1/10W 1/10W		R408 R410 R411 R412 R413	1-216-689-11 1-216-069-00 1-216-033-00 1-216-089-91	METAL CHIP METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	39K 6.8K 220 47K 1M	0.50% 5% 5% 5% 5%	1/10W 1/10W 1/10W	
R343 R344 R345 R346	1-216-095-00 1-216-099-00 1-216-063-00 1-216-057-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	82K 120K 3.9K 2.2K	5% 5% 5%	1/10W 1/10W 1/10W 1/10W		R414 R416 R417	1-216-121-00 1-216-073-00 1-216-113-00 1-216-665-11	METAL GLAZE METAL GLAZE METAL CHIP	10K 470K	5% 5% 0.50%	1/10W 1/10W 1/10W 1/10W	

-	ŀ
Λ	l
	l

 REF.NO.	PART NO.	DESCRIPTION				REMARK	REF.NO.	PART NO.	DESCRIPTION				REMARK	
R418 R420 R422 R423 R424	1-216-667-11 1-216-105-00 1-216-073-00 1-216-073-00 1-216-033-00	METAL CHIP METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	220K 10K 10K 220		1/10W 1/10W 1/10W 1/10W 1/10W		R488 R489 R490 R491 R492	1-216-073-00 1-216-077-00 1-216-057-00 1-216-063-00 1-216-085-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	10K 15K 2.2K 3.9K 33K	5%	1/10W 1/10W 1/10W 1/10W 1/10W		
R425 R426 R427 R428 R429	1-216-049-00 1-216-039-00 1-216-033-00 1-216-097-00 1-216-073-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	1K 390 220 100K 10K		1/10W 1/10W 1/10W 1/10W 1/10W		R494 R495 R496 R497	1-216-295-00	METAL GLAZE METAL GLAZE METAL CHIP METAL GLAZE METAL CHIP	0 33K 1K - 10K	5% 5% 5% 0.50% 5% 0.50%	1/10W 1/10W 1/10W 1/10W		
R430 R431 R432 R434 R435	1-216-119-00 1-216-097-00 1-216-089-91 1-216-109-00 1-216-105-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	820K 100K 47K 330K 220K		1/10W 1/10W 1/10W 1/10W 1/10W		R498 R499 R500 R501 R502	1-216-063-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL CHIP	3.9K 220 39K 15K 12K	5% 5% 5%	1/10W 1/10W 1/10W 1/10W		
R436 R437 R438 R439 R440	1-216-113-00 1-216-097-00 1-216-053-00 1-216-033-00 1-216-049-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	470K 100K 1.5K 220 1K	5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W		R503 R504 R505	1-216-677-11 1-216-111-00 1-216-067-00 1-216-073-00 1-216-083-00	METAL CHIP	390K 5.6K 10K 27K 220K	0.50%	1/10W 1/10W 1/10W 1/10W 1/10W		
R441 R442 R443 R444 R445	1-216-645-11 1-216-647-11 1-216-049-00 1-216-105-00 1-216-095-00	METAL CHIP METAL CHIP METAL GLAZE METAL GLAZE METAL GLAZE	680 1 K 220 K 82 K				R508 R509 R510 R511 R512	1-216-105-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	220K 47K 100K 120K 1.8K 0		1/10W 1/10W 1/10W 1/10W 1/10W		
R447 R448 R449 R450 R451	1-216-069-00 1-216-049-00 1-216-073-00 1-216-121-00 1-216-037-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	6.8K 1K 10K 1M 330	5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W		R513 R514 R515 R516 R517	1-216-295-00	METAL GLAZE METAL GLAZE	0 10K 100K 20K 100K	5% 0.50%	1/10W 1/10W 1/10W 1/10W 1/2W		
R452 R453 R455 R456 R457	1-216-651-11 1-216-097-00 1-216-085-00 1-216-053-00 1-216-025-00	METAL CHIP METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	100K 33K 1.5K 100		1/10W 1/10W 1/10W 1/10W 1/10W		R518 R519 R520 R521 R522	1-216-017-00 1-249-423-11 1-216-065-00 1-260-111-11	METAL GLAZE CARBON	100K 47 3.3K 4.7K 10K 1K		1/2W 1/10W 1/4W 1/10W 1/2W	<b>F</b> .	
R458 R459 R460 R462 R463	1-216-113-00 1-216-649-11 1-216-073-00 1-216-651-11 1-216-063-00	METAL GLAZE METAL CHIP METAL GLAZE METAL CHIP METAL GLAZE	10K 1K 3.9K	0.50% 5% 0.50% 5%	1/10W 1/10W 1/10W		R523 R524 R525 R526 R527	1-215-892-11 1-216-093-00 1-216-069-00 1-216-089-91 1-216-089-91	METAL OXIDE  METAL GLAZE  METAL GLAZE  METAL GLAZE  METAL GLAZE	68K 6.8K 47K 47K	5%	2W 1/10W 1/10W 1/10W 1/10W	F	
R464 R465 R466 R467 R468	1-216-065-00 1-216-025-00 1-216-077-00 1-216-121-00 1-216-105-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	4.7K 100 15K 1M 220K	5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W		R528 R529 R530 R531 R531 R532	1-216-089-91 1-216-089-91 1-216-367-11 1-216-077-00 1-216-478-11	METAL GLAZE METAL GLAZE	47K 47K 0.68 15K 390	5% 5% 5%	1/10W 1/10W 2W 1/10W 3W	F F	
R469 R470 R471 R472 R473	1-216-063-00 1-216-069-00 1-216-109-00 1-216-077-00 1-216-121-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	3.9K 6.8K 330K 15K 1M	5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W		R533 R534 R535 R536 R537	1-247-723-11 1-216-085-00 1-249-448-11 1-216-101-00 1-216-089-91	CARBON METAL GLAZE CARBON METAL GLAZE METAL GLAZE	6.8K 33K 1.2 150K 47K	5% 5% 5% 5% 5%	1/4W 1/10W 1/4W 1/10W 1/10W		
R474 R475 R476 R477 R478	1-216-649-11 1-216-025-00 1-216-061-00 1-216-061-00 1-216-073-00	METAL CHIP METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	820 100 3.3K 3.3K 10K	0.50% 5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W		R539 R540 R541 R542 R543	1-216-065-00 1-216-113-00 1-249-383-11 1-216-057-00 1-212-883-00	METAL GLAZE  METAL GLAZE  CARBON  METAL GLAZE  FUSIBLE	4.7K 470K 1.5 2.2K 120	5% 5% 5% 5% 5%	1/10W 1/10W 1/4W 1/10W 1/4W		
R479 R480 R481 R482 R483	1-216-085-00 1-216-077-00 1-216-033-00 1-216-057-00 1-216-025-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	33K 15K 220 2.2K 100	5% 5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W		R544 R545 R546 R547 R548	1-216-095-00 1-216-073-00 1-249-425-11 1-249-438-11 1-216-057-00	METAL GLAZE  METAL GLAZE  CARBON  CARBON  METAL GLAZE	82K 10K 4.7K 56K 2.2K	5% 5% 5% 5%	1/10W 1/10W 1/4W 1/4W 1/10W		
R484 R485 R486 R487	1-216-651-11 1-216-033-00 1-216-681-11 1-216-653-11	METAL CHIP METAL GLAZE METAL CHIP METAL CHIP	1K 220 18K 1.2K	5% 0.50%	1/10W 1/10W 1/10W 1/10W		R549 R550 R551	1-216-677-11 1-216-053-00 1-216-077-00	METAL CHIP METAL GLAZE METAL GLAZE	12K 1.5K 15K	0.50% 5% 5%	1/10W 1/10W 1/10W		

	1	7	
Ł			ı

REF.NO. PART NO.	DESCRIPTION		REMARK	REF.NO.	PART NO.	DESCRIPTION			REMARK
R552 1-216-033-00 R553 1-216-083-00 R554 1-216-095-00 R555 1-216-692-11 R556 1-216-464-11	METAL GLAZE 82K METAL CHIP 51K METAL OXIDE 18K		, m, m, m, m	R1126 R1127 R1128 R1129	1-216-071-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	8.2K 5%	1/10W 1/10W 1/10W 1/10W 1/10W	
R558 1-247-711-11 R559 1-216-109-00 R560 1-216-091-00 R561 1-216-049-00 R562 1-247-692-11	CARBON 680 METAL GLAZE 330K METAL GLAZE 56K METAL GLAZE 1K CARBON 22	5% 1/10W 5% 1/10W 5% 1/4W	F.	R1131 R1132 R1133 R1134	1-216-049-00 1-216-049-00 1-216-071-00 1-216-069-00 1-216-073-00	HEITHE GEHEE	1K 5% 8.2K 5% 6.8K 5% 10K 5%	1/10W 1/10W 1/10W 1/10W 1/10W	
R563 1-216-017-00 R564 1-216-107-00 R565 1-216-033-00 R566 1-216-685-11 R567 1-216-081-00	METAL GLAZE 220 METAL CHIP 27K METAL GLAZE 22K	5% 1/10W 5% 1/10W 0.50% 1/10W 5% 1/10W		R1136 R1137 R1138 R1139	1-216-295-00 1-216-097-00 1-216-073-00 1-216-081-00 1-216-055-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	100K 5% 10K 5% 22K 5% 1.8K 5%	1/10W 1/10W 1/10W 1/10W 1/10W	
R568 1-216-073-00 R569 1-260-119-11 R571 1-216-065-00 R572 1-216-059-00 R573 1-216-071-00	CARBON 47K METAL GLAZE 4.7K METAL GLAZE 2.7K METAL GLAZE 8.2K	5% 1/10W 5% 1/10W 5% 1/10W		R1141 R1142 R1143	1-216-653-11 1-216-083-00 1-216-653-11 1-216-653-11 1-216-073-00 1-216-067-00	METAL GLAZE METAL CHIP METAL CHIP METAL GLAZE	27K 5% 1.2K 0.5 1.2K 0.5	1/10W	
R574 1-216-689-11 R576 1-216-101-00 R578 1-216-693-11 R580 1-216-105-00 R582 1-216-085-00 R583 1-216-039-00	METAL GLAZE 150K	0.50% 1/10W 5% 1/10W 5% 1/10W		R1146 R1147 R1148 R1150	1-216-057-00 1-216-057-00 1-216-065-00 1-216-037-00	METAL GLAZE	5.6K 5% 2.2K 5% 2.2K 5% 4.7K 5% 330 5% 22K 5%	1/10W 1/10W 1/10W 1/10W 1/10W 1/10W	
R584 1-216-073-00 R585 1-216-033-00 R586 1-216-686-11 R587 1-216-675-11	METAL GLAZE 10K METAL GLAZE 220 METAL CHIP 30K METAL CHIP 10K	5% 1/10W 5% 1/10W 0.50% 1/10W 0.50% 1/10W		R1155 R1161 R1162 R1163	1-216-081-00 1-216-133-00 1-218-776-11 1-218-768-11 1-216-033-00	METAL GLAZE METAL CHIP METAL CHIP METAL GLAZE	3.3M 5% 1M 0.5 470K 0.5 220 5%	1/10W 0% 1/10W 0% 1/10W 1/10W	
R589 1-216-067-00 R590 1-216-081-00 R591 1-216-683-11 R592 1-247-688-11	METAL GLAZE 22K METAL CHIP 22K CARBON 10	5% 1/10W 5% 1/10W 0.50% 1/10W 5% 1/4W	F	R1165 1 R1166 1 R1167 1 R1168 1	1-216-049-00 1-216-049-00 1-216-295-00 1-216-097-00 1-216-097-00	METAL GLAZE	1K 5% 0 5% 100K 5% 100K 5%	1/10W 1/10W 1/10W 1/10W 1/10W	
R593 1-216-647-11 R594 1-260-104-91 R595 1-216-689-11 R596 1-214-754-00 R597 1-249-417-11 R598 1-216-085-00	METAL CHIP 680 CARBON 2.7K METAL GLAZE 39K METAL 11K CARBON 1K METAL GLAZE 33K	5% 1/10W 1% 1/4W 5% 1/4W	F	R1170 1 R1171 1	1-216-097-00 1-216-089-91 1-216-085-00 1-216-085-00 1-216-295-00 1-216-295-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	100K 5% 47K 5% 33K 5% 33K 5% 0 5% 0 5%	1/10W 1/10W 1/10W 1/10W 1/10W 1/10W	
R599 1-216-645-11 R1101 1-216-295-00 R1102 1-216-295-00 R1103 1-216-077-00	METAL GLAZE O METAL GLAZE O METAL GLAZE 15K	0.50% 1/10W 5% 1/10W 5% 1/10W 5% 1/10W		R1177 R1178 R1179 R1180	1-216-071-00 1-216-295-00 1-216-041-00 1-216-089-91	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	8.2K 5% 0 5% 470 5% 47K 5%	1/10W 1/10W 1/10W 1/10W	
R1104 1-216-699-11 R1105 1-216-073-00 R1106 1-216-097-00 R1107 1-216-059-00 R1108 1-216-681-11	METAL CHIP 100K METAL GLAZE 100K METAL GLAZE 100K METAL CHIP 18K	5% 1/10W 5% 1/10W 5% 1/10W 0.50% 1/10W		R1182 R1183 R1184 R1185	1-216-295-00 1-216-131-11 1-216-071-00 1-216-131-11 1-216-071-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	0 5% 2.7M 5% 8.2K 5% 2.7M 5% 8.2K 5% 2.7M 5%	1/10W 1/10W 1/10W 1/10W 1/10W	
R1109 1-216-295-00 R1110 1-216-295-00 R1111 1-216-065-00 R1112 1-216-065-00 R1113 1-216-081-00	METAL GLAZE 0 METAL GLAZE 0 METAL GLAZE 4.7K METAL GLAZE 4.7K METAL GLAZE 22K	5% 1/10W 5% 1/10W		R1187 R1188 R1189 R1190	1-216-131-11 1-216-071-00 1-216-131-11 1-216-071-00 1-216-131-11	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	8.2K 5% 2.7M 5% 8.2K 5% 2.7M 5%	1/10W 1/10W 1/10W 1/10W 1/10W	
R1114 1-216-049-00 R1115 1-216-049-00 R1116 1-216-677-11 R1117 1-216-069-00 R1118 1-216-113-00	METAL GLAZE 1K METAL GLAZE 1K METAL CHIP 12K METAL GLAZE 6.8K METAL GLAZE 470K	5% 1/10W		R1192 R1193 R1194 R1195	1-216-071-00 1-216-131-11 1-216-025-00 1-216-085-00 1-216-025-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	8.2K 5% 2.7M 5% 100 5% 33K 5% 100 5%	1/10W 1/10W 1/10W 1/10W 1/10W	
R1119 1-216-694-11 R1120 1-216-089-91 R1123 1-216-071-00 R1124 1-216-113-00	METAL CHIP 62K METAL GLAZE 47K METAL GLAZE 8.2K METAL GLAZE 470K			R1197	1-216-085-00 1-216-025-00 1-216-085-00	METAL GLAZE METAL GLAZE METAL GLAZE	33K 5% 100 5% 33K 5%	1/10W 1/10W 1/10W	

	ł
_	١
	l
$\overline{}$	l
	ľ

REF.NO. PART NO.	DESCRIPTION		REMARK	REF.NO.	PART NO.	DESCRIPTION			REMARK
REF. NO. PART NO	METAL GLAZE 150 METAL GLAZE 150 METAL GLAZE 390 METAL GLAZE 39K METAL GLAZE 220	5% 1/10W 5% 1/10W 5% 1/10W 5% 1/10W 5% 1/10W		R1366 R1367 R1368 R1369	1-216-081-00 1-216-057-00 1-216-059-00 1-216-051-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	22K 5% 2.2K 5% 2.7K 5% 1.2K 5%	1/10W 1/10W 1/10W 1/10W 1/10W	
R1306 1-216-645-11 R1307 1-216-091-00 R1308 1-216-645-11 R1309 1-216-025-00 R1310 1-216-025-00	METAL CHIP 560 METAL GLAZE 56K METAL CHIP 560 METAL GLAZE 100 METAL GLAZE 100	0.50% 1/10W 5% 1/10W 0.50% 1/10W 5% 1/10W 5% 1/10W		R1371 R1372 R1373 R1374 R1375	1-216-113-00 1-249-437-11 1-216-063-00 1-216-101-00 1-216-645-11	METAL GLAZE  CARBON METAL GLAZE METAL GLAZE METAL GLAZE METAL CHIP	470K 5%  47K 5%  3.9K 5%  150K 5%  560 0.50	1/10W 1/10W 1/4W 1/10W 1/10W 2 1/10W	
R1311 1-216-089-91 R1312 1-216-027-00 R1313 1-216-097-00 R1314 1-216-081-00 R1315 1-216-025-00	METAL GLAZE 47K METAL GLAZE 120 METAL GLAZE 100K METAL GLAZE 22K METAL GLAZE 100	5% 1/10W 5% 1/10W 5% 1/10W 5% 1/10W 5% 1/10W	4	R1376 R1377 R1378 R1379 R1380	1-216-647-11 1-216-055-00 1-216-065-00 1-216-037-00 1-216-645-11	METAL CHIP  METAL GLAZE METAL GLAZE METAL GLAZE METAL CHIP	1.8K 5% 4.7K 5% 330 5% 560 0.50	7 1/10W 7 1/10W 1/10W 1/10W 1/10W 7/10W	
R1316 1-216-065-00 R1317 1-216-041-00 R1318 1-216-061-00 R1319 1-216-085-00 R1320 1-216-065-00	METAL GLAZE 4.7K METAL GLAZE 470 METAL GLAZE 3.3K METAL GLAZE 33K METAL GLAZE 4.7K	5% 1/10W 5% 1/10W 5% 1/10W 5% 1/10W 5% 1/10W	9	R1381 R1382 R1383 R1384 R1385	1-216-647-11 1-216-073-00 1-216-681-11 1-216-091-00 1-216-073-00	METAL CHIP METAL GLAZE METAL CHIP METAL GLAZE METAL GLAZE METAL GLAZE	10K 5% 18K 0.50 56K 5% 10K 5%	1/10W 1/10W 1/10W 1/10W 1/10W	
R1322 1-216-057-00 R1324 1-216-061-00 R1325 1-216-652-11 R1326 1-216-073-00	METAL GLAZE 2.2K METAL GLAZE 3.3K METAL CHIP 1.1K METAL GLAZE 10K	0.50% 1/10W 5% 1/10W 0.50% 1/10W 5% 1/10W	4 4	R1387 R1388 R1389 R1390	1-216-653-11 1-216-689-11 1-216-657-11 1-216-647-11 1-216-025-00	METAL CHIP METAL CHIP METAL CHIP METAL CHIP METAL CHIP METAL CHIP	1.2K 0.50 39K 0.50 1.8K 0.50 680 0.50	1/10W % 1/10W % 1/10W % 1/10W % 1/10W % 1/10W	
R1328 1-216-125-00 R1329 1-216-103-91 R1330 1-216-081-00 R1331 1-216-679-11 R1332 1-216-671-11	METAL GLAZE 1.5M 5 METAL GLAZE 180K 5 METAL GLAZE 22K 5 METAL CHIP 15K 6	5% 1/10W 5% 1/10W 5% 1/10W 0.50% 1/10W		R1392 R1393 R1394 R1395 R1396	1-216-041-00 1-216-063-00 1-216-041-00 1-216-071-00 1-216-071-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	470 5% 3.9K 5% 470 5% 8.2K 5%	1/10W 1/10W 1/10W 1/10W 1/10W	
R1333 1-216-049-00 R1334 1-216-063-00 R1335 1-249-401-11 R1336 1-216-095-00 R1337 1-216-061-00	METAL GLAZE 1K METAL GLAZE 3.9K CARBON 47 METAL GLAZE 82K METAL GLAZE 3.3K	5% 1/10W 5% 1/10W 5% 1/4W F 5% 1/10W		R1397 R1399 R1401 R1402 R1403	1-216-065-00 1-216-073-00 1-216-085-00 1-216-295-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL CHIP	4.7K 5% 10K 5% 33K 5% 0 5%	1/10W 1/10W 1/10W 1/10W 1/10W	
R1338 1-216-647-11 R1339 1-216-033-00 R1340 1-216-033-00 R1341 1-216-033-00 R1342 1-216-083-00	METAL CHIP 680 C METAL GLAZE 220 F METAL GLAZE 220 F METAL GLAZE 220 F METAL GLAZE 27K	0.50% 1/10W 5% 1/10W 5% 1/10W 5% 1/10W 5% 1/10W		R1404 R1405 R1406 R1407 R1408	1-216-681-11 1-216-071-00 1-216-653-11 1-216-063-00 1-216-113-00	METAL CHIP METAL GLAZE METAL CHIP METAL GLAZE METAL GLAZE	18K 0.50% 8.2K 5% 1.2K 0.50% 3.9K 5% 470K 5%	3 1/10W 1/10W 1/10W 3 1/10W 1/10W	
R1343 1-216-037-00 R1344 1-216-093-00 R1345 1-216-109-00 R1346 1-216-097-00 R1347 1-216-073-00	METAL GLAZE 330 EMETAL GLAZE 68K EMETAL GLAZE 330K EMETAL GLAZE 100K EMETAL GLAZE 10K EMETAL GLAZE 10K	5% 1/10W 5% 1/10W 5% 1/10W 5% 1/10W 5% 1/10W		R1409 R1410 R1411 R1412 R1413	1-216-295-00 1-216-053-00 1-216-073-00 1-216-107-00 1-216-081-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	0 5% 1.5K 5% 10K 5% 270K 5% 22K 5%	1/10W 1/10W 1/10W 1/10W 1/10W	
R1352 1-216-065-00	10.000 a			R1414 R1415 R1416 R1417 R1418	1-216-057-00 1-216-093-00 1-216-113-00 1-216-033-00 1-216-033-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	2.2K 5% 68K 5% 470K 5% 220 5% 220 5%	1/10W 1/10W 1/10W 1/10W 1/10W	
R1353 1-216-065-00 R1354 1-216-089-91 R1355 1-216-033-00 R1356 1-216-105-00 R1357 1-216-101-00	METAL GLAZE 220K 5 METAL GLAZE 150K 5	5% 1/10W 5% 1/10W 5% 1/10W 5% 1/10W 5% 1/10W		R1419 R1420	1-216-025-00 1-216-089-91 1-216-649-11 1-216-085-00 1-216-057-00	METAL GLAZE METAL GLAZE METAL CHIP METAL GLAZE METAL GLAZE	100 5% 47K 5%	1/10W 1/10W 1/10W 1/10W 1/10W	
R1358 1-216-071-00 R1359 1-216-099-00 R1360 1-216-065-00 R1361 1-216-113-00 R1362 1-216-676-11	METAL GLAZE 8.2K 5 METAL GLAZE 120K 5 METAL GLAZE 4.7K 5 METAL GLAZE 470K 5	5% 1/10W 5% 1/10W 5% 1/10W 5% 1/10W	- '	R1424 R1425 R1426 R1427	1-216-081-00 1-216-013-00 1-216-113-00 1-216-681-11 1-216-061-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL CHIP METAL GLAZE	22K 5% 33 5% 470K 5%	1/10W 1/10W 1/10W 1/10W 1/10W	
R1363 1-216-113-00 R1364 1-216-073-00 R1365 1-216-131-11	METAL GLAZE 470K 5 METAL GLAZE 10K 5 METAL GLAZE 2.7M 5	5% 1/10W 5% 1/10W 5% 1/10W		R1429	1-216-668-11 1-216-073-00	METAL CHIP METAL GLAZE		1/10W 1/10W	

The components identified by shading and mark A are critical for safety.

Replace only with part number specified.

 The components identified by in this manual have been carefully factory-selected for each set in order to satisfy regulations regarding X-ray radiation.
 Should replacement be required, replace only with the value originally used.



REF.NO. PART NO. DESCRIPTION		REMARK	REF.NO.	PART NO.	DESCRIPTION				REMARK
R1433 1-216-085-00 METAL GLAZE 33 R1434 1-216-645-11 METAL CHIP 56 R1435 1-216-055-00 METAL GLAZE 1.	2M 5% 1/10W K 5% 1/10W K 5% 1/10W 0 0.50% 1/10W 8K 5% 1/10W		R1497 R1498 R1499	1-216-089-91 1-216-113-00 1-247-839-31 1-216-057-00 1-216-649-11		470K 2.2K 2.2K	5% 5% 5%	1/10W 1/10W 1/4W 1/10W	
	K 5% 1/10W 8K 5% 1/10W K 5% 1/10W 7K 5% 1/10W 0 5% 1/10W		R1501 R1502 R1503 R1504 R1505	1-216-071-00 1-260-105-11 1-216-063-00 1-216-686-11 1-247-688-11	METAL GLAZE CARBON METAL GLAZE METAL CHIP CARBON	3.3K 3.9K 30K	0.50% 5%	1/2W 1/10W 1/10W 1/4W	F
	0 5% 1/10W K 5% 1/10W 2K 5% 1/10W 2K 5% 1/10W 2K 5% 1/10W K 5% 1/10W K 5% 1/10W 2K 5% 1/10W K 5% 1/10W 2K 5% 1/10W 2K 5% 1/10W 2K 5% 1/10W		R1506 R1507 R1508 R1509 R1510	1-216-041-00 1-216-065-00 1-216-689-11 1-249-439-11 1-216-077-00 1-216-360-11	METAL GLAZE METAL GLAZE METAL GLAZE CARBON METAL GLAZE METAL GLAZE METAL OXIDE	470 4.7K 39K 68K 15K 8.2		1/10W 1/10W 1/10W 1/4W 1/10W 1/10W	r
	2K 5% 1/10W K 5% 1/10W K 5% 1/10W 2K 5% 1/10W 2M 5% 1/10W	· ·	R1512 R1513 R1514 R1515	1-216-647-11 1-247-752-11 1-247-711-11 1-216-350-11	METAL CHIP		0.50%	1/100	
	K 5% 1/10W 5% 1/10W 7K 5% 1/10W 0K 5% 1/10W		R1518	1-215-867-00 1-216-355-11		470 3.3 18 150 33		1W 1W 1/10W 1/10W	F
	2M 5% 1/10W K 5% 1/10W K 5% 1/10W BM 5% 1/10W OK 5% 1/10W		R1523 R1524 R1525 R1526	1-216-350-11 1-216-427-00 1-216-083-00 1-216-089-91	METAL OXIDE METAL OXIDE METAL GLAZE METAL GLAZE		5% 5% 5%	1/10W 1/10W	F
R1461 1-216-645-11 METAL CHIP 56 R1462 1-216-645-11 METAL CHIP 56 R1463 1-216-645-11 METAL CHIP 56 R1464 1-216-057-00 METAL GLAZE 2. R1465 1-216-097-00 METAL GLAZE 10	0 0.50% 1/10W 0 0.50% 1/10W 2K 5% 1/10W 0K 5% 1/10W		R1528 R1529 R1530	1-249-413-11 1-215-869-11 1-202-829-11 1-216-115-00 1-247-697-11	CARBON METAL OXIDE SOLID METAL GLAZE CARBON	1K 8.2K 560K	5% 20% 5%	1/4W 1W 1/2W 1/10W 1/4W	<b>F</b>
R1466 1-216-055-00 METAL GLAZE 1. R1467 1-216-073-00 METAL GLAZE 10 R1468 1-249-438-11 CARBON 56 R1469 1-216-057-00 METAL GLAZE 2. R1470 1-216-061-00 METAL GLAZE 3.	8K 5% 1/10W K 5% 1/10W K 5% 1/10W K 5% 1/10W 3K 5% 1/10W 5% 1/10W 5% 1/10W K 5% 1/10W K 5% 1/10W K 0.50% 1/10W K 0.50% 1/10W		R1532 R1533 R1534 ■R1535 A ■R1536 A	1-216-059-00 1-249-414-11 1-216-659-11	METAL GLAZE CARBON METAL CHIP	2.7K 560 2.2K	5% 5% 0.50%	1/10W 1/4W 1/10W	<b>F</b>
R1471 1-216-049-00 METAL GLAZE 1K R1472 1-216-085-00 METAL GLAZE 33 R1473 1-216-081-00 METAL GLAZE 22 R1474 1-216-687-11 METAL CHIP 33 R1475 1-216-677-11 METAL CHIP 12	5% 1/10W K 5% 1/10W K 5% 1/10W K 0.50% 1/10W K 0.50% 1/10W		R1537 R1538 R1539 R1540	1-249-389-11 1-216-073-00 1-216-689-11 1-216-105-00	CARBON METAL GLAZE METAL GLAZE	4.7 10K 39K 220K	5% 5% 5%	1/4W 1/10W 1/10W 1/10W	enterential de la constantial
R1476 1-216-063-00 METAL GLAZE 3. R1477 1-216-057-00 METAL GLAZE 2. R1478 1-216-061-00 METAL GLAZE 3. R1479 1-216-295-00 METAL GLAZE 0. R1480 1-216-089-91 METAL GLAZE 47	9K 5% 1/10W 2K 5% 1/10W 3K 5% 1/10W 5% 1/10W K 5% 1/10W		R1542 R1543 R1544 R1545	1-216-111-00 1-216-027-00 1-216-117-00 1-216-101-00	METAL GLAZE METAL GLAZE METAL GLAZE	120 680K	5% 5% 5%	1/10W 1/10W 1/10W	
R1481 1-216-115-00 METAL GLAZE 56 R1482 1-216-089-91 METAL GLAZE 47 R1483 1-216-089-91 METAL GLAZE 47 R1484 1-216-081-00 METAL GLAZE 22 R1485 1-216-113-00 METAL GLAZE 47	OK 5% 1/10W K 5% 1/10W K 5% 1/10W K 5% 1/10W		R1548 R1549 R1550	1-216-393-00 1-216-057-00 1-260-094-11 1-216-105-00 1-249-393-11	METAL OXIDE METAL GLAZE CARBON METAL GLAZE CARBON	2.2K 390 220K	5% 5% 5%	3W 1/10W 1/2W 1/10W	
R1486 1-216-121-00 METAL GLAZE 1M R1487 1-216-113-00 METAL GLAZE 47 R1488 1-216-083-00 METAL GLAZE 27 R1489 1-216-069-00 METAL GLAZE 6.	5% 1/10W OK 5% 1/10W K 5% 1/10W SK 5% 1/10W		R1552 R1553 R1554 R1555	1-216-091-00 1-216-091-00 1-216-059-00 1-216-295-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	56K 2.7K 0	5% 5% 5%	1/10W 1/10W 1/10W 1/10W	•
R1490 1-216-035-00 METAL GLAZE 27 R1491 1-216-035-00 METAL GLAZE 27 R1492 1-216-035-00 METAL GLAZE 27 R1493 1-216-083-00 METAL GLAZE 27 R1494 1-216-081-00 METAL GLAZE 22	0 5% 1/10W 0 5% 1/10W K 5% 1/10W		R1557 R1558 R1559 R1560	1-216-071-00 1-218-760-11 1-249-393-11 1-249-393-11 1-216-049-00	METAL GLAZE METAL CHIP CARBON CARBON METAL GLAZE	220K 10 10 1K	0.50% 5% 5% 5%	1/4W 1/4W 1/10W	F F
			R1561 R1562	1-216-681-11 1-214-964-00	METAL CHIP METAL		0.50% 1%	1/10W 1/4W	

Ä	Į
Δ	1
	1

REF.NO.	PART NO.	DESCRIPTION				REMARK	REF.NO.	PART NO.	DESCRIPTION				REMARK
R1563 R1564 R1567 R1568 R1569	1-214-964-00 1-216-681-11 1-216-089-91 1-216-081-00 1-216-073-00	METAL CHIP METAL GLAZE METAL G	1M 18K 47K 22K 10K	1% 0.50% 5% 5%	1/4W 1/10W 1/10W 1/10W 1/10W	•	R2349 R2350 R2351 R2352 R2353	1-216-679-11 1-216-061-00 1-216-061-00 1-216-061-00 1-216-041-00	METAL CHIP METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	15K 3.3K 3.3K 3.3K 470	0.50% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W	
R1570 R1571 R1572 R1573 R1574	1-216-073-00 1-216-103-91 1-216-101-00 1-216-073-00 1-216-041-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	10K 180K 150K 10K 470	5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W		R2354 R2356 R2358 R2361 R2362	1-216-025-00 1-216-089-91 1-216-025-00 1-216-099-00 1-216-081-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	100 47K 100 120K 22K 4.7K	5% 5%	1/10W 1/10W 1/10W 1/10W	
R1575 R1576 R1577 R1578 R1579	1-216-025-00 1-216-025-00 1-216-025-00 1-216-065-00 1-216-690-11	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL CHIP	100 100 100 4.7K 43K	5% 5% 5% 0.50%	1/10W 1/10W 1/10W 1/10W 1/10W		R2364 R2365 R2366 R2367	1-216-065-00 1-216-025-00 1-216-687-11 1-216-067-00 1-216-097-00	METAL GLAZE METAL CHIP METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	4.7K 100 33K 5.6K 100K	5% 0.50% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W 1/10W	
R2301 R2302 R2303 R2304	1-216-065-00 1-216-671-11 1-216-093-00 1-216-105-00 1-216-085-00	METAL GLAZE METAL CHIP METAL GLAZE METAL GLAZE METAL GLAZE	4.7K 6.8K 68K 220K	5% 0.50% 5% 5%	1/10W 1/10W 1/10W 1/10W		R2369 R2370 R2371 R2372 R2374	1-216-089-91 1-216-085-00 1-216-049-00 1-216-113-00 1-216-097-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	47K 33K 1K 470K 100K	5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W	
R2306 R2307 R2308 R2309	1-216-089-91 1-216-033-00 1-216-103-91 1-216-049-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	47K 220 180K 1K	5% 5% 5%	1/10W 1/10W 1/10W 1/10W		R2375 R2376 R2377 R2378	1-216-089-91 1-216-089-91 1-216-033-00 1-216-089-91 1-216-033-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	47K 47K 220 47K 220	5% 5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W	
R2311 R2312 R2313 R2314	1-216-073-00 1-216-053-00 1-216-049-00 1-216-645-11	METAL GLAZE METAL GLAZE METAL GLAZE METAL CHIP	10K 1.5K 1K 560	5% 5% 5% 0.50%	1/10W 1/10W 1/10W 1/10W		R2380 R2381 R2382 R2383 R2384	1-216-089-91 1-216-089-91 1-216-089-91 1-216-033-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	47K 47K 47K 220 39K	5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W	
R2316 R2317 R2318 R2319	1-216-081-00 1-216-049-00 1-216-069-00 1-216-093-00 1-216-677-11	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL CHIP	22K 1K 6.8K 68K	5% 5% 5% 5% 0.50%	1/10W 1/10W 1/10W 1/10W 1/10W		R2385 R2386 R2387 R2388 R2389	1-216-073-00 1-216-073-00 1-216-073-00 1-216-073-00 1-216-033-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	10K 10K 10K 10K 10K 220	5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W	
R2321 R2322 R2323 R2324 R2325	1-216-057-00 1-216-065-00 1-216-683-11 1-216-073-00	METAL GLAZE METAL GLAZE METAL CHIP METAL GLAZE METAL GLAZE	2.2K 4.7K 22K 10K	5% 5% 0.50% 5%	1/10W 1/10W 1/10W 1/10W		R2390 R2391 R2392 R2393 R2394	1-216-647-11 1-216-647-11 1-216-073-00 1-216-073-00	METAL CHIP METAL CHIP METAL GLAZE METAL GLAZE METAL GLAZE	680 680 10K 10K	0.50% 0.50% 5% 5%	1/10W	
R2326 R2327 R2328 R2329	1-216-041-00 1-216-059-00 1-216-049-00 1-216-059-00 1-216-049-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	470 2.7K 1K 2.7K	5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W		R2396 R2397 R2398 R2399 R2501	1-216-041-00 1-216-113-00 1-216-109-00 1-216-073-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	470 470K 330K 10K		1/10W 1/10W 1/10W 1/10W 1/10W	
R2331 R2332 R2333 R2334	1-216-059-00 1-216-049-00 1-216-089-91 1-216-041-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	2.7K 1K 47K 47O	5% 5% 5%	1/10W 1/10W 1/10W 1/10W		R2502 R2551 R2552 R2553	1-216-085-00 1-216-091-00 1-216-085-00 1-216-083-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	33K 56K 33K 27K	5% 5% 5%	1/10W 1/10W 1/10W 1/10W	
R2336 R2337 R2338	1-216-061-00 1-216-065-00 1-216-037-00 1-216-037-00 1-216-037-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	3.3K 4.7K 330 10K 330	5%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%	1/10W 1/10W 1/10W 1/10W		R2558 R2559	1-216-055-00 1-216-051-00 1-216-067-00 1-216-057-00 1-216-039-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	1.8K 1.2K 5.6K 2.2K 390	5% % % % % % % % % % % % % % % % % % %	1/10W 1/10W 1/10W 1/10W 1/10W	
R2341 R2342 R2343 R2344	1-216-073-00 1-216-037-00 1-216-071-00 1-216-081-00 1-216-121-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	10K 330 8.2K 22K 1M	5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W		R2560 R2561 R2562 R2563 R3301	1-216-069-00 1-216-001-00 1-216-057-00 1-216-073-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	6.8K 10 10 2.2K 10K	5% % % % % % % % % % % % % % % % % % %	1/10W 1/10W 1/10W 1/10W 1/10W	
R2346 R2347	1-216-681-11 1-216-061-00 1-216-061-00 1-216-061-00	METAL CHIP METAL GLAZE METAL GLAZE METAL GLAZE	18K 3.3K 3.3K 3.3K	0.50% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W		R3303	1-216-065-00 1-216-065-00 1-216-065-00	METAL GLAZE METAL GLAZE METAL GLAZE	4.7K 4.7K 4.7K	5%	1/10W 1/10W 1/10W	

The components identified by shading and mark  $ext{$\Delta$}$  are critical for safety. Replace only with part number specified.



												1	# <b>~</b>	-
REF.NO.	PART NO.	DESCRIPTION				REMARK	REF.NO.	PART NO.	DESCRIPTION			L	REMAR	K
R3306 R3307 R3308	1-216-061-00 1-216-063-00 1-216-093-00 1-216-097-00 1-216-073-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	3.3K 3.9K 68K 100K 10K	5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W		R4401 R4402 R4404	1-216-690-11 1-216-085-00 1-216-113-00 1-216-073-00	METAL GLAZE METAL GLAZE METAL GLAZE	33K 470K 10K	0.50% 5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W		
R3311 R3312 R3317	1-216-049-00 1-216-091-00 1-216-105-00 1-216-099-00 1-216-085-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	1K 56K 220K 120K 33K	5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W		R4407 R4408 R4409 R4410	1-216-069-00 1-216-061-00 1-216-059-00 1-216-059-00 1-216-059-00	METAL GLAZE	1	55 55555555555555555555555555555555555	1/10W 1/10W 1/10W 1/10W 1/10W		
R3335	1-216-113-00 1-216-073-00 1-216-113-00 1-216-099-00 1-218-759-11	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL CHIP	470K 10K 470K 120K 200K	5% 5% 5% 5% 0.50%	1/10W 1/10W 1/10W 1/10W 1/10W		1	1-216-113-00 1-216-113-00 1-216-295-00 1-216-295-00 1-216-295-00 1-216-295-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE			1/10W 1/10W 1/10W 1/10W 1/10W		
R3341 R3342	1-216-093-00 1-216-099-00 1-216-089-91 1-216-093-00 1-216-089-91	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	68K 120K 47K 68K 47K	5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W			-216-295-00 <var 1-223-102-00</var 	IABLE RESISTOR	?>		1/10W		
R3345 R3346 R3347	1-216-081-00 1-216-033-00 1-216-025-00 1-216-025-00 1-216-025-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	22K 220 100 100 100	5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W	r	T300 T500	1-406-781-11	NSFORMER> COIL TRANSFORMER,	FERRITE	(HDT)	······································	· zw. przywkiejskiejskiejskiejskiejskiejskiejskiejs	
R3350 R3351	1-216-025-00 1-216-117-00 1-216-115-00 1-216-111-00 1-216-089-91	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	100 680K 560K 390K 47K	5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W		T502 T503 A	1-400-668-11 1-453-164-11 1-453-164-11 1-413-059-00 1-460-017-11	TRANSFORMER, TRANSFORMER	SSY, FL FERRITE	YBACK (DFT)			144
R3356 R3357 R3358 R3359 R3360	1-216-051-00 1-216-051-00 1-216-051-00 1-216-081-00 1-216-073-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	1.2K 1.2K 1.2K 22K 10K	5%	1/10W 1/10W 1/10W 1/10W 1/10W		# 		STAL>					
R3362 R3363 R3364	1-216-089-91 1-216-049-00 1-216-049-00 1-216-073-00 1-216-085-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	47K 1K 1K 10K 33K	5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W		X300 X301	1-579-175-11 1-577-259-11 1-527-722-00	VIBRATOR, CRY OSCILLATOR, C	STAL RYSTAL	*****	*****	******	**
R3368 - R3369 R3370	1-216-121-00 1-216-041-00 1-216-681-11 1-216-055-00 1-216-121-00	METAL GLAZE METAL GLAZE METAL CHIP METAL GLAZE METAL GLAZE	1M 470 18K 1.8K 1M	5% 5% 0.50% 5%	1/10W 1/10W 1/10W 1/10W 1/10W			1-533-189-11 4-363-414-00 4-382-854-11	**************************************	**** 	(+)			
R3372 R3373 R3374 R3375 R3376	1-216-649-11 1-216-647-11 1-216-121-00 1-216-681-11 1-216-081-00	METAL CHIP METAL CHIP METAL GLAZE METAL CHIP METAL GLAZE	820 680 1M 18K 22K	0.50% 0.50% 5% 0.50% 5%	1/10W		C602 <b>∧</b> .	1-161-953-71 1-161-953-71	CERAMIC	0.0047MF 0.0047MF	2	0%	400V 400V	
R3377 R3378 R3379 R3381 R3382	1-216-107-00 1-216-121-00 1-216-107-00 1-216-041-00 1-216-647-11	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL CHIP	270K 1M 270K 470 680	5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W		C604 A. C605 A. C606 C607	1-161-953-71 1-161-953-71 1-104-706-51 1-124-907-11 1-124-798-11	CERAMIC, FILM FILM ELECT	0.0047MF 0.0047MF 0.22MF 10MF 1MF	1 2 2 2	0% 0% 0%	400V 400V 250V 50V 160V	or the way of the feet of the
R3383 R3384 R3385 R3386 R3390	1-216-069-00 1-216-063-00 1-216-057-00 1-216-057-00 1-216-057-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	6.8K 3.9K 2.2K 2.2K 2.2K	5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W		C610 C611 C612	1-129-765-00 1-124-126-00 1-124-902-00 1-130-729-00 1-107-722-11	ELECT ELECT FILM ELECT	0.047MF 47MF 0.47MF 0.0027MF 470MF	1 2 2 5	0% 0% 0% %	200V 10V 50V 50V 400V	
R3394 R3395 R3396 R3397	1-216-089-91 1-249-417-11 1-216-041-00 1-216-041-00	METAL GLAZE CARBON METAL GLAZE METAL GLAZE	47K 1K 470 470	5% 5% 5%	1/10W 1/4W 1/10W 1/10W		C613 A. C614 C615 A.	1-104-706-51 1-102-978-00 1-104-706-51	FILM CERAMIC FILM	0.22MF 220PF 0.22MF 0.001MF	2) 5 2)	0% : 2 0% :	250V 50V 250V 500V	



The components identified by shading and mark A are critical for safety.
Replace only with part number specified.

REF.NC	. PART NO.	DESCRIPTION		REMARK	REF.NO.	PART NO.	DESCRIPTION	REMARK
C618 C619 C620 C621 C622	1-124-907-11 1-162-116-00 1-162-116-00 1-136-153-00 1-126-773-11	ELECT 10M CERAMIC 680 CERAMIC 680 FILM 0.0 ELECT 47M	PF 10% 1MF 5% F 20%	50V 2KV 2KV 50V 250V	D615 D616 D617 D618 D619	8-719-300-33 8-719-911-19 8-719-911-19 8-719-908-03 8-719-110-41	DIODE RU-3AM DIODE 1SS119 DIODE 1SS119 DIODE GP08D DIODE RD15ESB2	
C623 C624 C625 C627 C628	1-162-318-11 1-124-477-11 1-161-973-00 1-136-066-00 1-136-067-00	ELECT 47M CERAMIC 220 FILM 0.00 FILM 0.00	PF 10% 03MF 3% 036MF 3%	500V 16V 400V 2KV 2KV	D620 D621 D622 D623 D625	8-719-045-48 8-719-911-19 8-719-979-58 8-719-045-48 8-719-016-42	DIODE FML-G12S DIODE 1SS119 DIODE EGP10D DIODE FML-G12S DIODE MC932	
C629 C630 C631 C632 C633	1-124-887-00 1-102-973-00 1-161-973-00 1-162-599-12 1-162-599-12	CERAMIC 100 CERAMIC 220 CERAMIC 0.0 CERAMIC 0.0	PF 10% 047MF 20% 047MF 20%	3KV 50V 400V 400V 400V	D626 D628 D629 D630 D631	8-719-109-71 8-719-979-50 8-719-979-85 8-719-911-19 8-719-911-19	DIODE RD3.9ESB1 DIODE EGP30D DIODE EGP20G DIODE 1SS119 DIODE 1SS119	
C634 C635 C636	1-102-125-00 1-124-903-11 1-126-801-11	ELECT 1MF	20%	50V 50V 50V		<fer< td=""><td>RITE BEAD&gt;</td><td></td></fer<>	RITE BEAD>	
C637 C638	1-102-030-00 1-102-030-00	CERAMIC 330 CERAMIC 330	PF 10%	500V 500V	FB602A	_1-543-190-11		
C639 C640 C641 C642 C643	1-104-783-51 1-128-386-11 1-106-343-00 1-102-030-00 1-104-884-11	ELECT 1000 ELECT 1000 MYLAR 0.00 CERAMIC 3300 ELECT 470	OMF 20% 01MF 10% PF 10%	25V 25V 100V 500V 50V	EDGUIA	1-543-190-11 1-543-190-11	FERRITE BEAD INDUCTOR BEAD, FERRITE BEAD, FERRITE	
C644 C645 C646 C647 C649	1-102-030-00 1-162-131-11 1-102-973-00 1-126-385-11 1-126-803-11	CERAMIC 220 CERAMIC 220 CERAMIC 100 ELECT 390 ELECT 47M	PF 10% PF 5% MF 20%	500V 2KV 50V 16V	IC602 IC603	<1C> 8-759-100-75 8-759-255-41 8-759-927-49 8-759-924-12	IC MM1108XS IC IR9431	
C650 C651	1-126-103-11 1-126-101-11	ELECT 470 ELECT 1001	MF 20%	16V 16V		<c01< td=""><td>L&gt;</td><td></td></c01<>	L>	
	1-124-667-11 1-136-169-00 ▲ 1-161-953-71	The second secon	2MF 5% 047MF 20%	50V 50V 400V	L603 L604 L605	1-410-645-31 1-407-365-00 1-410-645-31	COIL, CHOKE	
C656	<u>A</u> . 1-161-953-71, <u>A</u> . 1-161-953-71 1-102-965-00	CERAMIC 0.0 CERAMIC 0.0 CERAMIC 39P	047MF 20%	400V 400V 50V		<ph0< td=""><td>TO COUPLER&gt;</td><td></td></ph0<>	TO COUPLER>	
C658 C659	<b>A.</b> 1-161-953-71 1-102-123-00	"CERAMIC 0.0	047MF 20% 033MF 10%	400V 50V	PH602 PH606	8-749-923-50 8-749-923-50	PHOTO COUPLER PC111YS PHOTO COUPLER PC111YS	
C660 C661	1-124-791-11 1-130-467-00	ELECT 1MF MYLAR 470		100V 50V		ation of the	NS1STOR>	
CNCO		NECTOR> PIN, CONNECTOR (	טר ממצטט/ אט		Q601 Q602	8-729-119-80	TRANSISTOR 2SC2785-HFF TRANSISTOR 2SC2688-LK	
CN602 CN603	2 *1-695-561-11 3 1-508-765-00	PIN, CONNECTOR () PIN, CONNECTOR (	PC/BOARD) 7P 5MM PITCH) 3	Р	Q603 Q605 Q606	8-729-119-80 8-729-802-14	TRANSISTOR 2SC2688-LK TRANSISTOR 2SC2688-LK TRANSISTOR 2SC3460	
CN60	5 *1-564-508-11 5 *1-564-508-11	PIN, CONNECTOR ( PLUG, CONNECTOR PIN, CONNECTOR 2	PC BUARD) BP	<b>P</b>	Q607 Q609	8-729-905-67	TRANSISTOR 2SD774-34 TRANSISTOR 2SD1944-K	
UN60			P		Q610 Q611	8-729-209-03 8-729-200-17	TRANSISTOR 2SC2551-RO TRANSISTOR 2SA1091-0	
D601		DE> DIODE D4SB6OL	7.: 84.0 (19.56) <b>4.</b> 330 248 3				ISTOR>	
D603 D604 D605	8-719-300-33 8-719-110-90 8-719-110-90 8-719-109-97	DIODE D4SB60L DIODE R0-3AM DIODE RD39ESB4 DIODE RD39ESB4 DIODE RD6.8ESB2 DIODE RD110EB DIODE RD15ESB2 DIODE RU-3AM DIODE RU-3AM DIODE RU-3AM			R602 <b>2</b> 2   R603   R604 <b>2</b> 4	. 1-260-123-91 1-249-427-11	METAL 1M 1%	1/2W 1/4W 1/2W
D606 D607 D608	8-719-118-34 8-719-110-41 8-719-300-33	DIODE RD110EB DIODE RD15ESB2 DIODE RU-3AM			R606 R607	1-260-111-11 1-205-943-11	CARBON 10K 5% WIREWOUND 1 5%	1/2W 20W
D610 D611	8-719-200-02 8-719-300-33	DIODE 10E-2 DIODE RU-3AM			R608 R609	1-260-127-11 1-215-922-11	CARBON 220K 5% METAL OXIDE 6.8K 5%	1/2W 3W F

The components identified by shading and mark  $\, \Delta \,$  are critical for safety. Replace only with part number specified.

\* : Selected to yield optimum performance.

-	' V IVI	-2054Q
		G C
<b>%</b>	1/4W	
% % %	1/4W 1/4W 1/4W 1/4W 1/4W	
% % % % % % % % % % % % % % % % % % %	1/4W 1/4W 1/4W 1/4W 1/4W	 
% % % % % % % % % % % % % % % % % % %	1/4W 1/4W 1/4W 1/4W 1/4W	
% % % % %	1/4W 1/4W 1/4W 1/4W	•
2.18 2.18 2.18	purity.	n gangara Nggaran Sangara Nggaran Sangara
	(LFT) (LFT) SRT)	
Tara es Classical		
		******
. •		
	10%	50 <b>V</b>

REF.NO.	PART NO.	DESCRIPTION				REM	ARK	REF.NO.	PĀRT NO.	DESCRIPTION			L	REMARK	
R610 R611 R612 R613 R614	1-215-922-11 1-215-457-00 1-202-719-00 1-202-720-00 1-249-423-11	METAL OXIDE METAL SOLID SOLID CARBON	6.8K 33K 1M 1.2M 3.3K	5% 1% 20% 20% 5%	3W 1/4W 1/2W 1/2W 1/4W	F		₩R690 ₩R690 ₩R690 ₩R690 ₩R690	1-214-127-00 1-214-725-00 1-215-418-00 1-214-727-00	METAL METAL METAL METAL METAL METAL	620 680 750 820 910	1% 1% 1%	1/4W 1/4W 1/4W 1/4W 1/4W		
R615 R616 R617 R618 R619	1-260-324-11 1-247-710-11 1-214-716-00 1-249-496-11 1-216-444-11	METAL CARBON METAL OXIDE	470 560 300 100K 82K	5% 5% 1% 5%	1/2W 1/4W 1/4W 1/2W 1W	F F	:	<b>≭</b> R690	1-214-728-11 1-214-729-00 1-214-730-00 1-214-731-00 1-214-732-00 1-214-733-00 1-215-426-00	METAL METAL METAL METAL METAL	1K 1.1K 1.2K 1.3K 1.5K	1% 1% 1% 1% 1% 1% 1%	1/4W 1/4W 1/4W 1/4W 1/4W		
R620 R621 R622 R623 R624	1-216-444-11 1-249-427-11 1-217-190-21 1-249-393-11 1-247-887-00	CARBON	82K 6.8K 0.15 10 220K	5%	1W 1/4W 2W 1/4W 1/4W	F		1	1-215-426-00 1-214-735-00 1-215-428-00 1-214-737-00 1-214-739-00 1-214-741-00	METAL METAL METAL METAL METAL	1.6K 1.8K 2K 2.2K 2.7K 3.3K	1% 1% 1% 1% 1%	1/4W 1/4W 1/4W 1/4W		
R625 R626 R627 R628 R629	1-247-887-00 1-249-436-11 1-249-429-11 1-214-777-00 1-247-891-00	CARBON CARBON CARBON METAL CARBON	220K 39K 10K 100K 330K	5 <b>%</b>	1/4W 1/4W 1/4W 1/4W 1/4W		34 - 41 - 51 - 51 - 51 - 51 - 51 - 51 - 51 - 5	i	1-214-741-00 1-214-743-00 1-214-745-00 1-214-747-00 1-214-749-00	METAL METAL METAL METAL METAL		1% 1% 1% 1% 1%	1/4W 1/4W 1/4W 1/4W 1/4W		
R630 R631 R632 R633 R635	1-247-885-00 1-249-412-11 1-249-441-11	CARBON CARBON CARBON CARBON CARBON	3.9K 10K 180K 390 100K	5% 5% 5%	1/4W 1/4W 1/4W 1/4W 1/4W			RV601		IABLE RESISTOR		0			
R636 R637 R638 R642 R643	1-247-753-11 1-216-491-11 1-216-491-11 1-247-807-31 1-249-423-11	CARBON METAL OXIDE METAL OXIDE CARBON CARBON	1.2K 56K 56K 100 3.3K	5% 5% 5% 5%	1/2W 3W 3W 1/4W 1/4W	F		RY6014		RELAY	e organicas, 1922 per 1 (L)			i serviciones. Programas serviciones de la companya	
R644 R645 R646 R647 R648	1-249-417-11 1-218-265-11 1-249-417-11 1-260-121-11 1-249-443-11	CARBON CARBON	1K 8.2M 1K 68K 0.47	5% 5% 5% 5%	1/4W 1W 1/4W 1/2W 1/4W	F		; T603	1-426-716-11 1-426-716-11 1-437-090-00	NSFORMER> TRANSFORMER, TRANSFORMER, HDT TRANSFORMER,					
R649 R650 R652 R653 R654	1-260-097-11 1-249-422-11 1-247-895-00 1-260-124-11 1-215-924-00	CARBON CARBON METAL OXIDE	680 2.7K 470K 120K 15K	5% 5% 5%	1/2W 1/4W 1/4W 1/2W 3W	ŗ		TH601 TH602	<the 1-807-973-11="" 1-807-973-11<="" td=""><td>RMISTOR&gt; THERMISTOR THERMISTOR</td><td>gradi gradi gradi gradi</td><td></td><td></td><td></td><td></td></the>	RMISTOR> THERMISTOR THERMISTOR	gradi gradi gradi gradi				
R655 R656 R659 R660 R661	1-249-440-11 1-247-883-00 1-249-443-11 1-215-427-00 1-215-412-00	CARBON CARBON CARBON METAL METAL	82K 150K 0.47 1.8K 430	5% 5% 5% 1%	1/4W 1/4W 1/4W 1/4W 1/4W	F		******	∆1-808-059-32 <i>%</i> ********** *A-1331-300-A	THERMISTOR, P ************************************	****** Lete		*****	******	: : <b>*</b>
R662 R663 R664 R665 R666	1-260-123-11 1-260-089-11 1-216-390-11 1-216-390-11 1-216-369-00		100K 150 1.2 1.2 1	5% 5% 5% 5%	1/2W 1/2W 3W 3W 2W	F F			*4-379-160-01 *4-379-167-01	COVER (REAR L COVER (MAIN),	ID), C	<b>y</b>	•		
R667 R669 R670 R671 R672	1-205-943-11 1-215-419-00 1-249-435-11 1-249-429-11 1-215-469-00	WIREWOUND METAL CARBON CARBON METAL	1 820 33K 10K 100K	5% 1% 5% 5%	20W 1/4W 1/4W 1/4W 1/4W			C701 C702 C703 C704 C705	1-102-116-00 1-102-116-00 1-102-116-00 1-102-121-00 1-126-101-11	CERAMIC CERAMIC CERAMIC	680PF 680PF 680PF 0.0022 100MF	MF	10% 10% 10% 10% 20%	50V 50V 50V 50V 16V	
R673 R674 R675 R676 R677	1-249-437-11 1-247-889-00 1-249-429-11 1-247-883-00 1-260-120-11	CARBON CARBON CARBON CARBON CARBON	47K 270K 10K 150K 56K	5% 5% 5%	1/4W 1/4W 1/4W 1/4W 1/2W			C706 C707 C708 C710	1-120-101-11 1-102-074-00 1-162-116-00 1-136-601-11 1-101-880-00 1-101-880-00	CERAMIC CERAMIC FILM CERAMIC	0.001M 680PF 0.01MF 47PF 47PF	F	10% 10% 10% 5% 5%	50V 2KV 630V 50V 50V	
R678 <b>※</b> R690 <b>※</b> R690 <b>※</b> R690	1-249-436-11 1-214-721-00 1-215-414-00 1-214-723-00	CARBON METAL METAL METAL	39K 470 510 560	5% 1% 1% 1%	1/4W 1/4W 1/4W 1/4W			C712 C714 C715	1-101-880-00 1-102-976-00 1-102-976-00	CERAMIC CERAMIC	47PF 180PF 180PF		5% 5% 5%	50V 50V 50V	

СН

The components identified by shading and mark  $\triangle$  are critical for safety. Replace only with part number specified.

REF.NO. PART NO.	DESCRIPTION			REMARK	REF.NO.	PART NO.	DESCRIPTION				RE	MARK
C716 1-102-976-00 C722 1-162-622-11 C724 1-124-667-11 C726 1-123-948-00 C733 1-123-947-00	ELECT ELECT		5%	50V 6.3KV 100V 250V 250V	R702 R704 R705 R706 R707	1-247-897-11 1-215-404-00 1-215-404-00 1-215-404-00 1-249-429-11	CARBON METAL METAL METAL CARBON	560K 200 200 200 200 10K	5% 1% 1% 1% 5%	1/4W 1/4W 1/4W 1/4W 1/4W		
C734 1-101-888-00 C737 1-102-934-00		68PF 1PF	5% 0.25PF	50V 50V	R708 R709 R710 R711 R712	1-249-429-11 1-249-429-11 1-215-388-00 1-215-390-00 1-215-388-00	CARBON CARBON METAL METAL METAL	10K 10K 43 51 43	5% 5% 1% 1%	1/4W 1/4W 1/4W 1/4W 1/4W		
CN701 *1-564-511-11 CN702 *1-573-964-11 CN703 *1-691-134-11	PLUG, CONNECT PIN, CONNECT PIN, CONNECT	TOR 8P OR (PC BOARD) OR (PC BOARD)	6P 2P		R715 R716 R717 R718 R719	1-202-818-00 1-216-486-00 1-202-818-00 1-216-486-00 1-202-818-00	SOLID METAL OXIDE SOLID METAL OXIDE SOLID	1K 8.2K 1K 8.2K 1K	20% 5% 20% 5% 20%	1/2W 3W 1/2W 3W 1/2W	F F	
C737 1-102-934-00  C00  CN701 *1-564-511-11  CN702 *1-573-964-11  CN703 *1-691-134-11  CN703 *1-691-134-11  CN703 8-719-911-19  D704 8-719-911-19  D705 8-719-911-19  D706 8-719-911-19  D707 8-719-911-19  D708 8-719-901-83  D709 8-719-901-83  D713 8-719-901-83  D715 8-719-901-83  D716 8-719-901-83  D717 8-719-901-83	DIODE 1SS119 DIODE 1SS119 DIODE 1SS119 DIODE 1SS119 DIODE 1SS119			· · · · · · · · · · · · · · · · · · ·	R720 R722 R723 R724 R725	1-216-486-00 1-202-883-11 1-202-838-00 1-202-842-11 1-202-838-00	METAL OXIDE SOLID SOLID SOLID SOLID	8.2K 680K 100K 220K 100K	5% 20% 20% 20% 20%	3W 1/2W 1/2W 1/2W 1/2W	F	
D706 8-719-911-19 D707 8-719-901-83 D708 8-719-901-83 D709 8-719-901-83 D713 8-719-901-83	DIODE 1SS119 DIODE 1SS83 DIODE 1SS83 DIODE 1SS83 DIODE 1SS83 DIODE 1SS83				R726 R727 R728 R729 R730	1-202-846-00 1-202-842-11 1-202-837-00 1-202-549-00 1-202-842-11	SOLID SOLID SOLID SOLID SOLID	470K 220K 82K 100 220K	20% 20% 20% 20% 20%	1/2W 1/2W 1/2W 1/2W 1/2W		
D715 8-719-901-83 D716 8-719-901-83 D717 8-719-901-83	DIODE 1SS83 DIODE 1SS83 DIODE 1SS83			:	R731 R732 R733 R734 R735	1-249-409-11 1-249-409-11 1-249-409-11 1-249-409-11 1-249-409-11	CARBON CARBON CARBON CARBON CARBON	220 220 220 220 220 220	5% 5% 5% 5%	1/4W 1/4W 1/4W 1/4W 1/4W	F	
<ja J701 <u>А</u>. 1-526-798-29 <c0< td=""><td>SOCKET, PITU</td><td></td><td></td><td></td><td>R736 R737 R738 R739 R740</td><td>1-249-409-11 1-247-807-31 1-247-807-31 1-247-807-31 1-249-433-11</td><td>CARBON CARBON CARBON CARBON CARBON</td><td>220 100 100 100 22K</td><td>5% 5% 5% 5%</td><td>1/4W 1/4W 1/4W 1/4W 1/4W</td><td>F</td><td></td></c0<></ja 	SOCKET, PITU				R736 R737 R738 R739 R740	1-249-409-11 1-247-807-31 1-247-807-31 1-247-807-31 1-249-433-11	CARBON CARBON CARBON CARBON CARBON	220 100 100 100 22K	5% 5% 5% 5%	1/4W 1/4W 1/4W 1/4W 1/4W	F	
L702 1-408-413-00 L703 1-408-414-00 L704 1-408-414-00 L705 1-412-530-31 L706 1-410-667-31	INDUCTOR INDUCTOR INDUCTOR INDUCTOR	22UH 27UH 27UH 27UH 22UH			R741 R742 R744 R745 R746	1-249-433-11 1-249-433-11 1-249-423-11 1-249-429-11 1-215-879-11	CARBON CARBON CARBON CARBON METAL OXIDE	22K 22K 3.3K 10K 47K	5% 5% 5% 5%	1/4W 1/4W 1/4W 1/4W 1W	F	
	ANSISTOR>			* p = 4 *	R747 R748 R749	1-215-902-11	CARBON CARBON METAL OXIDE	10K 1K 47K	5% 5% 5% 5%	2W	F F	
Q701         8-729-119-78           Q702         8-729-119-78           Q703         8-729-119-78           Q704         8-729-200-17           Q705         8-729-200-17	TRANSISTOR 2 TRANSISTOR 2 TRANSISTOR 2	SC2785-HFE SC2785-HFE SA1091-0			R751 R752 R753 R754 R755 R756	1-247-887-00 1-247-887-00 1-249-433-11 1-249-434-11 1-249-440-11		220K 220K 220K 22K 27K 82K	5%	1/4W 1/4W 1/4W 1/4W 1/4W 1/4W		
Q706 8-729-200*17 Q707 8-729-326-11 Q708 8-729-326-11 Q709 8-729-326-11 Q710 8-729-200-17	TRANSISTOR 2 TRANSISTOR 2 TRANSISTOR 2	SC2611 SC2611 SC2611			R760	1-249-400-11 <var< td=""><td>CARBON  IABLE RESISTOR</td><td>39 &gt;</td><td>*</td><td>1/4W</td><td></td><td></td></var<>	CARBON  IABLE RESISTOR	39 >	*	1/4W		
Q711 8-729-200-17 Q712 8-729-200-17 Q713 8-729-255-12 Q714 8-729-255-12 Q715 8-729-255-12	TRANSISTOR 2 TRANSISTOR 2 TRANSISTOR 2	SA1091-0 SC2551-0 SC2551-0			RV709 *****	1-226-114-00	RES, ADJ, MET RES, ADJ, MET *************** H BOARD, COMP	'AL GLA ****** 'LETE	ZE 2.2	M		
Q716 8-729-255-12		SC2551-0				*4-348-208-00	**************************************	****				
<re< td=""><td>SISTOR&gt;</td><td></td><td></td><td></td><td>]  </td><td><con< td=""><td>NECTOR&gt;</td><td></td><td></td><td></td><td></td><td></td></con<></td></re<>	SISTOR>				] 	<con< td=""><td>NECTOR&gt;</td><td></td><td></td><td></td><td></td><td></td></con<>	NECTOR>					

The components identified by shading and mark A are critical for safety. Replace only with part number specified.

DESCRIPTION REF.NO. PART NO. CN105 \*1-564-527-11 PLUG, CONNECTOR 12P CN106 \*1-564-526-11 PLUG, CONNECTOR 11P <DIODE> D2102 8-719-920-05 D10DE SLP281C-50 D2103 8-719-812-32 D10DE TLY123 D2104 8-719-901-33 D10DE 1SS133 <RESISTOR> 1-249-419-11 1-249-430-11 1-249-414-11 1-249-414-11 1-249-414-11 CARBON 1.5K R2101 1/4W 1/4W 1/4W 12K R2107 R2136 R2137 CARBON CARBON 560 CARBON 560 1/4W CARBON R2138 1-249-414-11 1-249-414-11 1-249-414-11 1-249-414-11 CARBON 560 R2139 1/4W 1/4W 560 CARBON R2140 R2141 R2142 CARBON CARBON 1/4W1/4W 1-249-414-11 CARBON 560 R2143 1/4W CARBON 560 1-249-414-11 R2144 1/4W 1/4W 1-249-414-11 1-249-414-11 1-215-427-00 1-215-419-00 1-215-414-00 R2145 R2147 560 1.8K CARBON METAL METAL 1/4W 820 R2148 1/4W METAL R2149 1-215-409-00 1-215-407-00 1-215-404-00 1-215-401-11 1-215-399-00 1/49 330 270 METAL R2150 R2151 R2152 METAL. 1/4W METAL 200 1/4W R2153 1/4W METAL R2154 1% 1% 1% 1% 1% 1/4W 100 1-215-397-00 METAL R2155 1/4W 1-215-421-00 1-215-416-00 1-215-410-00 R2156 METAL 1 K 620 1/4W R2157 METAL 1/4W360 METAL. 1/4W 220 1-215-405-00 R2159 METAL. 1% 1/4W R2160 1-215-421-00 METAL 1K <VARIABLE RESISTOR> RES, VAR, CARBON 20K RES, VAR, CARBON 20K RES, VAR, CARBON 20K RES, VAR, CARBON 20K RV2101 1-241-846-11 RV2103 1-241-845-11 RV2105 1-241-845-11 RV2109 1-241-845-11 RV2113 1-241-845-11 RES. VAR. CARBON 20K RES, VAR, CARBON 20K RV2117 1-241-846-11 <SWITCH> SWITCH, KEY BOARD SWITCH, KEY BOARD \$2101 1-570-101-41 \$2102 1-570-101-41 \$2103 1-570-101-41 SWITCH, KEY BOARD SWITCH, KEY BOARD 1-570-101-41 S2104 1-570-101-41 SWITCH, KEY BOARD S2105 SWITCH, KEY BOARD 1-570-969-11 SWITCH, KEY BOARD SWITCH, KEY BOARD SWITCH, KEY BOARD SWITCH, KEY BOARD 1-570-969-11 1-570-101-41 1-570-101-41 S2107 \$2108 \$2109 \$2110 1-570-101-41 SWITCH, KEY BOARD SWITCH, KEY BOARD SWITCH, KEY BOARD SWITCH, KEY BOARD 1-570-101-41 1-570-101-41 1-570-969-11 S2113

1-570-969-11

REMARK | REF. NO. PART NO.

DESCRIPTION

\*

REMARK

\*A-1388-166-A J BOARD, COMPLETE \*\*\*\*\*\*\*\*\*\*\*

<CONNECTOR>

CN608 \*1-695-561-11 PIN, CONNECTOR (PC BOARD) 7P

<SWITCH>

S601 A. 1-692-921-11. SWITCH, PUSH (A.C. POWER) \*\*\*\*\*\*\*\*\*\*\*\*\*\*\*\*\*\*

\*A-1390-390-A X BOARD, COMPLETE

<CONNECROR>

CN108 \*1-564-518-11 PLUG, CONNECTOR 3P

<DIODE>

8-719-023-78 8-719-023-78 8-719-023-78 DIODE SEL3810DLC05 DIODE SEL3810DLC05 DIODE SEL3810DLC05 D001 D002 D003 DIODE SEL3810DLC05 8-719-023-78

### MISCELLANEOUS

▲ 1-426-505-11 COIL, DEMAGNETIZATION ▲ 1-451-349-11 DEFLECTION YOKE (Y20FZA) 1-537-735-11 TERMINAL BOARD ASSY, I/O (A) 1-544-063-12 SPEAKER ▲ 1-576-231-11 FUSE (H.B.C.) (4,0A/250V)

\*

V901 & 8-736-122-05 PITURE TUBE (M49KGH21X)

#### ACCESSORIES AND PACKING MATERIALS \*\*\*\*\*\*\*\*\*\*\*

\*

A. 1-590-151-11 CORD SET, POWER (10.0A/250V)
1-765-268-11 CORD, CONNECTION
3-170-078-01 HOLDER (B), PLUG
3-758-531-41 MANUAL, INSTRUCTION
\*4-043-769-01 CUSHION (UPPER) (ASSY)

\*4-043-770-01 CUSHION (LOWER) (ASSY) 4-044-040-01 LABEL, TALLY \*4-044-454-01 INDIVIDUAL CARTON

SONY. SERVICE MANUAL V03273 **AEP Model** Serial No. 2,000,501 and Higher

Chassis No. SCC-G62A-A

# **SUPPLEMENT-1**

File this supplement with the service manual.


#### INTRODUCTION


Set, having CE mark (Safety mark), have been applied to the above Serial No. and changed G Block.

New G Block shows on next pages.



## - G BOARD -





G

G

The components identified by shading and mark  $\triangle$  are critical for safety.
Replace only with part number specified.

REF.NO. PART NO.	DESCRIPTION		REMARK	REF.NO.	PART NO.	DESCRIPTION	REMARK																																								
* A-1316-213-A	G BOARD, COMPLETE (PVM-13 ************************************	54Q) 54Q) 54PM)	-	D606 D607 D608 D609 D610		DIODE RU-3AM DIODE RU-3AM DIODE ISS119-25 DIODE RU-3AM DIODE RU-3AM																																									
* A-1316-214-A	(PVM-14 (PVM-20 G BOARD, COMPLETE (PVM-13 ************************************	54QM) 50)		D612 D613 D614 D615 D616	8-719-045-48 8-719-971-65 8-719-045-48 8-719-971-65 8-719-300-33	DIODE FML-G12S DIODE RGP15J-6040 DIODE FML-G12S DIODE RGP15J-6040 DIODE RU-3AM																																									
<cap< td=""><td>ACITOR&gt;</td><td></td><td></td><td>D617</td><td>8-719-110-46</td><td>DIODE RD16ESB3</td><td></td></cap<>	ACITOR>			D617	8-719-110-46	DIODE RD16ESB3																																									
C602 A 1-136-360-51 C603 A 1-136-360-51	FILM 0.22MF FILM 0.22MF	20% 25 20% 25	50V 50V		<fus< td=""><td>A AND THE RESIDENCE OF STREET AND ADDRESS OF THE PERSON.</td><td></td></fus<>	A AND THE RESIDENCE OF STREET AND ADDRESS OF THE PERSON.																																									
C603 & 1-150-300 31 C604 & 1-161-741-21 C605 & 1-161-741-21 C606 & 1-161-741-21		10% 40 10% 40 10% 40	00Y 00Y 00Y		1-533-189-11	FUSE, GLASS TUBE 1.6A/129 HOLDER, FUSE FUSE, GLASS TUBE 1.6A/129 HOLDER, FUSE																																									
C607 A 1-161-741-21 C608 A 1-161-953-71	CERAMIC U.UU4/MF	20% 40	00Y 00Y	  -  - 	. crn	DITE DEADS																																									
C609 A 1-161-953-71 C610 A 1-161-953-71 C611 A 1-161-953-71	CERAMIC 0.0047MF CERAMIC 0.0047MF CERAMIC 0.0047MF	20% 4	00V 00V 00V	FB601		RITE BEAD> FERRITE BEAD INDUCTOR 0.4	5UH																																								
C612 A 1-137-484-61	FILM 0.47MF	10% 6	30Y	FB602 FB603	1-410-396-41 1-410-396-41	FERRITE BEAD INDUCTOR 0.45 FERRITE BEAD INDUCTOR 0.45	50H 50H																																								
C613 1-137-484-11 C614 1-129-720-00	FILM U.47MF FILM 0.033MF	10% 6	30V 30V KV	FB604 FB605	1-410-396-41 1-410-396-41	FERRITE BEAD INDUCTOR 0.4 FERRITE BEAD INDUCTOR 0.4	50H																																								
C615 1-136-619-11 C616 1-124-910-11	ELECT 47MF	20% 3	57	: :	<10>																																										
C617 1-136-557-11 C618 1-126-096-11 C619 1-124-911-11 C620 1-161-754-00	ELECT 10MF ELECT 220MF CERAMIC 0.001MF	20% 2 20% 5 10% 2	30V 55V 60V KV	į	8-749-010-47	SCREW (M3X10), P, SW (+); IC STR-S3115																																									
C621 1-125-494-11			.60V 500V	10603	4-382-854-11 8-759-701-56	SCREW (M3X10), P, SW (+); IC NJM78M05FA	10002																																								
C622 1-102-038-00 C623 1-126-944-11 C624 1-102-038-00 C625 1-124-557-11 C626 1-102-038-00	ELECT 3300MF CERAMIC 0.001MF ELECT 1000MF	20% 2 5 20% 2	50 000 50 50 50 50 50 50 50 50 50 50 50	10604	4-382-854-11 8-759-231-53 4-382-854-11	SCREW (M3X10), P, SW (+); IC TA7805S SCREW (M3X10), P, SW (+);																																									
C627 1-124-922-11	ELECT 1000MF CERAMIC 0.001MF		50V 500V		<ju)< td=""><td>IPER&gt;</td><td></td></ju)<>	IPER>																																									
C628 1-102-038-00 C629 1-124-922-11 C630 1-124-907-11 C631 1-136-853-11	ELECT 1000MF ELECT 10MF	20% 20%	50V 50V 200V	JW609	1-410-679-31	INDUCTOR 270UH (PV	M-1353MD)																																								
C632 1-124-562-11 C633 1-124-122-11	ELECT 100MF	20%	160V 50V		<c01< td=""><td></td><td></td></c01<>																																										
C634 1-124-911-11 C636 1-124-910-11 C1602 1-137-484-11	ELECT 220MF ELECT 47MF	20%	50V 50V 630V	L601 L1601 L1602	1-411-215-11 1-410-679-31 1-421-421-00	COIL, CHOKE 200UH INDUCTOR 270UH (PV COIL, CHOKE	M-1453MD)																																								
<00	NNECTOR>				<ph0< td=""><td>OTO COUPLER&gt;</td><td></td></ph0<>	OTO COUPLER>																																									
CN601 1-691-960-11 CN602 *1-695-561-11	PIN, CONNECTOR (PC BOAR PIN, CONNECTOR (PC BOAR	D) 3P D) 7P		PH601	8-749-923-50	PHOTO COUPLER PC111YS																																									
CN602 *1-595-301 11 CN603 *1-508-765-00 CN604 *1-564-506-11	) PIN, CONNECTOR (5MM PIT	CH) 3P			<tr <="" td=""><td>ANSISTOR&gt;</td><td></td></tr> <tr><td>CN605 *1-573-964-11</td><td>PIN, CONNECTOR (PC BUAR</td><td>D) 6P</td><td></td><td>Q601 Q603</td><td>8-729-303-61</td><td>TRANSISTOR 2SD774-34 TRANSISTOR 2SC3851-G</td><td></td></tr> <tr><td></td><td>PLUG, CONNECTOR 5P</td><td></td><td></td><td></td><td>4-382-854-11</td><td>SCREW (M3X10), P, SW (+);</td><td>Q603</td></tr> <tr><td>- 1 4460 4000 1000 1000 1000 1000 1000 10</td><td>IODE&gt; 9 DIODE DSA3A4-F3</td><td></td><td></td><td></td><td></td><td>SISTOR&gt;</td><td></td></tr> <tr><td>D601 A 8-719-032-3' D602 A 8-719-032-3' D603 A 8-719-032-3' D604 A 8-719-032-3' D605 8-719-971-6'</td><td>9 DIODE DSA3A4-F3 9 DIODE DSA3A4-F3 9 DIODE DSA3A4-F3</td><td></td><td></td><td>R601 Z R602</td><td>3.1-202-885-91 1-216-489-11</td><td>SOLID 1M 20% METAL OXIDE 27K 5%</td><td>1/2W 3W F</td></tr> <tr><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td></tr>	ANSISTOR>		CN605 *1-573-964-11	PIN, CONNECTOR (PC BUAR	D) 6P		Q601 Q603	8-729-303-61	TRANSISTOR 2SD774-34 TRANSISTOR 2SC3851-G			PLUG, CONNECTOR 5P				4-382-854-11	SCREW (M3X10), P, SW (+);	Q603	- 1 4460 4000 1000 1000 1000 1000 1000 10	IODE> 9 DIODE DSA3A4-F3					SISTOR>		D601 A 8-719-032-3' D602 A 8-719-032-3' D603 A 8-719-032-3' D604 A 8-719-032-3' D605 8-719-971-6'	9 DIODE DSA3A4-F3 9 DIODE DSA3A4-F3 9 DIODE DSA3A4-F3			R601 Z R602	3.1-202-885-91 1-216-489-11	SOLID 1M 20% METAL OXIDE 27K 5%	1/2W 3W F								
ANSISTOR>																																															
CN605 *1-573-964-11	PIN, CONNECTOR (PC BUAR	D) 6P		Q601 Q603	8-729-303-61	TRANSISTOR 2SD774-34 TRANSISTOR 2SC3851-G																																									
	PLUG, CONNECTOR 5P				4-382-854-11	SCREW (M3X10), P, SW (+);	Q603																																								
- 1 4460 4000 1000 1000 1000 1000 1000 10	IODE> 9 DIODE DSA3A4-F3					SISTOR>																																									
D601 A 8-719-032-3' D602 A 8-719-032-3' D603 A 8-719-032-3' D604 A 8-719-032-3' D605 8-719-971-6'	9 DIODE DSA3A4-F3 9 DIODE DSA3A4-F3 9 DIODE DSA3A4-F3			R601 Z R602	3.1-202-885-91 1-216-489-11	SOLID 1M 20% METAL OXIDE 27K 5%	1/2W 3W F																																								

The components identified by shading and mark are critical for safety.
Replace only with part number specified.

PART NO.	DESCRIPTION				REMARK
1-216-491-11 1-249-418-11 1-249-415-11	METAL OXIDE CARBON CARBON	56K 1.2K 680	5% 5% 5%	3W 1/4W 1/4W	F
1-207-642-00 1-249-423-11 1-249-426-11 1-249-426-11 1-249-421-11	WIREWOUND CARBON CARBON CARBON CARBON	0.15 3.3K 5.6K 5.6K 2.2K	10% 5% 5% 5% 5%	3W 1/4W 1/4W 1/4W 1/4W	F
1-249-417-11 1-249-404-00 1-249-419-11 1-249-385-11 1-218-265-11	CARBON CARBON CARBON CARBON METAL	1K 82 1.5K 2.2 8.2M	5% 5% 5% 5%	1/4W 1/4W 1/4W 1/4W 1W	F
1-216-341-11 1-216-341-11 1-249-443-11 1-216-341-11 1-249-443-11	METAL OXIDE METAL OXIDE CARBON METAL OXIDE CARBON	0.22 0.22 0.47 0.22 0.47	5%% 5%% 5%% 5%%	1W 1W 1/4W 1W 1/4W	÷ + + + + + + + + + + + + + + + + + + +
1-215-877-11 1-247-700-11 1-249-417-11 1-216-341-11 1-216-341-11	METAL OXIDE CARBON CARBON METAL OXIDE METAL OXIDE	22K 100 1K 0.22 0.22	5% 5% 5% 5%	1W 1/4W 1/4W 1W 1W	F
1-247-895-00 1-247-807-31 1-215-869-11 1-202-846-00	CARBON CARBON METAL OXIDE SOLID	470K 100 1K 470K	5% 5% 5% 20%	1/4W 1/4W 1W 1/2W	F
<rei< td=""><td>.AY&gt;</td><td></td><td></td><td></td><td></td></rei<>	.AY>				
<b>A</b> 1-515-738-11	RELAY				
mater of the distributions representation				erene er	
<b>5</b> .1-426-716-11	TRANSFORMER.	LINE F	ILTER-	(LFT)	
<th< td=""><td>ERMISTOR&gt;</td><td></td><td></td><td></td><td></td></th<>	ERMISTOR>				
1 <b>4</b> 1-808-059-32	THERMISTOR	P051T1V	<b>/E</b>		
<va< td=""><td>RISTOR&gt;</td><td></td><td></td><td></td><td></td></va<>	RISTOR>				
**********	*********	*****	****	******	******
	1-216-491-11 1-249-418-11 1-249-415-11 1-249-423-11 1-249-426-11 1-249-426-11 1-249-426-11 1-249-421-11 1-249-404-00 1-249-419-11 1-249-385-11 1-218-265-11 1-216-341-11 1-216-341-11 1-216-341-11 1-216-341-11 1-249-443-11 1-249-443-11 1-249-443-11 1-249-443-11 1-249-417-11 1-249-417-11 1-216-341-11 1-249-417-11 1-216-341-11 1-247-895-00 1-247-807-31 1-215-869-11 1-202-846-00 <rei 1-426-716-11="" 1-427-885-11="" 1-515-738-11="" <th<="" <tr="" a="" td=""><td>1-216-491-11 METAL OXIDE 1-249-418-11 CARBON 1-249-415-11 CARBON 1-249-423-11 CARBON 1-249-423-11 CARBON 1-249-426-11 CARBON 1-249-426-11 CARBON 1-249-421-11 CARBON 1-249-421-11 CARBON 1-249-417-11 CARBON 1-249-419-11 CARBON 1-249-419-11 CARBON 1-249-385-11 CARBON 1-218-265-11 METAL OXIDE 1-216-341-11 METAL OXIDE 1-216-341-11 METAL OXIDE 1-249-443-11 CARBON 1-216-341-11 METAL OXIDE 1-249-443-11 CARBON 1-216-341-11 METAL OXIDE 1-249-443-11 CARBON 1-216-341-11 METAL OXIDE 1-247-700-11 CARBON 1-247-807-11 CARBON 1-216-341-11 METAL OXIDE 1-247-895-00 CARBON 1-216-341-11 METAL OXIDE 1-247-807-31 CARBON 1-215-869-11 TRANSFORMER 1-426-716-11 TRANSFORMER 1-426-716-11 TRANSFORMER 1-427-885-11 TRANSFORMER</td><td>1-216-491-11 METAL OXIDE 1-249-418-11 CARBON 1.2K 1-249-415-11 CARBON 680  1-207-642-00 WIREWOUND 0.15 1-249-423-11 CARBON 5.6K 1-249-426-11 CARBON 5.6K 1-249-426-11 CARBON 5.6K 1-249-421-11 CARBON 5.6K 1-249-421-11 CARBON 1.2 CARBON 5.6K 1-249-421-11 CARBON 1.5 CARBON 1.2 C</td><td>1-216-491-11 METAL OXIDE 56K 5% 1-249-418-11 CARBON 1.2K 5% 1-249-415-11 CARBON 680 5% 1-249-425-11 CARBON 3.3K 5% 1-249-426-11 CARBON 5.6K 5% 1-249-426-11 CARBON 5.6K 5% 1-249-426-11 CARBON 5.6K 5% 1-249-426-11 CARBON 5.6K 5% 1-249-421-11 CARBON 5.6K 5% 1-249-421-11 CARBON 5.6K 5% 1-249-421-11 CARBON 1.5K 5% 1-249-419-11 CARBON 1.5K 5% 1-249-404-00 CARBON 82 5% 1-249-419-11 CARBON 1.5K 5% 1-249-385-11 CARBON 2.2 5% 1-218-265-11 METAL OXIDE 0.22 5% 1-216-341-11 METAL OXIDE 0.22 5% 1-216-341-11 METAL OXIDE 0.22 5% 1-249-443-11 CARBON 0.47 5% 1-216-341-11 METAL OXIDE 0.22 5% 1-249-443-11 CARBON 0.47 5% 1-249-417-11 CARBON 100 5% 1-249-417-11 CARBON 100 5% 1-249-417-11 CARBON 100 5% 1-216-341-11 METAL OXIDE 0.22 5% 1-216-341-11 TRANSFORMER, LINE FILTER 1-216-341-11 TRANSFORMER, LINE FILTER 1-216-341-11 TRANSFORMER, CONVERTER 0.5% 1-215-869-11 /td><td>1-216-491-11 METAL OXIDE 56K 5% 3W 1-249-418-11 CARBON 1.2K 5% 1/4W 1-249-415-11 CARBON 680 5% 1/4W 1-249-425-11 CARBON 3.3K 5% 1/4W 1-249-426-11 CARBON 5.6K 5% 1/4W 1-249-421-11 CARBON 2.2K 5% 1/4W 1-249-421-11 CARBON 2.2K 5% 1/4W 1-249-417-11 CARBON 1.5K 5% 1/4W 1-249-419-11 CARBON 1.5K 5% 1/4W 1-249-385-11 CARBON 1.5K 5% 1/4W 1-249-385-11 CARBON 2.2 5% 1/4W 1-249-385-11 CARBON 2.2 5% 1/4W 1-216-341-11 METAL OXIDE 0.22 5% 1/4W 1-216-341-11 METAL OXIDE 0.22 5% 1/4W 1-216-341-11 METAL OXIDE 0.22 5% 1/4W 1-249-443-11 CARBON 0.47 5% 1/4W 1-249-411 CARBON 0.47 5% 1/4W 1-249-411 METAL OXIDE 0.22 5% 1/4W 1-247-807-31 CARBON 100 5% 1/4W 1-247-807-31 TRANSFORMER, LINE FILTER (LFT) 1-427-885-11 TRANSFORMER, LINE FILTER (LFT) 1-427-885-11 TRANSFORMER, CONVERTER (SRT) CHERMISTOR&gt;  **CHANSTOR**  **A1-426-716-11 TRANSFORMER, LINE FILTER (LFT) 1-427-885-11 TRANSFORMER, CONVERTER (SRT)</td></rei>	1-216-491-11 METAL OXIDE 1-249-418-11 CARBON 1-249-415-11 CARBON 1-249-423-11 CARBON 1-249-423-11 CARBON 1-249-426-11 CARBON 1-249-426-11 CARBON 1-249-421-11 CARBON 1-249-421-11 CARBON 1-249-417-11 CARBON 1-249-419-11 CARBON 1-249-419-11 CARBON 1-249-385-11 CARBON 1-218-265-11 METAL OXIDE 1-216-341-11 METAL OXIDE 1-216-341-11 METAL OXIDE 1-249-443-11 CARBON 1-216-341-11 METAL OXIDE 1-249-443-11 CARBON 1-216-341-11 METAL OXIDE 1-249-443-11 CARBON 1-216-341-11 METAL OXIDE 1-247-700-11 CARBON 1-247-807-11 CARBON 1-216-341-11 METAL OXIDE 1-247-895-00 CARBON 1-216-341-11 METAL OXIDE 1-247-807-31 CARBON 1-215-869-11 TRANSFORMER 1-426-716-11 TRANSFORMER 1-426-716-11 TRANSFORMER 1-427-885-11 TRANSFORMER	1-216-491-11 METAL OXIDE 1-249-418-11 CARBON 1.2K 1-249-415-11 CARBON 680  1-207-642-00 WIREWOUND 0.15 1-249-423-11 CARBON 5.6K 1-249-426-11 CARBON 5.6K 1-249-426-11 CARBON 5.6K 1-249-421-11 CARBON 5.6K 1-249-421-11 CARBON 1.2 CARBON 5.6K 1-249-421-11 CARBON 1.5 CARBON 1.2 C	1-216-491-11 METAL OXIDE 56K 5% 1-249-418-11 CARBON 1.2K 5% 1-249-415-11 CARBON 680 5% 1-249-425-11 CARBON 3.3K 5% 1-249-426-11 CARBON 5.6K 5% 1-249-426-11 CARBON 5.6K 5% 1-249-426-11 CARBON 5.6K 5% 1-249-426-11 CARBON 5.6K 5% 1-249-421-11 CARBON 5.6K 5% 1-249-421-11 CARBON 5.6K 5% 1-249-421-11 CARBON 1.5K 5% 1-249-419-11 CARBON 1.5K 5% 1-249-404-00 CARBON 82 5% 1-249-419-11 CARBON 1.5K 5% 1-249-385-11 CARBON 2.2 5% 1-218-265-11 METAL OXIDE 0.22 5% 1-216-341-11 METAL OXIDE 0.22 5% 1-216-341-11 METAL OXIDE 0.22 5% 1-249-443-11 CARBON 0.47 5% 1-216-341-11 METAL OXIDE 0.22 5% 1-249-443-11 CARBON 0.47 5% 1-249-417-11 CARBON 100 5% 1-249-417-11 CARBON 100 5% 1-249-417-11 CARBON 100 5% 1-216-341-11 METAL OXIDE 0.22 5% 1-216-341-11 TRANSFORMER, LINE FILTER 1-216-341-11 TRANSFORMER, LINE FILTER 1-216-341-11 TRANSFORMER, CONVERTER 0.5% 1-215-869-11	1-216-491-11 METAL OXIDE 56K 5% 3W 1-249-418-11 CARBON 1.2K 5% 1/4W 1-249-415-11 CARBON 680 5% 1/4W 1-249-425-11 CARBON 3.3K 5% 1/4W 1-249-426-11 CARBON 5.6K 5% 1/4W 1-249-421-11 CARBON 2.2K 5% 1/4W 1-249-421-11 CARBON 2.2K 5% 1/4W 1-249-417-11 CARBON 1.5K 5% 1/4W 1-249-419-11 CARBON 1.5K 5% 1/4W 1-249-385-11 CARBON 1.5K 5% 1/4W 1-249-385-11 CARBON 2.2 5% 1/4W 1-249-385-11 CARBON 2.2 5% 1/4W 1-216-341-11 METAL OXIDE 0.22 5% 1/4W 1-216-341-11 METAL OXIDE 0.22 5% 1/4W 1-216-341-11 METAL OXIDE 0.22 5% 1/4W 1-249-443-11 CARBON 0.47 5% 1/4W 1-249-411 CARBON 0.47 5% 1/4W 1-249-411 METAL OXIDE 0.22 5% 1/4W 1-247-807-31 CARBON 100 5% 1/4W 1-247-807-31 TRANSFORMER, LINE FILTER (LFT) 1-427-885-11 TRANSFORMER, LINE FILTER (LFT) 1-427-885-11 TRANSFORMER, CONVERTER (SRT) CHERMISTOR>  **CHANSTOR**  **A1-426-716-11 TRANSFORMER, LINE FILTER (LFT) 1-427-885-11 TRANSFORMER, CONVERTER (SRT)

Sony Corporation
B & I Systems Company

English 95EZ24079-1 Printed in Japan ©1995. 5